



6408—CTA Line Matrix Printer

G246-0084-01

Maintenance Information Manual

5

Adjustment Procedures

Chapter Contents

| | |
|---|------|
| Preparing the Printer for Maintenance | 5-2 |
| Returning the Printer to Normal Operation | 5-3 |
| Belt, Paper Feed Timing, Adjustment | 5-4 |
| Belt, Platen Open, Adjustment | 5-6 |
| Paper Drive Motor Pulley Alignment | 5-8 |
| Paper Scale Alignment | 5-10 |
| Platen Angle Adjustment | 5-12 |
| Platen Gap Adjustment | 5-14 |
| Platen Open Motor Pulley Alignment | 5-16 |
| Ribbon Guide Alignment | 5-18 |
| Splined Shaft Skew Adjustment | 5-20 |
| Adjusting the End of Forms Distance | 5-22 |
| Hammer Phasing Adjustment | 5-27 |

Preparing the Printer for Maintenance

DANGER

Unplug the printer power cord from the power outlet before doing any maintenance procedure. Failure to remove power could result in injury to you or damage to equipment. If you must apply power during maintenance, you will be instructed to do so in the maintenance procedure.

To prepare the printer for maintenance, do the following steps *before* making an adjustment:

1. Set the printer power switch to O (off).
2. Unplug the printer power cord from the AC power source.
3. Unload paper.
4. Read the entire adjustment procedure before you begin working on the printer.
5. Gather the necessary parts before you begin working on the printer.

Returning the Printer to Normal Operation

When you are finished servicing the printer, restore it to operation by following the steps below:

1. Install the ribbon.
2. Plug the AC power cord into the printer and the power source.
3. Set the printer power switch to 1 (on).
4. Load paper.
5. Close the cabinet doors and the printer cover.
6. Test printer operation by selecting and running one of the operator print tests.
7. Select the emulation. (Refer to the *Operator's Guide*.)
8. Set the top-of-form. (Refer to the *Operator's Guide*.)

Belt, Paper Feed Timing, Adjustment (Figure 5-1)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the paper guide assembly (page 6-40).
4. Remove four screws and the barrier shield (page 6-75, Figure 6-10).
5. Remove the timing belt cover (1) by squeezing the top and bottom to release the plastic tabs from the slots in the side plate.
6. Loosen (do not remove) the motor mount bolts (2).
7. Using the straight end of a force gauge, apply 12 pounds (53.4 N) of pressure to the paper feed drive motor (3). Use the splined shaft (4) to steady the gauge.
8. Reduce tension to 9 pounds (40.0 N) and torque the paper feed motor mount bolts (2) to 18 ± 2 inch-pounds ($2.03 \pm 0.23 \text{ N}\cdot\text{m}$).
9. Snap the timing belt cover (1) into the slots in the side plate.
10. Install the barrier shield and four screws (page 6-75, Figure 6-10).
11. Install the paper guide assembly (page 6-40).
12. Return the printer to normal operation (page 5-3).




Figure 5-1. Paper Feed Timing Belt Adjustment


Belt, Platen Open, Adjustment (Figure 5-2)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the platen open belt cover (1) by squeezing the top and bottom to release the plastic tabs from the slots in the side plate.
4. Loosen the motor mount screws (2).
5. Close the forms thickness lever all the way.

WARNING

Too much tension on the platen open belt can cause the platen gap to change, which can lead to premature wear of the platen, damaged hammer tips, and poor print quality.

6. Using a force gauge, apply 10 ± 1 pounds (44.48 ± 4.45 N) of tension to the platen open motor shaft (3), pulling away from the large platen pulley.
7. Reduce tension to 5 ± 1 pounds (22.24 ± 4.45 N) and torque the motor mount screws (2) to 11 ± 2 inch-pounds (1.24 ± 0.23 N•m).
8. Check the platen gap (page 5-14). Loosen the belt and readjust the gap if necessary.
9. Snap the platen open belt cover (1) into the slots in the side plate.
10. Return the printer to normal operation (page 5-3).



- 1. Belt Cover
- 2. Motor Mount Screw
- 3. Platen Open Motor Shaft




Figure 5-2. Platen Open Belt Adjustment

Paper Drive Motor Pulley Alignment (Figure 5-3)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the timing belt cover (1) by squeezing the top and bottom to release the plastic tabs from the slots in the side plate.
4. Loosen the set screw (2) in the motor pulley collar (3).
5. Align the paper drive motor pulley (4) with the splined shaft pulley (5).

WARNING

Make sure there is at least 0.010 inches (0.25 mm) of clearance between the collar/pulley and the motor face plate.

6. Hold the collar (3) flush against the motor pulley (4) and tighten the set screw (2):
 - a. If the pulley (4) is black (aluminum), torque the set screw to 11 \pm 2 inch-pounds (1.24 \pm 0.23 N•m).
 - b. If the pulley (4) is silver (steel), torque the set screw to 25 \pm 2 inch-pounds (2.82 \pm 0.23 N•m).
7. Check for correct tension on the paper feed timing belt (page 5-4). Adjust if necessary.
8. Snap the timing belt cover (1) into the slots in the side plate.
9. Return the printer to normal operation (page 5-3).





Figure 5-3. Paper Drive Motor Pulley Alignment

Paper Scale Alignment (Figure 5-4)

1. Load paper and ribbon.
2. Connect the power cord to the AC power source.
3. Set the printer power switch to 1 (on).
4. Open the printer cover.
5. Verify that the shuttle cover (1) is properly installed (page 6-23).
6. Print a full 132 column line by selecting and running one of the diagnostic self-tests. (See Chapter 4.)
7. Check alignment of the scale to the print at column positions 1 and 132.
8. If adjustment is necessary, loosen the three button-head 5/64 inch hex screws (2).
9. Position the scale (3) so that column positions 1 and 132 line up with the first and last characters on the 132 character printout.
10. Tighten the button-head screws (2).
11. Close the printer cover.




1. Shuttle Cover
2. Screw, Button-Head, 5/64 inch hex (3)
3. Paper Scale

Figure 5-4. Paper Scale Alignment

Platen Angle Adjustment (Figure 5-5)

1. Prepare the printer for maintenance (page 5-2).
2. Remove the shuttle frame assembly (page 6-55).
3. Close the forms thickness lever (1) all the way. (Position 'A' on the scale.)
4. Install the platen position gauge (2) and check the angle of the platen (3): forms thickness lever should be against the platen stop, the flat surface of the platen flush with the position gauge, and the position gauge flat on the mechanism base.
 - a. If the angle is correct, no adjustment is necessary. Go to step 7.
 - b. If the angle is incorrect, loosen the clamp screw (4) and set screw (5).
5. Position the platen (3) at the correct angle.
6. Slide the platen (3) to the right and the forms thickness lever (1) to the left to remove end play. Ensure that the forms thickness lever is fully closed. Tighten the clamp screw (4), then tighten the setscrew (5).
7. Remove the platen position gauge (2).
8. Check the platen gap adjustment (page 5-14).
9. Install the shuttle frame assembly (page 6-55).
10. Check the hammer phasing adjustment (page 5-27).
11. Return the printer to normal operation (page 5-3).

- 
1. Forms Thickness Lever
2. Platen Position Gauge
3. Platen
4. Clamp Screw
5. Setscrew
- The diagram shows a mechanical assembly with a large roller at the top. Below the roller, there is a complex arrangement of levers, gauges, and screws. A circular callout 'A' is located on the right side of the assembly.




Figure 5-5. Platen Angle Adjustment

Platen Gap Adjustment (Figure 5-6)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the shuttle cover assembly (page 6-23).
4. Remove the ribbon.
5. Loosen the platen open belt (page 5-6, steps 3. and 4.).
6. Raise the forms thickness lever (1) to the fully open position.

WARNING

Do not force the platen against the feeler gauge. Damage to the printer will result.

7. Insert a 0.010 inch (0.25 mm) flat feeler gauge (2) straight down between the hammer bank cover plate (3) and ribbon mask (4), within four hammer positions of the left end of the hammer bank.
8. Gently close the forms thickness lever (1). As the platen is closing, gently slide the feeler gauge up and down, keeping it between the hammer tip and ribbon mask. If the feel is too tight when the platen is being closed, adjust the set screw (5) at the end of the platen counterclockwise. If the feel is too loose, adjust the set screw clockwise. With the forms thickness lever closed all the way, the feeler gauge should contact both the tips and the ribbon mask and move with light friction. Shift the gauge slightly to verify.
9. Repeat steps 6. through 8. at the right end of the hammer bank.
10. After adjusting both sides, check the gap again at both ends. Readjust if necessary.
11. When the platen gap is correct at both ends of the platen, adjust the platen open belt (page 5-6).
12. Install the shuttle cover assembly (page 6-23).
13. Check the hammer phasing adjustment (page 5-27).
14. Return the printer to normal operation (page 5-3).




Figure 5-6. Platen Gap Adjustment

Platen Open Motor Pulley Alignment (Figure 5-7)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the platen open belt cover (1) by squeezing the top and bottom to release the plastic tabs from the slots in the side plate.
4. Loosen the set screw (2) in the motor pulley.
5. Align the platen open motor pulley (3) with the platen shaft pulley (4) and tighten the set screw (2) to 9 ± 2 inch-pounds (1.02 ± 0.23 N•m).
6. Check the platen open belt tension (page 5-6). Adjust if necessary.
7. Snap the platen open belt cover (1) into the slots in the side plate.
8. Return the printer to normal operation (page 5-3).







Figure 5-7. Platen Open Motor Pulley Alignment

Ribbon Guide Alignment (Figure 5-8)

1. Open the printer cover.
2. Load paper and install the ribbon. To adjust the left ribbon guide, the ribbon should have a full spool on the right hub (1).
3. Run a ribbon and shuttle diagnostic self-test. (See Chapter 4.)
4. To adjust the left ribbon guide, momentarily short between the left ribbon guide skid screws (2) to assure right to left motion of the ribbon.
5. Observe how the ribbon (3) is passing around the left ribbon guide (4). It should be centered and not folding against either of the two white nylon washers.
6. If the ribbon is not centered, loosen the retaining screws (5) just enough so that the ribbon guide (4) can be rotated to new positions, but remains in place once moved.
7. Rotate the ribbon guide (4) as necessary to center the ribbon (3).
8. Observe how the ribbon (3) is winding on the left spool (6). If the ribbon is interfering with the flange of the spool, make sure the ribbon hub and spool are mounted correctly.
9. Tighten the screws (5).
10. Allow most of the ribbon to accumulate on the left spool (6). Repeat steps 3 through 9 for the right ribbon guide (7).




1. Right Hub
2. Screw, Left Ribbon Guide Skid (2)
3. Ribbon
4. Ribbon Guide, Left
5. Screw, Retaining (2)
6. Left Ribbon Spool
7. Ribbon Guide, Right

Figure 5-8. Ribbon Guide Alignment

Splined Shaft Skew Adjustment (Figure 5-9)

If lines of print are not parallel with the edge perforations on the paper, perform the following adjustment.

1. Prepare the printer for maintenance (page 5-2).
2. Loosen the screw (1) securing the adjusting link (2).
3. Adjust the link (2) by raising or lowering the horizontal adjustment knob (3) to obtain print parallel with paper perforations. Tighten the screw (1).
4. Return the printer to normal operation (page 5-3).



- 1. Screw
- 2. Adjusting Link
- 3. Horizontal Adjustment Knob

Figure 5-9. Splined Shaft Skew Adjustment

Adjusting the End of Forms Distance

This procedure tests and sets the distance from the page perforation at which an END OF FORMS fault message is triggered. This adjustment prevents printing on the platen when the printer runs out of paper. The measurement units are dot rows.

You will use the dot row patterns printed by the END OF FORMS ADJUST self-test to verify that this parameter is set correctly.

NOTE: Do this procedure only if a new paper detector switch assembly has been installed, or if you are sure that the end of forms adjustment is incorrect. An END OF FORMS triggering distance of 1 or 2 dot rows from the perforation is acceptable; 5 to 7 dot rows off indicates adjustment is required.

Also, although it is not required, it is advisable to test the End of Forms distance with 6-part paper, in order to verify correct printing with multi-part forms.

The procedure below describes how to run the END OF FORMS ADJUST printer test and modify the END OF FORMS ADJUSTMENT VALUE.

1. Power on the printer.
2. Load paper and set the top of form. Make sure the forms thickness lever is closed. Open the cabinet front door.
3. On the paper just below the paper entrance slot, tear a four-inch square on the left side, immediately below the perforation. (See Figure 5-10.) This creates a hole that will trigger an END OF FORMS condition, but allows printing to the right of the hole (which would normally be on the platen).





Figure 5-10. Paper Preparation for Paper Out Adjustment Test

4. Tear a four inch square in the manner described above, on every third sheet, until you have made 3 or 4 holes.
5. If the printer is in **READY** mode, press **Stop** to put it into **NOT READY** mode.
6. Press **Scroll↑ + Scroll↓** to unlock the **Enter** key.
7. Press **Scroll↑ + Scroll↓ + Return + Enter** to enter the **CE Tests** menu. (Press all four keys at the same time.)
8. The display will show "**SERVICE / PRINTER MECHANISM TESTS**," the first menu item. Press **Enter** to enter the mechanism tests menu.
9. Press **Scroll↑** or **Scroll↓** until "**PRINTER MECHANISM TESTS / END OF FORMS ADJUST**" is on the display.

This test will print a vertical "comb" pattern at around column 70, each long bar separated by 4 dot rows. (An enlarged example of the comb pattern is shown below.)



10. Press **Enter** until the **END OF FORMS ADJUST** test starts. The comb pattern will print until the display shows "**001 END OF FORMS / LOAD FORMS**" and (if enabled) the audible alarm sounds. If the alarm sounds, press **Stop** to silence it.
11. Remove the paper from the tractors and examine the area of the page perforation. (If the alarm sounds when you open the platen, press **Stop** to silence it.)

If a long bar just meets the perforation, the end of forms adjustment distance is correct. (1 or 2 dot rows off is OK; 5 to 7 dot rows off is too much.) Unless you wish to restart the procedure with 6-part paper, you may stop the test here, and skip to step 22. (See the note at the beginning of this procedure.)

If the comb pattern stopped short of the perforation or printed beyond the perforation, go to step 12.

12. Measure how short or long the comb pattern printed by counting the number of dot rows needed to reach the perforation, or the number of dot rows that printed beyond the perforation.

NOTE: You can use the long bars to count the dot rows quickly. There are three dot rows between each long bar, so each long bar increases the number of dot rows by four. You can also tear off a small piece of the comb pattern from the beginning of the pattern and use it as a ruler to help you measure the dot rows required either to reach the perforation or back up to it.

13. Reload the paper and set the top of form.
14. Press **Scroll↑ + Scroll↓ + Return + Enter** to enter the CE Tests menu. (Press all four keys at the same time.)
15. The display will show "SERVICE / PRINTER MECHANISM TESTS," the first menu item. Press **Scroll↑** or **Scroll↓** until "SERVICE / END OF FORMS ADJUSTMENT VALUE" is on the display.
16. Press **Enter**. The top line of the display will show "END OF FORMS ADJUSTMENT VALUE" and the bottom line will show the current setting for the number of dots.
17. Press **Enter**. The number of dots will move up to the top line of the display.
18. Using the **Scroll↑** or **Scroll↓** key, adjust the **XX DOTS** value up or down by the number of dots you counted in step 12. (If the comb pattern stopped short of the perforation, increase the number of dots. If the comb pattern printed beyond the perforation, decrease the number of dots.)
19. Press **Enter** to select the new number of dots as the active value. (The asterisk that appears tells you that it is now the active value.)
20. Press **Stop** to put the printer into NOT READY mode.
21. Run the **END OF FORMS ADJUST** and the **END OF FORMS ADJUSTMENT VALUE** tests until the comb pattern prints at an acceptable distance from the page perforation. (Return to step 7.)
22. When the End of Forms Adjustment is acceptable, reload the paper, feed it past any remaining unused holes that you tore in it, and set the top of form.

23. Press **Scroll↑ + Scroll↓** to lock the **Enter** key.

24. Press **Start** to put the printer into **READY** mode.

Hammer Phasing Adjustment

Hammer phasing must be checked and adjusted if PROMs on the controller board are replaced.

Phasing should be adjusted with the printer printing at full paper width.

The procedure is as follows:

1. Power on the printer.
2. Install the ribbon.
3. Load full width (132 column) paper and set the top of form.
4. Press **Stop** to put the printer into NOT READY mode.
5. Press **Scroll**↑ + **Scroll**↓ to unlock the **Enter** key.
6. Press **Scroll**↑ + **Scroll**↓ + **Return** + **Enter** to enter the CE Tests menu.
(Press all four keys at the same time.)
7. The display will show "SERVICE / PRINTER MECHANISM TESTS," the first menu item. Press **Enter** to enter the mechanism tests menu.
8. Press **Scroll**↑ or **Scroll**↓ until "PRINTER MECHANISM TESTS / HAMMER PHASING" is on the display.
9. Press **Enter**. The printer begins printing all Hs, each line preceded by the phasing index number.
10. Press **Return**. The display will show "SERVICE / PRINTER MECHANISM TESTS".
11. Press **Scroll**↑ or **Scroll**↓ until "SERVICE / HAMMER PHASE VALUE" is on the display.
12. Press **Enter**. The top line of the display will show "HAMMER PHASE VALUE" and the bottom line will show the current phasing index number.
13. Press **Enter**. The phasing index (followed by an asterisk) will move up to the top line of the display.

14. Press **Scroll↑** or **Scroll↓** to increase or decrease the phasing index, followed by pressing **Enter**, which activate the value as it prints. Continue to increase or decrease the phasing index until the pattern of Hs appears as shown below:



15. When the print pattern is acceptable, press **Stop**. Printing stops, and the printer automatically enters the current phase index value into NVRAM. The display shows "NOT READY".
16. Press **Scroll↑ + Scroll↓** to lock the **Enter** key.
17. Close the printer cover. Press **Start** to put the printer into READY mode.

Note!

Before using the information and the product it works with, ensure that you read the general information under "Notices" on page vi.

First Edition (August 1994)

Second Edition (June 1995)

The following paragraph does not apply to any other country where such provisions are inconsistent with local law.

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you. Requests for IBM publications should be made to your IBM representative or to your IBM branch office serving your locality. If you request publications from the address given below, your order will be delayed because publications are not stocked there.

IBM welcomes your comments; please send your comments to:

The IBM Printing Systems Company
Information Development
Department 582, Building 004L
P.O. Box 1900
Boulder, CO 80301-9191, U.S.A.

When you send information to IBM, you grant a nonexclusive right to use or distribute the information in any way IBM believes appropriate without incurring any obligation to you.

(Copyright Symbol) Copyright International Business Machines Corporation, 1995. All rights reserved.

Note to U.S. Government Users – Documentation related to restricted rights – Use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corporation.

© Copyright International Business Machines Corporation 1995. All rights reserved.

Table of Contents

1 Maintenance Overview

| | |
|---|------|
| About the Printer | 1-2 |
| About This Manual | 1-3 |
| How to Use This Manual | 1-3 |
| Notes and Notices | 1-3 |
| Related Documents | 1-4 |
| Printing Conventions in This Manual | 1-5 |
| Controls and Indicators | 1-6 |
| Electrical Controls and Indicators | 1-6 |
| Mechanical Controls and Indicators | 1-8 |
| Tools, Test Equipment, and Supplies | 1-10 |

2 Installation

| | |
|--------------------|-----|
| Installation | 2-1 |
|--------------------|-----|

3 Preventive Maintenance

| | |
|----------------------------|-----|
| Overview | 3-2 |
| Cleaning the Printer | 3-3 |

4 Troubleshooting

| | |
|---------------------------------------|-----|
| Introduction | 4-2 |
| Troubleshooting Aids | 4-3 |
| Fault Messages | 4-4 |
| Power-On / Reset (POR) Messages | 4-5 |
| Printer State Messages | 4-6 |
| Communications Messages | 4-7 |
| Attention Messages | 4-8 |
| Recoverable Unit Checks | 4-8 |

| | |
|--|------|
| Unrecoverable Unit Checks | 4-9 |
| Symptoms Not Indicated by Fault Messages | 4-29 |
| Troubleshooting Table | 4-30 |
| Printer Confidence Check | 4-34 |
| Controller Board Diagnostic Check | 4-35 |
| Operator Print Tests | 4-37 |
| Selecting and Running Operator Print Tests | 4-39 |
| Customer Engineer Tests | 4-40 |
| Selecting and Running CE Tests | 4-42 |
| Hex Code Printout | 4-43 |
| Soft vs. Hard Reset | 4-46 |

5 Adjustment Procedures

| | |
|---|------|
| Preparing the Printer for Maintenance | 5-2 |
| Returning the Printer to Normal Operation | 5-3 |
| Belt, Paper Feed Timing, Adjustment | 5-4 |
| Belt, Platen Open, Adjustment | 5-6 |
| Paper Drive Motor Pulley Alignment | 5-8 |
| Paper Scale Alignment | 5-10 |
| Platen Angle Adjustment | 5-12 |
| Platen Gap Adjustment | 5-14 |
| Platen Open Motor Pulley Alignment | 5-16 |
| Ribbon Guide Alignment | 5-18 |
| Splined Shaft Skew Adjustment | 5-20 |
| Adjusting the End of Forms Distance | 5-22 |
| Hammer Phasing | 5-27 |

6 Replacement Procedures and Illustrated Parts List

| | |
|------------------------------------|-----|
| Organization of This Chapter | 6-3 |
|------------------------------------|-----|

Section I: Replacement Procedures

| | |
|---|-----|
| Preparing the Printer for Maintenance | 6-4 |
|---|-----|

| | |
|---|------|
| Belt, Paper Feed Timing | 6-5 |
| Belt, Platen Open | 6-6 |
| Cable Assembly W4, Hammer Bank | 6-8 |
| Cable Assembly W5, Intermediate | 6-10 |
| Cable Assembly, Multi I/O | 6-12 |
| Circuit Board: LP30-CT Controller | 6-14 |
| Circuit Board: LP30 Backplane | 6-16 |
| Circuit Board: Mechanism Driver | 6-18 |
| Circuit Board: Power Supply | 6-20 |
| Circuit Breaker | 6-21 |
| Operator Panel Assembly | 6-38 |
| Cover Assembly, Hammer Bank | 6-22 |
| Cover Assembly, Shuttle | 6-23 |
| Diskette Drive Assembly | 6-24 |
| Fan Assembly, Card Cage | 6-26 |
| Fan Assembly, Cabinet Exhaust | 6-27 |
| Fan Assembly, Hammer Bank | 6-28 |
| Hammer Spring Assembly | 6-29 |
| Magnetic Pick-up (MPU) Assembly | 6-32 |
| Motor Assembly, Ribbon Drive | 6-33 |
| Motor Assembly, Paper Feed | 6-34 |
| Motor Assembly, Platen Open | 6-36 |
| Paper Guide Assembly | 6-40 |
| Paper Ironer | 6-41 |
| Paper Stacker Tray Assembly | 6-42 |
| Platen | 6-43 |
| PROMs and Modules on the Controller Board | 6-46 |
| PROMs on the Mechanism Driver Board | 6-48 |
| Ribbon Hub | 6-50 |
| Ribbon Guide Assembly (L/R) | 6-51 |
| Security Module | 6-46 |
| Shaft, Splined | 6-52 |
| Shaft, Support | 6-54 |
| Shuttle Frame Assembly | 6-55 |

| | |
|---|------|
| Spring Assembly, Gas | 6-57 |
| Spring, Extension | 6-58 |
| Switch Assembly, Cover Open | 6-59 |
| Switch Assembly, Paper Detector | 6-60 |
| Switch Assembly, Platen Interlock | 6-61 |
| Tractor (L/R) | 6-62 |
| Returning the Printer to Normal Operation | 6-63 |

Section II: Illustrated Parts List

| | |
|---|------|
| Figure 6-6. Top Cover, Doors, and Casters | 6-67 |
| Figure 6-7. Paper Stacker Tray Assembly and Paper Chains | 6-69 |
| Figure 6-8. Operator Panel and Cabinet Details | 6-71 |
| Figure 6-9. Floppy Diskette Drive | 6-73 |
| Figure 6-10. Covers | 6-75 |
| Figure 6-11. Print Mechanisms and Card Cage | 6-77 |
| Figure 6-13. Magnetic Pickup Unit (MPU) and Extension Spring | 6-81 |
| Figure 6-14. Tractor Shafts | 6-83 |
| Figure 6-15. Platen | 6-85 |
| Figure 6-16. Motors, Card Cage Fan, and Paper Detector Switch | 6-87 |
| Figure 6-17. Circuit Breaker | 6-89 |
| Figure 6-18. Cable Assembly W4, Hammer Bank | 6-91 |
| Figure 6-19. Cable Assembly W5, Intermediate, and Cover Open Switch Assembly | 6-93 |

7 Principles of Operation

| | |
|---|------|
| Functional Elements of the Printer | 7-2 |
| Operator Panel | 7-4 |
| Controller Board | 7-5 |
| Controller Communication with the Host Computer and Operator | 7-6 |
| Printing | 7-8 |
| Fault Monitoring | 7-11 |
| Hardware Summary | 7-12 |
| Mechanism Driver Board | 7-17 |

| | |
|-----------------------------------|------|
| Ribbon Drive System | 7-17 |
| Shuttle Drive System | 7-19 |
| Paper Feed System | 7-19 |
| Reverse Paper Feed System | 7-20 |
| Magnetic Pick-up Unit (MPU) | 7-20 |
| Power Supply Board | 7-21 |
| AC Power | 7-21 |
| DC Power | 7-21 |
| Printing Mechanism | 7-22 |
| Shuttle Frame Assembly | 7-22 |
| Paper Transport System | 7-26 |
| Ribbon Transport System | 7-27 |
| Printer Interface | 7-28 |

Appendices

- A Wire Data**
- B Printer Specifications**
- C Ferrite Noise Suppression Cores**
- D Metric Conversion Tables**
- E Torque Table**
- F Safety Inspection Guide**
- G Acronyms and Signal Mnemonics**
- H Power Cords**
- I Part Numbers**

Index

Notices

References in this publication to IBM products, programs, or services do not imply that IBM intends to make these available in all countries in which IBM operates. Any reference to an IBM product, program, or service is not intended to state or imply that only IBM's product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any of the intellectual property rights of IBM may be used instead of the IBM product, program, or service. The evaluation and verification of operation in conjunction with other products, except those expressly designated by IBM, are the responsibility of the user.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to use these patents. You can send license inquiries, in writing, to the IBM Director of Commercial Relations, IBM Corporation, Purchase, NY 10577, U.S.A.

Electronic Emission Notices

Federal Communications Commission (FCC) Statement

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canadian Department of Communications Compliance Statement

This equipment does not exceed Class A limits per radio noise emission for digital apparatus, set out in the Radio Interference Regulation of the Canadian Department of Communications.

Operation in a residential area may cause unacceptable interference to radio and TV reception requiring the owner or operator to take whatever steps are necessary to correct the interference.

Avis de conformité aux normes du ministère des Communications du Canada.

Cet équipement n dépasse pas les limites de Classe A d'émission de bruits radioélectriques pour les appareils numériques, telles que prescrites par le Règlement sur brouillage radioélectrique établi par le ministère de Communications du Canada. L'exploitation faite en milieu résidentiel peut entraîner le brouillage des réceptions radio et télé, ce qui obligerait le propriétaire ou l'opérateur à prendre les dispositions nécessaires pour en éliminer les causes.

New Zealand Compliance Statement

This is a Class A computing device and shall not be located at a distance closer than 20 meters from the boundary of a residential property.

United Kingdom Telecommunications Compliance Act

This equipment is approved under approval number NS/G/23/J/100003 for indirect connections to the public telecommunications systems in the United Kingdom.

Trademarks and Service Marks

The following terms, denoted by an asterisk (*) in this publication, are trademarks of the IBM Corporation in the United States or other countries or both.

IBM

SCS

The following terms, denoted by a double asterisk (**) in this publication, are trademarks of other companies:

Code V

ECOS

Fluke

IGP

Printronic

Quality Micro Systems, Inc.

ECOS Electronics Corp., Inc., Oak Park, Ill.

John Fluke Manufacturing Co., Inc.

Printronic, Inc.

Printronic, Inc.

Safety Notices

DANGER

To prevent serious personal injury from electrical shock when connecting or disconnecting the signal cable, set the printer power switch to the off position and unplug the power cable.

DANGER

Always disconnect the AC power cord from the power source before performing any maintenance procedure. Failure to remove power could result in injury to persons or damage to equipment. If you must apply power during maintenance, you will be instructed to do so in the maintenance procedure.

DANGER

Always disconnect the AC power cord before cleaning the printer.

DANGER

To prevent injury from electric shock, wait at least one minute after shutting off power before removing the power supply circuit board. Wear a properly grounded static wrist strap when handling the power supply board. Handle the board by the ejection levers and the sides. Do not touch components or flex the board during removal/installation.

CAUTION

Over time, the upper edge of the paper ironer can become sharp. To avoid cutting yourself, handle the paper ironer on the sides.

CAUTION

Hold the printer cover securely while disengaging the gas spring assembly.

DANGER

Exercise caution when configuring the printer. Exposed moving parts can cause injury, and electrical currents are shock hazards.

Sikkerhedsinstruktioner

DANISH

FARE

Hver gang De vil sætte ledningen, der forbinder computeren og printeren, i eller tage den ud, skal De først slukke for printeren og tage stikket ud af stikkontakten for at forebygge alvorlig personskade der forvoldes af elektriske stød.

FARE

Afbryd altid strømmen ved at tage stikket ud af kontakten inden De foretager nogen form for vedligeholdelsesprocedure. Undlader man at afbryde strømmen kan det føre til maskin- eller personskade. Dersom der skal bruges strøm under vedligeholdelseeftersyn, vil De blive instrueret om at slutte den til i vedligeholdelsesvejledningen.

FARE

Tag stikket ud af kontakten inden De gør printeren ren.

FARE

Til at forebygge skader, der forvoldes af elektriske stød, skal De vente mindst eet minut efter strømmen er blevet afbrudt med at udtage spændingslederpladen. Bær en antistatisk håndledsrem, der er korrekt jordforbundet, mens De håndterer spændingslederpladen. Tag kun på pladen ved udskydningsbeslagene og på siderne. Rør ikke ved komponenterne og vrid ikke pladen ved udtagning eller isætning.

FORSIGTIG

Med tiden kan overkanten af papirudglatteren blive skarp, så for ikke at skære sig, skal man kun holde papirudglatteren på siderne.

FORSIGTIG

Sørg for at printerdækslet holdes fast mens dækselpumpen frigøres.

FARE

Udvis forsigtighed mens printeren konfigureres. Blottede bevægelige dele kan forvolde skade og tændt strøm udgør risiko for stød.

Veiligheidsaanwijzingen

DUTCH

GEVAARLIJK

Om zwaar letsel door elektrische schok te voorkomen bij het aansluiten of loskoppelen van de signaalkabel, dient u de printer uit te schakelen en het netsnoer uit het stopcontact te nemen.

GEVAARLIJK

Neem het netsnoer altijd uit het stopcontact voordat u onderhoudswerkzaamheden gaat uitvoeren. Het niet afsluiten van de stroom kan persoonlijk letsel of beschadiging van de apparatuur tot gevolg hebben. Mocht u tijdens onderhoudswerkzaamheden toch netvoeding nodig hebben, dan worden daarover in de beschrijving van het onderhoud aanwijzingen gegeven.

GEVAARLIJK

Neem het netsnoer uit het stopcontact voordat u de printer gaat schoonmaken.

GEVAARLIJK

Om letsel door elektrische schok te voorkomen, dient u na het uitschakelen van de printer minstens één minuut te wachten voordat u de printplaat voor de voeding verwijdt. Maak gebruik van een op juiste wijze geaarde statische polsband als u de printplaat voor de voeding moet aanraken. Pak de plaat aan de zijkanten beet bij de daarvoor bestemde hendeltjes. Tijdens het demonteren/installeren geen onderdelen aanraken en de plaat niet verbuigen.

VOORZICHTIG

Na verloop van tijd kan de bovenkant van de papierstrijker scherp worden. Om te voorkomen dat u zich snijdt, dient u de papierstrijker bij de zijkanten beet te pakken.

VOORZICHTIG

Houd de printerkap goed op zijn plaats als u de gasveerconstructie loszet.

GEVAARLIJK

Ga bij het configureren van de printer voorzichtig te werk. Onbedekte bewegende onderdelen kunnen letsel veroorzaken en sommige onderdelen kunnen onder spanning staan.

Huomautuksia Turvallisuudesta

FINNISH

VAARA

Sähköisku voi aiheuttaa vakavia henkilövahinkoja. Tästä syystä täytyy kirjoittimesta aina katkaista virta ja irrottaa virtakaapeli, kun signaalikaapeli liitetään tai irrotetaan.

VAARA

Irrota aina vaihtovirtajohto virtalähteestä ennen huoltotoimenpiteitä. Laiminlyönti voi aiheuttaa henkilö- tai laitevahinkoja. Jos virtaa tarvitaan huollon aikana, huoltotoimenpiteiden ohjeissa on sitä koskevia neuvoja.

VAARA

Irrota vaihtovirtajohto ennen kirjoittimen puhdistamista.

VAARA

Sähköiskun estämiseksi odota ainakin yksi minuutti virran katkaisun jälkeen ennen kuin poistat virtapiirilevyn. Käytä oikein maadoitettua staattista ranneketta, kun käsittelet virtapiirilevyä. Tartu levyyn sen poistovivusta ja reunoista. Älä koske komponentteja tai taivuta levyä poiston tai asennuksen aikana.

VAROITUS

Ajan myötä voi paperinsilittäjän yläreuna terävöityä. Välttääksesi haavoja käsittele paperinsilittäjää sen reunoista.

VAROITUS

Tartu kirjoittimen kannesta tukevasti kiinni, kun irrotat kaasujousilaitetta.

VAARA

Noudata varovaisuutta kirjoitinta asennettaessa. Paljaat liikkuvat osat voivat aiheuttaa vahinkoja, ja sähköisissä osissa on sähköiskun vaara.

Consignes de Sécurité

FRENCH

DANGER

Afin d'éviter tout risque de blessure par électrocution lors du branchement ou du débranchement du câble de signal, mettre l'imprimante hors tension et débrancher le câble d'alimentation.

DANGER

Toujours débrancher le cordon d'alimentation en courant alternatif de la source d'alimentation avant d'effectuer toute opération d'entretien. Le fait de laisser le cordon branché peut provoquer des blessures ou endommager l'équipement. Si l'alimentation électrique est nécessaire durant l'entretien, les instructions à suivre vous renseigneront à ce sujet.

DANGER

Débrancher le cordon d'alimentation en courant alternatif avant de nettoyer l'imprimante.

DANGER

Afin d'éviter tout risque d'électrocution, attendre au moins une minute après avoir coupé l'alimentation pour retirer la carte d'alimentation électrique. Porter un bracelet statique correctement mis à la terre lors de la manipulation de la carte d'alimentation électrique. Manipuler la carte par les leviers d'éjection et les bords. Ne pas toucher les composants ou plier la carte pendant son retrait ou son installation.

ATTENTION

Après un certain temps, le bord supérieur du lisseur de papier peut devenir tranchant. Afin de ne pas se couper, manipuler le lisseur de papier par ses côtés.

ATTENTION

Bien tenir le couvercle de l'imprimante tout en désenclenchant le bloc-ressort à gaz.

DANGER

Prendre toutes les précautions nécessaires lors de la configuration de l'imprimante. Les pièces mobiles découvertes peuvent provoquer des blessures et les courants électriques présentent des dangers d'électrocution.

Hinweise zur Sicherheit

GERMAN

GEFAHR!

Um ernstliche körperliche Verletzungen durch Stromschlag beim Anschließen oder Trennen des Signalton-Kabels zu vermeiden, muß der Drucker auf jeden Fall ausgeschaltet und der Netzstecker herausgezogen werden.

GEFAHR

Bevor Sie anfallige Wartungsarbeiten durchführen, müssen Sie zuerst immer das Netzkabel aus der Steckdose ziehen. Wird das Netzkabel nicht herausgezogen, können Verletzungen oder Geräteschäden entstehen. Falls die Wartungsarbeit Stromzufuhr erfordert, wird im Wartungsablauf darauf hingewiesen.

GEFAHR

Ziehen Sie das Netzkabel aus der Steckdose, bevor Sie den Drucker reinigen.

GEFAHR

Um Verletzungen durch Elektroschocks zu vermeiden, warten Sie mindestens eine Minute nach Stromausschaltung, bevor Sie die elektrische Schaltkarte entfernen. Bitte immer einen geerdeten, statischen Handgelenkriemen tragen, wenn Sie die elektrische Schaltkarte handhaben. Halten Sie die Karte nur an den seitlichen Auswurfshebeln. Während des Herausnehmens/Installierens dürfen die Komponenten der Karte nicht berührt oder gebogen werden.

VORSICHT

Die obere Kante der Papierschiene wird mit der Zeit scharf. Halten Sie die Schiene deshalb an den Seiten, damit Sie sich nicht schneiden.

VORSICHT

Behalten Sie die Druckerabdeckung sicher im Griff, wenn Sie das Gasfederpaket entfernen.

GEFAHR

Beim Konfigurieren des Druckers ist Vorsicht geboten. Hervorstehende, bewegliche Teile können Verletzungen und Elektroschocks verursachen.

PERICOLO

Durante la connessione o la disconnessione del cavo dei segnali, spegnere la stampante e scollegare il cavo di potenza, in modo da prevenire seri infortuni causati da scosse elettriche.

PERICOLO

Per evitare danni alle persone o alle apparecchiature, disconnettere sempre l'alimentazione prima di eseguire le operazioni di manutenzione. Se sarà necessario alimentare le apparecchiature durante la manutenzione, questo sarà indicato nella procedura di manutenzione.

PERICOLO

Disconnettere l'alimentazione prima di pulire la stampante.

PERICOLO

Per prevenire incidenti a causa di scosse elettriche, dopo aver tolto l'alimentazione attendere almeno un minuto prima di rimuovere la scheda dell'alimentatore. Prima di maneggiare quest'ultima, indossare un bracciale antistatico; tenere la scheda dalle leve di espulsione e dai lati. Non toccare i componenti o flettere la scheda durante la rimozione o l'installazione.

ATTENZIONE

Col tempo la parte superiore della barra che fa pressione sulla carta può diventare tagliente. Per evitare di tagliarsi, maneggiare la barra tenendola dai lati.

ATTENZIONE

Tenere il coperchio della stampante ben saldo quando si smonta il dispositivo di ammortizzazione.

PERICOLO

Prestare attenzione durante la configurazione della stampante. Le parti mobili esposte possono causare danni alle persone e le correnti elettriche possono causare scosse elettriche.

安全上の注意点

JAPANESE

危険

保守作業を行なう前に、必ずAC電源ケーブルを抜いて、電源から切り離しておいてください。身体、または機器に損傷を与える場合があります。保守作業中に電源を必要とする場合は、その旨、保守作業操作手順に指示があります。

危険

プリンタを清掃する前に、AC電源ケーブルを抜いてください。

危険

感電事故を防ぐために、電気回路基盤を取り外す前に電源を切ってから少なくとも1分間待ってください。電気回路基盤を取り扱う際は、帯電防止リストストラップを着用してください。ボードを取り扱う際は、インジェクションレバーと両側面以外には触らないでください。また、ボードを着脱する際は、ボード上の部品に触ったり、ボードを曲げたりしないでください。

注意

時間が経つにつれて、用紙抑えの上端が鋭利になってくる場合がありますので、取り扱いには、十分に注意してください。

注意

ガススプリングアセンブリを取り外す際は、プリンタカバーをしっかりと抑えてください。

危険

プリンタの環境設定時は、必ず注意事項を守ってください。露出した部品によりケガをしたり、感電する危険があります。

危険

感電しないよう、シグナルケーブルを接続、または取りはずす際は、必ずプリンタの電源を切り、電源コードを抜いてください。

ADVARSEL

Slå av skriveren og trekk ut strømledningens støpsel fra stikkontakten når du skal koble signalkabelen til eller fra, slik at alvorlige personskader unngås som følge av elektrisk støt.

ADVARSEL

Trekk alltid ut strømledningens støpsel fra stikkontakten før vedlikeholdsarbeid utføres på skriveren. Hvis man ikke bryter strømforbindelsen til lysnettet, kan det føre til skader på personer og utstyr. Hvis strømmen må stå på under vedlikeholdet, vil dette fremgå av vedlikeholdsprosedyren.

ADVARSEL

Trekk alltid ut strømledningens støpsel fra stikkontakten før skriveren rengjøres.

ADVARSEL

Vent i minst ett minutt etter at strømtilførselen er frakoplet før kretskortet med strømforsyningen tas ut, slik at personskader unngås. Man må ha en jordnet stropp rundt håndleddet når man skal ta i strømforsyningskortet. Hold kortet i utløserarmene på sidene. Man må ikke berøre komponentene eller bøye kortet når det skal ut eller installeres.

OBS!

Med tiden kan den øvre kanten av papirutretteren bli skarp. Derfor må man ta tak i papirutretterens sider for ikke å skjære seg.

OBS!

Hold skriverdekslet på plass når den gassbaserte fjæropphengningen frigjøres.

ADVARSEL

Utvís forsiktighet under konfigureringen av skriveren. Bevegelige deler kan forårsake skader og elektrisk strøm kan gi støt.

Normas de Segurança

PORTUGUESE

PERIGO

Quando ligar ou desligar o cabo de sinal, a fim de evitar ferimentos graves devido a choque eléctrico, desligue sempre a impressora e remova o cabo de energia da tomada.

PERIGO

Desligue sempre o fio de corrente alternada da tomada, antes de executar qualquer trabalho de manutenção a fim de evitar a ocorrência de acidentes pessoais ou danificar o equipamento. Se fôr absolutamente necessário utilizar corrente durante o trabalho de manutenção, ser-lhe-ão dadas instruções específicas para os procedimentos dessa manutenção.

PERIGO

Antes de começar a limpar a impressora, desligue sempre o fio de corrente alternada da tomada.

PERIGO

A fim de evitar a ocorrência de choques eléctricos, depois de desligar a corrente, espere pelo menos um minuto para remover a unidade de fornecimento de energia da placa de circuito impresso. Ao manusear a placa de fornecimento de energia, use sempre uma correia de pulso com isolamento estático. Toque apenas nos lados e nas alavancas de ejeção da placa. Não dobre nem toque nos componentes da placa durante a sua remoção ou instalação.

ATENÇÃO

Com o tempo, a parte superior do engomador de papel, pode tornar-se aguçada. Para não se cortar, manuseie o engomador de papel pelas partes laterais.

ATENÇÃO

Ao desmontar o conjunto de peças da mola de gás, agarre sempre na cobertura da impressora.

PERIGO

Preste atenção sempre que reconfigurar a sua impressora. Quando expostas, algumas das partes da impressora podem causar ferimentos e lembre-se de que componentes eléctricos constituem perigo de choque.

Avisos de seguridad

SPANISH

PELIGRO

Para evitar daños personales causados por descarga eléctrica al conectar o desconectar el cable de señal, apague la impresora y desenchufe el cable de alimentación.

PELIGRO

Desconecte siempre el cable del enchufe antes de realizar cualquier operación de mantenimiento. El no cumplimiento de esta condición puede derivar en lesiones personales o daños en el equipo. Si tiene que utilizar la corriente durante el mantenimiento, el procedimiento se lo indicará.

PELIGRO

Desenchufe el cable antes de limpiar la impresora.

PELIGRO

Para evitar una descarga eléctrica, espere por lo menos un minuto después que desconecte la corriente y antes que desmonte la tarjeta del circuito de alimentación eléctrica. Utilice una pulsera antiestática con toma de tierra, cuando manipule la tarjeta de alimentación. Sujete la tarjeta por las palancas de expulsión o por los lados. No toque sus componentes ni la doble, durante la operación de desmontaje/instalación.

PRECAUCION

Con el tiempo, el borde superior de la plancha de papel, puede hacerse afilado. Para evitar cortarse, manipule la plancha por los lados.

PRECAUCION

Sujete firmemente la cubierta de la impresora cuando desmonte los muelles de suspensión.

PELIGRO

Tenga cuidado al configurar la impresora. Las partes móviles, cuando quedan al descubierto, pueden provocar lesiones y provocar descargas eléctricas.

Säkerhetsföreskrifter

SWEDISH

FARA

Undvik allvarliga personskador från elektriska stötar när du ansluter eller kopplar loss signalkablen, genom att stänga av strömmen till skrivaren och koppla loss nätkabeln.

FARA

Koppla alltid loss nätkabeln från strömkällan innan du utför underhåll. Om strömmen inte är avstängd kan det uppstå personskador eller skador på utrustning. Om strömmen måste vara påkopplad vid underhållsarbete anges detta i underhållsanvisningarna.

FARA

Koppla loss nätkabeln innan du rengör skrivaren.

FARA

Undvik skador från elektriska stötar genom att vänta minst en minut efter att strömmen stängts av, innan du tar ut kretskortet med strömförsörjningen. Använd ett antistatiskt armband, som är rätt jordat, när du hanterar kretskortet med strömförsörjningen. Håll endast i kortets läshandtag och i dess sidor. Vidrör ej komponenter och böj ej kortet när du tar bort eller sätter in det.

VARNING

Efter längre tids användning kan papperspressen bli vass. Undvik skärsår genom att endast hålla i papperspressens sidor.

VARNING

Håll ordentligt i skrivarhuven när du kopplar loss gasfjädringsenheten.

FARA

Var försiktig när du utför ändringar på skrivaren. Rörliga delar som frilagts kan orsaka personskador. Dessutom kan elström ge upphov till elektriska stötar.

CHAPTER I

The first part of the book is devoted to a general survey of the history of the subject. It begins with a brief account of the early attempts to explain the phenomena of life, and then proceeds to a more detailed consideration of the various theories which have been advanced from time to time.

CHAPTER II

In this chapter we shall consider the various theories which have been advanced to explain the origin of life. We shall begin with the theory of spontaneous generation, and then proceed to a consideration of the theory of biogenesis.

CHAPTER III

The third chapter is devoted to a consideration of the various theories which have been advanced to explain the evolution of life.

CHAPTER IV

In this chapter we shall consider the various theories which have been advanced to explain the origin of the human race. We shall begin with the theory of spontaneous generation, and then proceed to a consideration of the theory of biogenesis.

CHAPTER V

The fifth chapter is devoted to a consideration of the various theories which have been advanced to explain the evolution of the human race.

CHAPTER VI

In this chapter we shall consider the various theories which have been advanced to explain the origin of the human race.

CHAPTER VII

The seventh chapter is devoted to a consideration of the various theories which have been advanced to explain the evolution of the human race.

1

Maintenance Overview

Chapter Contents

| | |
|---|------|
| About the Printer | 1-2 |
| About This Manual | 1-3 |
| How to Use This Manual | 1-3 |
| Notes and Notices | 1-3 |
| Related Documents | 1-4 |
| Printing Conventions in This Manual | 1-5 |
| Controls and Indicators | 1-6 |
| Electrical Controls and Indicators | 1-6 |
| Mechanical Controls and Indicators | 1-8 |
| Tools, Test Equipment, and Supplies | 1-10 |

About the Printer

The IBM 6408-CTA Printer is a high speed line printer featuring the latest refinements in line matrix printing technology. It is designed to perform a wide variety of high-volume printing tasks with minimum maintenance and maximum reliability.

The IBM 6408-CTA is very easy to use. The operator can select every printer function either at the operator panel or by sending commands from the host computer. It is a versatile printer. The user can load printer emulations into printer memory by means of a floppy diskette.




Figure 1-1. The IBM 6408-CTA Printer

About This Manual

This is a field service maintenance manual for the IBM 6408—CTA Printer. This manual is designed so that you can quickly locate maintenance information.

How to Use This Manual

1. Locate the procedure or information you need:
 - ♦ Use the **Table of Contents** at the front of the manual.
 - ♦ Use the **Chapter Contents** listed at the front each chapter.
 - ♦ Use the **Index** at the back of the manual.
2. Read the entire procedure before you do it.
3. Gather the parts and tools you will need.
4. Make sure you understand all safety notices before you start a task.
Notes and notices are defined below.

Notes and Notices

For your safety and to protect valuable equipment, it is very important that you read and comply with all information highlighted under notes and notices:

DANGER

A danger notice calls attention to a situation that is potentially lethal or extremely hazardous to people.

CAUTION

A caution notice calls attention to a situation that is extremely hazardous to people because of some existing condition.

WARNING

A warning notice indicates the possibility of damage to a program, device, system, or data.

IMPORTANT

Important draws your attention to information vital to proper operation of the printer.

NOTE: A note gives you helpful tips about printer operation and maintenance.

Related Documents

This manual does not explain how to operate or configure the printer. For that information, refer to the *Operator's Guide* and *Set-Up Guide*:

- ♦ *6408-CTA / 6412-CTA Operator's Guide*
(IBM Form Number G246-0057-01)
- ♦ *6408-CTA / 6412-CTA Set-Up Guide*
(IBM Form Number G246-0065-01)

Information pertaining to printer control languages, emulations, and codes is in the applicable *Programmer's Reference Manual*:

- ♦ *ASCII Programmer's Reference Manual, 6408-CTA / 6412-CTA*
(IBM Form Number G246-0075-01)
- ♦ *CT Programmer's Reference Manual, 6408-CTA / 6412-CTA*
(IBM Form Number G246-0073-01)
- ♦ *IPDS Programmer's Reference Manual, 6408-CTA / 6412-CTA*
(IBM Form Number G246-0074-01)

Information pertaining to the IGP** is in the applicable *IGP Reference Manual*:

- ♦ *Code V** Printronix** Emulation Reference Manual*
(IBM Form Number G246-0086-01)
- ♦ *IGP Printronix Emulation Reference Manual*
(IBM Form Number G246-0087-01)

Printing Conventions in This Manual

- ◆ Operator panel keys and indicators are highlighted in bold.

Example: Press the **Cancel** key, then press the **Start** key.

- ◆ “Liquid Crystal Display (LCD) messages” are set off by quotation marks.

Example: Press the **Stop** key. “NOT READY” appears on the LCD.

- ◆ Key combinations are denoted by the + (plus) symbol.

Example: ‘Press **Scroll**↑ + **Scroll**↓’ means to press the **Scroll**↑ key and the **Scroll**↓ key at the same time.

Controls and Indicators

Electrical Controls and Indicators (Figure 1–2)

| Key or Indicator | Function |
|-----------------------|---|
| Power Indicator | Lit when the printer is on. |
| Ready Indicator | Lit when the printer is in READY mode (on-line), no errors are pending, and the printer is ready to process data. Off when the printer is in NOT READY mode (off-line). |
| Processing Indicator | Flashes when the printer is receiving data from the host. |
| Attention Indicator | Flashes when an error occurs. After correcting the error, press Stop to turn off this LED. |
| Power Switch | Applies power to the printer: (1 = on, 0 = off.) This switch is also a circuit breaker. |
| LCD | The Liquid Crystal Display (LCD) displays printer status messages. |
| Start | Puts the printer in the READY (on-line) mode. This key also clears fault conditions, exits program mode menus, and moves paper back to print position after View is pressed. |
| Stop | Puts the printer in the NOT READY (off-line) mode. This key also silences the audible alarm, and stops a Printer Test. Stop + Enter resets the printer. |
| Form Feed | Advances paper to next Top-Of-Form, as defined by the current page length. |
| Set Top Of Form | Sets TOF and moves paper downward from the tractor alignment notches to the print position. |
| Line Feed | Moves paper up one line, as determined by current line spacing. |
| View | Press to move the current print position up to the tractor area for viewing. Press again to return paper to original print position. |
| Cancel | Cancels a print job. |
| Eject/Restore | In READY mode, stops printing and moves page to tear-off position. In NOT READY mode, moves page to tear-off position and displays "003 FORMS EJECTED." In either mode, pressing the key again moves page back to print position. |
| Menu | If in the NOT READY mode, this key puts the printer in the PROGRAM mode. If the configuration menus are locked, the LCD indicates the operator panel is locked. |
| Enter | Selects the option displayed on the LCD. This action either sets a value, moves to the next lower level of configuration, or starts a self-test. Stop + Enter resets the printer. |
| Return | Returns to the next higher level of a configuration menu. |
| Micro↑ | In the NOT READY mode, moves the paper upward 1/72 inch ("micro-step" function). |
| Micro↓ | In the NOT READY mode, moves the paper downward 1/72 inch ("micro-step" function). |
| Scroll↑ | In the PROGRAM mode, this key moves to the next menu ("Scroll" function). |
| Scroll↓ | In the PROGRAM mode, this key moves to the previous menu ("Scroll" function). |
| Printer Configuration | Prints the current configuration. |
| Stop + Enter | Soft reset: load last saved configuration in memory. Printer must be in NOT READY mode. |
| Scroll↑ + Scroll↓ | Toggles the lock on the configuration menus. |






Figure 1-2. IBM 6408-CTA Electrical Controls and Indicators

Mechanical Controls and Indicators (Figure 1-3)

| Control or Indicator | Function |
|-----------------------------------|---|
| Forms Thickness Lever | Sets platen for paper and forms of different thicknesses. Lever must be fully opened (raised) to load or unload paper. |
| Forms Thickness Pointer and Scale | Indicates the <i>relative</i> thickness of forms or paper. Set the forms thickness lever at A for thin (single-part) forms, B for thicker forms, and so on. |
| Tractors (2) | Hold and feed paper. Used to set side margin and position paper horizontally. |
| Tractor locks (2) | Lock tractors in position. |
| Horizontal Adjustment Knob | Allows fine positioning of left print margins. Moves paper and tractors left or right. |
| Vertical Position Knob | Used to set top of form or first line to be printed. Rotate to move paper vertically. |
| Ribbon Loading Path Diagram | A diagram that helps the operator load the ribbon correctly. |
| Paper Scale | <p>A horizontal scale graduated in tenths of an inch, useful for setting paper margins and counting text columns. (See below.)</p>  |




Figure 1-3. Mechanical Controls and Indicators

Tools, Test Equipment, and Supplies

The tools and equipment required for field level maintenance of IBM 6408 printers are listed below.

| Item | Part No. |
|--|----------|
| 1 30 Inch pound Torque Screwdriver | 16F1661 |
| Alcohol | 2200200 |
| EDS Wrist Strap | 6405959 |
| Grip Ring Pliers | 9900317 |
| Floppy Drive Head Cleaning Kit | 66E5655 |
| Lubricant, Bearing | IBM #20 |
| Module Extracting Tool | 9900764 |
| Module Extraction Tool | 75X5893 |
| Platen Position Gauge | 57G1505 |
| Tie Wraps | 75X5972 |
| Torque Screwdriver Adapter | 39F8449 |
| Torque Screwdriver Hex Adapter 3/32 inch | 39F8451 |
| Torque Screwdriver Hex Adapter 5/32 inch | 39F8450 |
| Torque Screwdriver Hex Adapter 3/16 inch | 73G1461 |
| Torque Screwdriver Hex Adapter 5/64 inch | 16F1662 |

2

Installation

Installation and configuration of the IBM 6408-CTA printer are covered in the *6408-CTA / 6412-CTA Set-Up Guide* (IBM Form No. G246-0065-01).

3

Preventive Maintenance

Chapter Contents

| | |
|----------------------------|-----|
| Overview | 3-2 |
| Cleaning the Printer | 3-3 |

Overview

Aside from normal replenishment of paper and ribbons, the only preventive maintenance required of the IBM 6408-CTA printer is periodic cleaning.

Because operating conditions vary widely, the user must determine how often to clean the printer.

However, since there is no guarantee that the user will clean the printer regularly, you should clean the printer whenever you are called to service it.

DANGER

Always unplug the printer power cord before cleaning the printer.

Cleaning the Printer

WARNING

Do not use abrasive cleaners, particularly on the window.

Do not drip water into the printer. Damage to the equipment will result.

Do not spray directly onto the printer when using spray solutions (spray the cloth, then apply the dampened cloth to the printer).

Do not vacuum circuit boards.

Cleaning the Cabinet Exterior

1. Power off the printer.
2. Disconnect the AC power cord from the printer and the power source.
3. Wipe the cabinet with a clean, lint-free cloth dampened (not wet) with water and a mild detergent or window cleaning solution.
4. Dry the cabinet with a clean, lint-free cloth.
5. Clean the inside of the cabinet (page 3-4).

Cleaning the Cabinet Interior (Figure 3-1)

1. Power off the printer.
2. Disconnect the AC power cord from the power source and the printer.
3. Open the printer cover.
4. Open the forms thickness lever.
5. Remove paper from the printer.
6. Remove the ribbon.
7. Using a soft-bristled, non-metallic brush, wipe paper dust and ribbon lint off the tractors, shuttle cover assembly, base casting, and ribbon guides. Vacuum up the residue.
8. Wipe the splined shaft with a soft cloth.

WARNING

To avoid corrosion damage, use only alcohol when cleaning printer mechanical elements. Make sure the cleaning solution contains no water.

9. Using a cloth dampened (not wet) with alcohol, clean the ribbon guides.
10. Vacuum up dust or residue that has accumulated inside the lower cabinet.
11. Wipe the interior of the lower cabinet with a clean, lint-free cloth dampened with water and a mild detergent or window cleaning solution.
12. Dry the cabinet interior with a clean, lint-free cloth.
13. Clean the shuttle frame assembly (page 3-6).




Figure 3-1. Cleaning Inside the Cabinet

Cleaning the Shuttle Frame Assembly (Figure 3–2)

1. Remove the shuttle cover assembly (page 6–23).
2. Remove the shuttle frame assembly (page 6–55).
3. Remove the paper ironer (page 6–41).

CAUTION

Over time, the upper edge of the paper ironer can become sharp. To avoid cutting yourself, handle the paper ironer on the sides.

4. Moisten a clean, soft cloth with alcohol. Wipe the paper ironer to remove lint, ink, and paper residue.
5. Install the paper ironer (page 6–41).
6. Remove the hammer bank cover assembly (page 6–22).
7. Moisten a clean, soft cloth with alcohol. Wipe the hammer bank cover assembly to remove lint, ink, and paper residue. Clean the holes in the cover strips.

WARNING

Do not use any solvents to clean the hammer tips. Clean the hammer tips gently—too much pressure can chip hammer tips.

8. Using a stiff, non-metallic brush (such as a toothbrush), gently brush the hammer tips to remove lint and ink accumulations. Vacuum up any residue.

WARNING

The hammer bank contains a strong magnet. To prevent damage to the hammer tips, do not let the hammer bank cover assembly snap into place as the hammer bank magnet attracts it. Any impact of the cover against the hammer bank can break hammer tips.

9. Install the hammer bank cover assembly (page 6–22).
10. Install the shuttle frame assembly (page 6–55).
11. Install the shuttle cover assembly (page 6–23).
12. Clean the card cage fan assembly (page 3–8).




Figure 3-2. Cleaning the Shuttle Frame Assembly

Cleaning the Card Cage Fan Assembly (Figure 3-3)

1. Remove the paper guide assembly (page 6-40).
2. Vacuum the card cage fan assembly and surrounding areas to remove paper particles, dust, and lint.
3. Install the paper guide assembly (page 6-40).
4. Close the printer cover.
5. Connect the AC power cord to the printer and the power source.




Figure 3-3. Cleaning the Card Cage Fan Assembly

4

Troubleshooting

Chapter Contents

| | |
|--|------|
| Introduction | 4-2 |
| Troubleshooting Aids | 4-3 |
| Fault Messages | 4-4 |
| Power-On / Reset (POR) Messages | 4-5 |
| Printer State Messages | 4-6 |
| Communications Messages | 4-7 |
| Attention Messages | 4-8 |
| Recoverable Unit Checks | 4-8 |
| Unrecoverable Unit Checks | 4-9 |
| Symptoms Not Indicated by Fault Messages | 4-29 |
| Troubleshooting Table | 4-30 |
| Printer Confidence Check | 4-34 |
| Controller Board Diagnostic Check | 4-35 |
| Operator Print Tests | 4-37 |
| Selecting and Running Operator Print Tests | 4-39 |
| Customer Engineer Tests | 4-40 |
| Selecting and Running CE Tests | 4-42 |
| Hex Code Printout | 4-43 |
| Soft vs. Hard Reset | 4-46 |

Introduction

This chapter contains procedures for troubleshooting printer malfunctions.

This manual does not cover printer operation or configuration, but you must operate the printer to check its performance and sometimes you may have to reconfigure the printer. Therefore, have the *Operator's Guide* and the *Setup Guide* handy when you troubleshoot the printer.

Troubleshooting Aids

Troubleshooting is faster and more effective if you understand the equipment and make use of all available tools. This manual provides a number of troubleshooting aids to help you isolate printer malfunctions:

- ♦ **LCD Message Troubleshooting Table — Page 4-4**

A troubleshooting symptom table for messages that can appear on the Liquid Crystal Display (LCD). LCD messages are defined and solutions provided.

- ♦ **Symptoms Not Indicated by Fault Messages — Page 4-29**

Basic procedures for troubleshooting problems that are not indicated by LCD messages. Also included is a logic table for troubleshooting common problems.

- ♦ **Printer Confidence Check — page 4-34**

A systematic check of printer operation in the form of a logic table. Use this procedure to establish basic printer status or to troubleshoot imprecise or intermittent symptoms.

- ♦ **Controller Board Diagnostic Check — page 4-35**

Checks the operation of the microprocessors and IC chips on the controller board as the board starts and initializes.

- ♦ **Operator Print Tests — Page 4-37**

A set of print tests included in the configuration menu structure for use as diagnostic tools.

- ♦ **Customer Engineer Tests — Page 4-40**

A set of procedures included in the configuration menu structure for use as maintenance tools.

- ♦ **Hex Code Printout — Page 4-43**

A procedure for printing data streams in hexadecimal format. Use to troubleshoot printer data reception problems.

- ♦ **Wire Data — Appendix A**

A system interconnect diagram, circuit board pin-outs, and diagrams of the cable assemblies. Use as source material for tracing electrical problems.

Fault Messages

DANGER

Always disconnect the AC power cord from the power source before performing any maintenance procedure. Failure to remove power could result in injury to persons or damage to equipment. If you must apply power during maintenance, you will be instructed to so in the maintenance procedure.

If a fault condition occurs in the printer, four things happen:

- ♦ The **Attention** indicator on the operator panel flashes on and off.
- ♦ If enabled, the audible alarm sounds. (Press **Stop** to silence the alarm.)
- ♦ A message describing the fault condition appears on the LCD.
- ♦ The condition is automatically recorded in the error log buffer.

The LCD displays two kinds of printer conditions:

- ♦ An *Attention* condition halts printing until the operator replenishes supplies, clears paper jams, corrects a problem of communication between the printer and host computer, etc.
- ♦ A *Unit Check* condition is a failure detected by self-test and fault circuitry. Unit check conditions are either *recoverable* or *unrecoverable*.
 - a. *Recoverable* unit check conditions are errors detected in the electromechanical print mechanism that may be temporary and correctable by recycling power. The printer tries a number of times to correct the condition before posting the message to the LCD, so the first thing to do is cycle power. If the message reappears, classify the check condition *unrecoverable*. (See below.)
 - b. *Unrecoverable* unit check conditions are “hard” failures such as overcurrent, component failure, or microcode failures that prevent printing until the conditions are corrected. Unrecoverable errors require that the printer be powered off and the condition corrected before powering the printer back on.

Clearing Errors

Refer to Table 4-1 and follow the instructions. After correcting an error, press the **Stop** key to clear the message and return the printer to the NOT READY state. Press **Start** to resume printing.

(If an error is not cleared, the printer will try to print again but will display another error message until the error is cleared.)

Table 4-1. LCD Message Troubleshooting Table

| Power-On / Reset (POR) Messages | Explanation | Solution |
|----------------------------------|---|--|
| ERROR: INCORRECT FONTS ON DISK | Diskette is corrupted; fonts cannot load. | Replace diskette with authorized IBM diskette. |
| LANGUAGE FILE NOT AVAILABLE | Translation menu for the desired foreign language is not on the diskette. | Obtain current diskette containing required language files. |
| LOADING FONTS FROM DISK | Startup status message: emulation font software loading. | No action required. If printer "hangs" while this message displays, go to page 4-27. |
| P01 INIT. RTPU-PFC COMMUNICATION | Startup status message: controller is testing RTPU to PFC communications. | Make a Controller Board Diagnostic Check (page 4-35). |
| P02 INIT. RTPU-RSP COMMUNICATION | Startup status message: controller is testing RTPU-to-RSP communications. | Make a Controller Board Diagnostic Check (page 4-35). |
| P03 STATIC RAM TEST | Startup status message: controller SRAM self-test in progress. | Make a Controller Board Diagnostic Check (page 4-35). |
| P04 WAITING FOR DPU | Startup status message: controller self-tests are in progress. | Make a Controller Board Diagnostic Check (page 4-35). |
| P05 DIAGNOSTIC TEST PASSED | Startup status message: initialization complete and controller electronics are operational. | No action required. |
| P06 ERROR: CANNOT READ DISK | Disk drive cannot read the emulation diskette. | Page 4-27. |

| Power-On / Reset (POR) Messages | Explanation | Solution |
|--|---|--|
| P07 LOADING PROGRAM FROM DISK | Startup status message: system and emulation software are loading. | No action required. If printer "hangs" while this message displays, go to page 4-27. |
| P08 ERROR: INCORRECT FILE FORMAT | Printer does not recognize the diskette. | Make sure an authorized IBM diskette is in the disk drive. If the message recurs, go to page 4-27. |
| P09 8344 DIAGNOSTIC FAILED | Link level code test detects hardware failure. | Replace the controller board (page 6-14). |
| P10 ERROR: EMULATION INIT. FAILED | Diskette is corrupted; emulation software cannot load. | Replace diskette with authorized IBM diskette. If the message recurs, go to page 4-27. |
| P14 FAULT CONDITION STATIC RAM* | SRAM failed power-on self-test. | Replace the controller board (page 6-14). |
| P15 FAULT CONDITION DPU TIMEOUT* | DPU cannot handshake with RTPU. | a) Replace RTPU PROM (page 6-46). b) Replace controller board (page 6-14). |
| P16 FAULT CONDITION 64180 OP CODE* | Failure of operational software on the controller board. | Replace the controller board (page 6-14). |
| P17 SECURITY VIOLATION | Part number mismatch of diskette and security module. | Match diskette and security module P/Ns (page 6-47). |
| Printer State Messages | Explanation | Solution |
| 006 HOST SYSTEM REQUEST ATTENTION | Attention signal sent from host computer. | Check host computer system. Printer is OK. |
| 008 HOLD PRINT TIMEOUT PRESS START | Printer was off-line more than 10 minutes and the "Intervention Required" parameter is set to "Send To Host." | Press Start to put printer in READY state. |
| A97 GRAPHIC CHECK ERROR PRESS STOP THEN START | The printer received a character that cannot be printed and the graphic check option is set to enable. | Page 4-25. |

| Communications Messages | Explanation | Solution |
|--|---|---|
| ACTIVATE LOST | Twinax protocol communications errors. | Page 4-26. |
| INVALID ACTIVATE | Twinax protocol communications errors. | Page 4-26. |
| INVALID COMMAND | Twinax protocol communications errors. | Page 4-26. |
| PARAMETER ERROR | Illegal parameter value received in command code. | Press Stop to clear fault. Press Start to go on-line. See also page 4-28. |
| SCS COMMAND ERROR | Printer received undefined control character (hex 40). | Printer clears the error. See also page 4-28. |
| 015 COMMUNICATIONS CHECK CHECK CABLE | Line not active. (Twinax interface) | Page 4-13. |
| 017 COMMUNICATIONS CHECK CHECK CABLE | Line parity check. (Twinax interface) | Page 4-13. |
| 021 SERIAL BUFFER OVERRUN VERIFY CONFIGURATION | Receive overrun. (Serial interface) | Page 4-28. |
| 022 UNIT ADDRESS NOT RECEIVED CHECK PRINTER ADDRESS | Unit address poll timeout. (Twinax interface) | Make sure the printer address is correct. |
| 024 SERIAL LINE PARITY ERROR VERIFY CONFIGURATION | Parity error. (Serial interface) | Page 4-28. |
| 025 SERIAL FRAMING ERROR VERIFY CONFIGURATION | Framing error. (Serial interface) | Page 4-28. |
| 027 COMMUNICATIONS CHECK CALL SYSTEM OPERATOR | Enable poll timeout. The printer was not enabled for one minute. (Coax interface) | Page 4-14. |
| 028 COMMUNICATIONS CHECK CALL SYSTEM OPERATOR | Poll timeout error. The printer was not polled for one minute. (Coax interface) | Page 4-14. |

| Attention Messages | Explanation | Solution |
|--|--|---|
| FM HEADER ERROR | Applications software has violated header parameters. | This is not a printer problem. The system administrator should correct applications data or configuration. |
| STRUCTURED FIELD ERROR | Applications software has violated structured data field parameters. | This is not a printer problem. The system administrator must correct applications data or configuration. |
| 001 END OF FORMS LOAD FORMS | Printer is out of paper. | Load paper. If message recurs, see page 4-10. |
| 002 FORMS JAMMED CLEAR JAM AND RELOAD FORMS | No paper motion. | Clear jam and reload paper. If message recurs, see page 4-11. |
| 031 END OF FORMS TIMEOUT LOAD FORMS | A timeout message is sent to the host if paper is not loaded 10 minutes after Stop was pressed to clear the paper out fault. | Load paper. If the message recurs, see page 4-10. |
| 032 FORMS JAMMED TIMEOUT CLEAR JAM AND RELOAD FORMS | A timeout message is sent to the host if no paper motion has occurred for 10 minutes after Stop was pressed to clear the jam fault. | Clear the jam and reload paper. If the message recurs, see page 4-11. |
| 057 CLOSE PLATEN | Forms thickness lever is raised to open position. | Page 4-21 |
| 090 CLOSE SHUTTLE COVER | Shuttle cover is missing, damaged, or not correctly installed. | Page 4-22 |
| Recoverable Unit Checks | Explanation | Solution |
| 058 SHUTTLE JAM SEE USER'S GUIDE | No shuttle movement or shuttle moving at wrong speed. | Page 4-21 |
| 089 RIBBON JAM | No ribbon movement. | Page 4-23 |
| 091 DISKETTE WRITE ERROR CHECK DISKETTE | Printer cannot write to the diskette. | Make sure an authorized IBM diskette is used, is not write-protected, and is correctly inserted in diskette drive. If problem persists, replace diskette. |

| Unrecoverable Unit Checks | Explanation | Solution |
|-----------------------------------|---|-----------|
| 051 HAMMER DRIVER SHORT | Electrical malfunction of hammer driver system. | Page 4-15 |
| 052 MECHANISM DRIVER HOT | Mechanism driver board is overheating. | Page 4-16 |
| 053 48 VOLTS FAILED | Internal power failure. | Page 4-17 |
| 054 HAMMER COIL SHORT | Electrical malfunction of one or more hammer coils. | Page 4-18 |
| 055 MECHANISM DRIVER LINK FAILURE | Electronic fault between controller board and mechanism driver board. | Page 4-19 |
| 056 HAMMER COIL OPEN | Electrical malfunction of one or more hammer coils. | Page 4-20 |
| 159 HAMMER BANK HOT | One or more hammer coils are overheating. | Page 4-24 |
| 160 SHUTTLE FAN FAILURE | Shuttle is overheating. | Page 4-24 |

001 END OF FORMS (TIMEOUT) LOAD FORMS

| Instruction | Indication | Yes | No |
|--|-----------------------------|---|-------------------------------------|
| 1. Load paper. Run an operator print test. | "001 END OF FORMS" message. | Replace paper detector switch assembly. Go to step 2. | Return printer to normal operation. |
| 2. Run an operator print test. | "001 END OF FORMS" message. | Replace the controller board. Go to step 3. | Return printer to normal operation. |
| 3. Run an operator print test. | "001 END OF FORMS" message. | Replace the intermediate cable assembly (W5). | Return printer to normal operation. |

002 FORMS JAMMED (TIMEOUT) CLEAR JAM AND RELOAD FORMS

| Instruction | Indication | Yes | No |
|--|--|---|--|
| 1. Check for a failure to sense End of Forms. | End of Forms (last form) is past the hammer area. | Do one at a time until the problem is gone: a) Clean the paper detector sensor with a cotton swab and alcohol. b) Replace the paper detector switch assembly. c) Replace the controller board. d) Replace intermediate cable assembly (W5). | Go to step 2. |
| 2. Inspect paper guide assembly for frayed, torn, folded paper or labels. | Paper guide assembly is clear. | Go to step 3. | Remove paper and go to step 3. |
| 3. Inspect the narrow passageway between the face of the platen and the ribbon mask for bits of torn paper or ribbon lint. Check the holes in the ribbon mask surrounding each hammer tip. | Debris found. | Gently remove paper or lint particles with a wooden stick or pair of tweezers. WARNING: Do not pry on or apply force to the hammer tips. Go to step 4. | Go to step 4. |
| 4. Load paper. Press the Form Feed key several times. | Forms feed without erratic motion, noise, or pin-hole damage. | Go to step 5. | If pin holes are damaged, go to step 7. For erratic motion or noise, go to step 9. |
| 5. Press the View key twice. | Forms move correctly in both directions, without jamming, tearing, or folding. | Suspect a false indication. Go to step 13. | Go to step 6. |
| 6. Check the platen motor belt. | Platen motor belt OK. | Replace one at a time until message goes away: a) platen motor b) mechanism driver board | Replace platen motor belt. |
| 7. Check that the ribbon mask has not been deformed in such a way as to block the paper guide assembly. | Ribbon mask damaged or bent. | Replace the hammer bank cover assembly. | Go to step 8. |

| Instruction | Indication | Yes | No |
|--|-----------------------------|--|-------------------------------------|
| 8. Check to platen gap adjustment. | Platen gap incorrect. | Adjust platen gap. Go to step 9. | Go to step 9. |
| 9. Check for damage to the paper feed belt. | Paper feed or belt damaged. | Replace the paper feed belt. Go to step 10. | Go to step 10. |
| 10. Check the tractors and tractor door springs for damage or excessive wear. | Tractors are OK. | Replace mech driver board. Go to step 11. | Replace defective tractor. |
| 11. Run an operator print test. | Paper Jam message. | Replace paper feed motor. Go to step 12. | Return printer to normal operation. |
| 12. Run an operator print test. | Paper Jam message. | Replace cable assembly W6. Go to step 13. | Return printer to normal operation. |
| 13. Load paper. Do some line feeds and run a diagnostic print test. | Paper Jam message. | Clean the paper motion detector with cotton swab and alcohol. Go to step 14. | Return printer to normal operation. |
| 14. Set the paper motion detector fault setting to DISABLE (Ref: <i>Setup Guide</i>). Run a print test and check paper feeding as the printer prints. | Paper Jam message. | Replace the mechanism driver board. Go to step 15. | Return printer to normal operation. |
| 15. Run an operator print test. | Paper Jam message. | Replace paper detector switch assembly. Go to step 16. | Return printer to normal operation. |
| 16. Run an operator print test. | Paper Jam message. | Replace the controller board. Go to step 17. | Return printer to normal operation. |
| 17. Run an operator print test. | Paper Jam message. | Replace the intermediate cable assembly (W5). | Return printer to normal operation. |

015 or 017 COMMUNICATIONS CHECK CHECK CABLE

DANGER

Always disconnect the AC power cord from the power source before performing any maintenance procedure. Failure to remove power could result in injury to persons or damage to equipment. If you must apply power during maintenance, you will be instructed to so in the maintenance procedure.

| Instruction | Indication | Yes | No |
|--|---|--|---|
| 1. a) Power off the printer. b) Disconnect the AC power cord from the printer. (See DANGER notice above.) c) Check the twinax host data cable connection. | Twinax host data cable connection is OK. | Check and reseal the twinax I/O cable connection at J1 on the controller board (page 6-77). Go to step 2. | Check and reseal the twinax host data cable connection. Go to step 2. |
| 2. a) Disconnect twinax auto-termination cable from printer and host. b) Check twinax auto-termination cable for resistances shown on page NO TAG. | Twinax auto-termination cable checks out OK. | Connect twinax auto-termination cable to host and printer. Go to step 3. | Replace twinax auto-termination cable assembly. |
| 3. a) Connect AC power cable to the printer. b) Power on the printer. c) Send a print job to the printer. | Job prints OK and no communications check messages appear. | Return printer to normal operation. | Go to step 4. |
| 4. a) Verify that all other devices on the twinax line are working properly. (Refer to line problem determination procedures, as recommended by host system documentation.) b) Send a print job to the printer. | Twinax line devices work properly, but message still appears. | Replace one at a time until message is gone: a) controller board b) multi I/O assembly c) LP30 backplane board. | Problem is not in the printer. Correct twinax line device malfunction or replace twinax line. |

027 or 028 COMMUNICATIONS CHECK CALL SYSTEM OPERATOR

DANGER

Always disconnect the AC power cord from the power source before performing any maintenance procedure. Failure to remove power could result in injury to persons or damage to equipment. If you must apply power during maintenance, you will be instructed to so in the maintenance procedure.

| Instruction | Indication | Yes | No |
|---|--|---|---|
| 1. a) Power off the printer. b) Disconnect the AC power cord from the printer. (See DANGER notice above.) c) Check the coax host data cable connection. | Coax host data cable connection is OK. | Check and reseal the coax I/O cable connection at J1 on the controller board. Go to step 2. | Check and reseal the twinax host data cable connection. Go to step 2. |
| 2. a) Connect AC power cable to the printer. b) Power on the printer. c) Send a print job to the printer. | Job prints OK and no communications check messages appear. | Return printer to normal operation. | Go to step 4. |
| 3. a) Refer to line problem determination procedures, as recommended by host system documentation. b) Send a print job to the printer. | Coax line OK. | Replace one a time until message is gone: a) controller board b) multi I/O assembly | Problem is not in the printer. Correct coax line device malfunction or replace coax line. |

051 HAMMER DRIVER SHORT

| Instruction | Indication | Yes | No | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|-------------------|--|-------------------|-----------|----|----|------------|------|------|--|------------------|-------------------|-----------|------|------|------------|----|----|--|------------------|-------------------|-----------|------|----|------------|------|----|--|------------------|-------------------|-----------|----|------|------------|----|------|--|
| 1. Cycle power: Power off printer. Wait 15 seconds. Power on printer. | "051 HAMMER DRIVER SHORT" message. | Go to step 2. | Return printer to normal operation. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2. a) Remove the hammer bank cover. b) On the shuttle frame assembly, disconnect the left and right flex circuit ribbon connectors (HBL and HBR) from the connectors on the base casting. (See Appendix A.) c) Install the hammer bank cover. d) Power on the printer and observe the card cage fan. | The card cage fan comes on and stays on. (NOTE: Any of a number of error messages may display during this check. Disregard them during this check.) | Go to step 3. | Replace the mechanism driver board. (NOTE: If the card cage fan never starts at all, replace the power supply board.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3. a) Power off the printer. b) One at a time, test HBL and HBR in both the left and right base casting connector, power up, and monitor the card cage fan. Before each test, replace the hammer bank cover before powering on the printer. Power off the printer after each test. (WARNING: Never connect or disconnect cables with power on.) c) Keep track of the test results, as follows: OK = card cage fan comes on and stays on. Fail = card cage fan starts, then stops. d) Compare your test results with the charts shown at right, and take the action shown in the Yes column. | <table border="1"> <tr> <td></td><td>Left Cable (HBL)</td><td>Right Cable (HBR)</td></tr> <tr> <td>Left Base</td><td>OK</td><td>OK</td></tr> <tr> <td>Right Base</td><td>Fail</td><td>Fail</td></tr> </table> <table border="1"> <tr> <td></td><td>Left Cable (HBL)</td><td>Right Cable (HBR)</td></tr> <tr> <td>Left Base</td><td>Fail</td><td>Fail</td></tr> <tr> <td>Right Base</td><td>OK</td><td>OK</td></tr> </table> <table border="1"> <tr> <td></td><td>Left Cable (HBL)</td><td>Right Cable (HBR)</td></tr> <tr> <td>Left Base</td><td>Fail</td><td>OK</td></tr> <tr> <td>Right Base</td><td>Fail</td><td>OK</td></tr> </table> <table border="1"> <tr> <td></td><td>Left Cable (HBL)</td><td>Right Cable (HBR)</td></tr> <tr> <td>Left Base</td><td>OK</td><td>Fail</td></tr> <tr> <td>Right Base</td><td>OK</td><td>Fail</td></tr> </table> | | Left Cable (HBL) | Right Cable (HBR) | Left Base | OK | OK | Right Base | Fail | Fail | | Left Cable (HBL) | Right Cable (HBR) | Left Base | Fail | Fail | Right Base | OK | OK | | Left Cable (HBL) | Right Cable (HBR) | Left Base | Fail | OK | Right Base | Fail | OK | | Left Cable (HBL) | Right Cable (HBR) | Left Base | OK | Fail | Right Base | OK | Fail | <p>Replace the mechanism driver board.</p> <p>Replace the mechanism driver board.</p> <p>Flex cable HBL is bad. Replace the shuttle frame assembly.</p> <p>Flex cable HBR is bad. Replace the shuttle frame assembly.</p> |
| | Left Cable (HBL) | Right Cable (HBR) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Left Base | OK | OK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Right Base | Fail | Fail | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Left Cable (HBL) | Right Cable (HBR) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Left Base | Fail | Fail | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Right Base | OK | OK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Left Cable (HBL) | Right Cable (HBR) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Left Base | Fail | OK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Right Base | Fail | OK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Left Cable (HBL) | Right Cable (HBR) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Left Base | OK | Fail | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Right Base | OK | Fail | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

052 MECHANISM DRIVER HOT

| Instruction | Indication | Yes | No |
|---|--------------------------------------|---------------------------------|-------------------------------------|
| 1. Cycle power: Power off printer. Wait 15 seconds. Power on printer. | "052 MECHANISM DRIVER HOT " message. | Go to step 2. | Return printer to normal operation. |
| 2. Press the Stop key. | "052 MECHANISM DRIVER HOT" message. | Go to step 3. | Return printer to normal operation. |
| 3. Run an operator print test. | "052 MECHANISM DRIVER HOT" message. | Go to step 4. | Return printer to normal operation. |
| 4. Open printer cover and observe card cage fan. | Card cage fan operates. | Replace mechanism driver board. | Replace card cage fan assembly. |

053 48 VOLTS FAILED

| Instruction | Indication | Yes | No |
|--|--------------------------------|--|---|
| 1. Cycle power: Power off printer. Wait 15 seconds. Power on printer. | "053 48 VOLTS FAILED" message. | Go to step 2. | Return printer to normal operation. |
| 2. Press the Stop switch. | "053 48 VOLTS FAILED" message. | Go to step 3. | Return printer to normal operation. |
| 3. Power off printer. Remove the paper guide assembly. Disconnect cable assembly W1, CCB/Mech Driver, from connector J3 on the controller and connector J6 on the Mech Driver board. (See Appendix A.) Power on the printer. | Card cage fan comes on. | Power off printer. Replace the controller board. Go to step 4. | Power off printer. Replace the Mech Driver board. Go to step 4. |
| 4. Cycle power: Power off printer. Wait 15 seconds. Power on printer. | "053 48 VOLTS FAILED" message. | Replace the power supply board. Go to step 5. | Return printer to normal operation. |
| 5. Cycle power and check for the fault message. | "053 48 VOLTS FAILED" message. | Replace cable assembly W2, +5V. (See Appendix A.) Go to step 6. | Return printer to normal operation. |
| 6. Cycle power and check for the fault message. | "053 48 VOLTS FAILED" message. | Replace cable assembly W3, Hi Voltage. (See Appendix A.) Go to step 7. | Return printer to normal operation. |
| 7. Cycle power and check for the fault message. | "053 48 VOLTS FAILED" message. | Replace cable assembly W6, Main Wire Harness. (See Appendix A.) | Return printer to normal operation. |

054 HAMMER COIL SHORT

| Instruction | Indication | Yes | No |
|--|----------------------------------|--|-------------------------------------|
| 1. Cycle power: Power off printer. Wait 15 seconds. Power on printer. | "054 HAMMER COIL SHORT" message. | Go to step 2. | Return printer to normal operation. |
| 2. Press the Stop key. | "054 HAMMER COIL SHORT" message. | Go to step 3. | Return printer to normal operation. |
| 3. Run an operator print test. | "054 HAMMER COIL SHORT" message. | Go to step 4. | Return printer to normal operation. |
| 4. Remove the shuttle cover. Install a magnet across the hole in the base casting where the cover open sensor is mounted. Disconnect the hammer bank flex circuit cables from the connectors on the base casting. Run a diagnostic print test. | "054 HAMMER COIL SHORT" message. | Replace the mechanism driver board, then go to step 5. | Replace the shuttle frame assembly. |
| 5. Run an operator print test. | "054 HAMMER COIL SHORT" message. | Replace both hammer bank cable assemblies. | Return printer to normal operation. |

055 MECHANISM DRIVER LINK FAILURE

| Instruction | Indication | Yes | No |
|---|--|--|--|
| 1. Cycle power: Power off printer. Wait 15 seconds. Power on printer. | "055 MECHANISM DRIVER LINK FAILURE" message. | Go to step 2. | Return printer to normal operation. |
| 2. Press the Stop key. | "055 MECHANISM DRIVER LINK FAILURE" message. | Go to step 3. | Return printer to normal operation. |
| 3. Power on printer and check for fault message. | "055 MECHANISM DRIVER LINK FAILURE" message. | Go to step 4. | Return printer to normal operation. |
| 4. Power off printer. Remove paper guide assembly. Check ribbon cable connectors between controller board and mechanism driver board. | Connectors are attached properly. | Go to step 5. | Connect and latch ribbon connectors. Go to step 5. |
| 5. Check installation of controller board and mechanism driver board. | Boards are installed correctly. | Go to step 6. | Reseat controller and mechanism driver boards in their edge connectors at bottom of card cage. Go to step 6. |
| 6. Power on printer and check for fault message. | "055 MECHANISM DRIVER LINK FAILURE" message. | Replace the controller board then go to step 7. | Return printer to normal operation. |
| 7. Power on printer and check for fault message. | "055 MECHANISM DRIVER LINK FAILURE" message. | Replace the mechanism driver board, then go to step 8. | Return printer to normal operation. |
| 8. Power on printer and check for fault message. | "055 MECHANISM DRIVER LINK FAILURE" message. | Replace cable assembly W1, OCB/Mech. Dr. (See Appendix A.) | Return printer to normal operation. |

056 HAMMER COIL OPEN

| Instruction | Indication | Yes | No |
|--|---|--|--|
| 1. Cycle power: Power off printer. Wait 15 seconds. Power on printer. | "056 HAMMER COIL OPEN" message. | Go to step 2. | Return printer to normal operation. |
| 2. Press the Stop key. | "056 HAMMER COIL OPEN" message. | Go to step 3. | Return printer to normal operation. |
| 3. Run an operator print test. | "056 HAMMER COIL OPEN" message. | Go to step 4. | Return printer to normal operation. |
| 4. Remove the shuttle cover. | — | Go to step 5. | — |
| 5. Install a magnet across the hole in the base casting where the cover open sensor is mounted. | — | Go to step 6. | — |
| 6. Run an operator print test and observe where the non-printing hammer is located. | — | Go to step 7. | — |
| 7. Reverse the hammer bank flex circuit cables in the connectors on the base casting. | — | Go to step 8. | — |
| 8. Run an operator print test. Observe where the non-printing hammer is located. (NOTE: Hammer number 48 is a permanently non-printing hammer. Keep this in mind when reversing cables.) | Position of the non-printing hammer remains the same. | Replace the shuttle frame assembly, then go to step 9. | If the non-printing hammer is now on the other side of the hammer bank, replace the mechanism driver board, then go to step 9. |
| 9. Return the hammer bank flex circuit cables to their correct connectors on the base casting. Run an operator print test. | "056 HAMMER COIL OPEN" message. | Replace both hammer bank cable assemblies. | Return printer to normal operation. |

057 CLOSE PLATEN

| Instruction | Indication | Yes | No |
|--|-----------------------------|---|--|
| 1. Load paper. Close the forms thickness lever. Run an operator print test. | "057 CLOSE PLATEN" message. | Go to step 2. | Return printer to normal operation. |
| 2. Power off the printer. Disconnect the platen interlock switch connector. Check the switch with a meter. | Switch is bad. | Replace platen interlock switch assembly. | Replace one at a time until the message is gone: a) controller board b) intermediate cable assembly (W5) |

058 SHUTTLE JAM

| Instruction | Indication | Yes | No |
|--|--------------------------------------|---|--|
| 1. Check the forms thickness lever; if it is set too tightly, it can slow the shuttle enough to trigger the fault message. | Forms thickness lever set correctly. | Go to step 2. | Set forms thickness lever for thicker paper. Go to step 2. |
| 2. Run an operator print test and check for shuttle obstruction. | "058 SHUTTLE JAM" message. | Go to step 3. | Return printer to normal operation. |
| 3. Remove shuttle cover and inspect shuttle area and mechanism for obstruction. | Shuttle movement blocked. | Remove obstruction. Go to step 4. | Install shuttle cover. Go to step 4. |
| 4. Run an operator print test and observe the shuttle. | Shuttle moves. | Go to step 5. | Go to step 7. |
| 5. Check MPU adjustment. | MPU adjustment OK. | Go to step 6. | Return printer to normal operation. |
| 6. Run an operator print test. | "058 SHUTTLE JAM" message. | Replace the MPU. Go to step 5. | Return printer to normal operation. |
| 7. Run an operator print test. | "058 SHUTTLE JAM" message. | Replace mechanism driver board. Go to step 8. | Return printer to normal operation. |
| 8. Run an operator print test. | "058 SHUTTLE JAM" message. | Replace shuttle frame assembly. | Replace main wire harness W6. |

090 CLOSE SHUTTLE COVER

| Instruction | Indication | Yes | No |
|--|------------------------------------|---|---|
| 1. Inspect shuttle cover for warping, damage, or missing magnet. (The magnet covers the sensor housing when the cover is installed.) | Shuttle cover damaged. | Replace the shuttle cover assembly. | Go to step 2. |
| 2. Check shuttle cover installation. | Shuttle cover installed correctly. | Go to step 3. | Install cover correctly. Make sure the cover lies flat and the two captive screws are fully seated. Go to step 3. |
| 3. Run an operator print test. | "090 CLOSE SHUTTLE COVER" message. | Replace the cover open switch assembly. | Replace one at a time until message is gone: a) controller board b) intermediate cable assembly W5 |

089 RIBBON JAM

| Instruction | Indication | Yes | No |
|--|---|--|---|
| 1. Using a screwdriver, short across the ribbon guide screws to reverse ribbon hub motion. Check for ribbon failing to reverse motion. | Ribbon fails to reverse. | Go to step 2. | Go to step 3. |
| 2. Check for missing foil strip at end of ribbon. | Foil strip missing. | Replace the ribbon. | Go to step 8. |
| 3. Check that forms thickness lever is not closed too tightly; this can jam the ribbon and shuttle. | Forms thickness lever is set correctly. | Go to step 4. | Readjust the setting of the forms thickness lever. Go to step 4. |
| 4. Run a ribbon and shuttle CE Test and check for shuttle obstruction. | Ribbon fault message. | Go to step 5. | Return printer to normal operation. |
| 5. Check ribbon path for blockage or obstruction. | Ribbon path is clear | Go to step 6. | Remove obstructions from ribbon path and go to step 6. |
| 6. Wind ribbon by hand and inspect for folds, tears, holes, fraying. | Ribbon is OK. | Rewind and reinstall ribbon. Go to step 7. | Replace ribbon, if damaged. Unfold and rewind ribbon if it was folded. Go to step 7. |
| 7. Run the "Shuttle Fast" CE Test and check the alignment of the ribbon guides and hubs if the ribbon was folded. | Ribbon tracks OK. | Go to step 8. | Align ribbon guides. Go to step 8. |
| 8. Using a screwdriver, short across the ribbon guide screws to reverse ribbon hub motion. Check for a ribbon drive motor that will not wind ribbon. | Both motors wind the ribbon. | Replace the mechanism driver board. | Replace one at a time until message is gone: a) defective ribbon drive motor b) mechanism driver board c) main wire harness W6 |

159 HAMMER BANK HOT

NOTE: The printer has protective circuits designed to sense conditions that can lead to overheating. When such conditions are sensed, print speed is reduced 50%. If the printer consistently prints at half speed, it may be printing long jobs of very dense graphics or operating in a severe environment. A severe environment is consistently above 90° Fahrenheit (32° Celsius) or is dirty enough to create blockage of the blower ducts. If the printer is located in such an environment, consider relocating it to a cooler, cleaner area or reducing the size and duration of the print jobs.

| Instruction | Indication | Yes | No |
|--|--------------------------------|---------------------------------|-------------------------------------|
| 1. Cycle power: Power off printer. Wait 15 seconds. Power on printer. | "159 HAMMER BANK HOT" message. | Go to step 2. | Return printer to normal operation. |
| 2. Press the Stop key. | "159 HAMMER BANK HOT" message. | Go to step 3. | Return printer to normal operation. |
| 3. Run "Plot Test" CE Test for 1/4 page. | "159 HAMMER BANK HOT" message. | Go to step 4. | Return printer to normal operation. |
| 4. Remove the shuttle cover. Install a magnet across the hole in the base casting where the cover open sensor is mounted. Run a diagnostic print test. | Hammer bank fan operates. | Replace shuttle frame assembly. | Replace hammer bank fan assembly. |

160 SHUTTLE FAN FAILURE

| Instruction | Indication | Yes | No |
|--|------------------------------------|--|-------------------------------------|
| 1. Remove the shuttle cover. Install a magnet across the hole in the base casting where the cover open sensor is mounted. Check for inoperative hammer bank or card cage fan, or obstructed airflow. | "160 SHUTTLE FAN FAILURE" message. | Replace one at a time until message is gone: a) inoperative fan(s) b) mech driver board c) controller board | Return printer to normal operation. |

A97 GRAPHICS CHECK

| Instruction | Indication | Yes | No |
|---|---|---|---|
| 1. Make a hex code printout (page 4-43), using the same print job that generated the error message. | "A97 GRAPHICS CHECK" message. | Go to step 2. | Return printer to normal operation. |
| 2. Have the system operator verify: a) Host data are correct. b) There are no invalid characters. c) The printer's World Trade Language is correct. | Host data contain no invalid characters and World Trade Language correct. | Go to step 3. | Have the system operator make the necessary corrections to data or configuration. |
| 3. a) Access the Coax or Twinax Interface configuration menu (Ref.: <i>Setup Guide</i>) b) Print the Character Table for the interface being used and check the characters. | "A97 GRAPHICS CHECK" message. | Replace one at a time until message is gone: a) controller board b) coax or twinax cable. | Return printer to normal operation. |

ACTIVATE LOST INVALID ACTIVATE INVALID COMMAND

DANGER

To prevent serious personal injury from electrical shock when connecting or disconnecting the signal cable, power the printer off and unplug the power cable.

| Instruction | Indication | Yes | No |
|--|---|---|-------------------------------------|
| 1. Print the Error Log (page 4-37). (A few parity errors in the log are acceptable.) | Host communication error message display logged. | Go to step 2. | Return printer to normal operation. |
| 2. a) Power off the printer. b) Disconnect the power cord. c) Check coax/twinax cable terminations at the I/O plate. | Coax and twinax cables are properly attached. | Go to step 3. | Attach cables correctly. |
| 3. Check coax and twinax I/O cable grounding and connections at controller board. | Cables are grounded and attached to controller board correctly. | Go to step 4. | Attach cables correctly. |
| 4. Check that external coax/twinax cable is undamaged and is not longer than 4921.5 feet (1500 meters). | Cable is OK. | Go to step 5. | Replace cable. |
| 5. a) Connect power cord to printer. b) Power on the printer. c) Send data from host. | Error message displays. | Power off printer. Replace one at a time until message is gone: a) coax or twinax cable b) controller board | Return printer to normal operation. |

Diskette and Disk Drive Messages

| Instruction | Indication | Yes | No |
|---|--|--|---|
| 1. a) Power off printer. b) Verify that the system diskette is not read/write protected. c) Insert the diskette in the diskette drive. Power on printer. | Diskette or disk driver error message. | Go to step 2. | Return printer to normal operation. |
| 2. a) Power off printer. b) Insert the diskette in the diskette drive. c) Power on printer and observe the diskette drive LED. | Diskette drive LED comes on. | Go to step 3. | Go to step 5. |
| 3. The diskette may have been altered or corrupted: Replace the diskette with an authorized IBM diskette. | Diskette or disk driver error message. | Go to step 4. | Return printer to normal operation. |
| 4. Clean the diskette drive heads. Use a commercially-available floppy drive head cleaning kit. Follow the instructions included with the kit. | Diskette or disk driver error message. | Go to step 5. | Return printer to normal operation. |
| 5. a) Power off printer. b) Check connections of the floppy interface cable assembly and floppy power cable assembly at the disk drive unit and at the LP30 backplane board. (See Appendix A.) | Connections are correct, clean, and tight. | Replace* one at a time until the message is gone: a) diskette drive assembly b) controller board c) floppy interface cable assembly d) floppy power cable assembly e) LP30 backplane board * After a replacement, verify disk drive read/write functionality by changing and saving a configuration parameter. (Refer to the <i>Setup Guide</i> .) | Reseat the cable(s). Verify disk drive read/write functionality by changing and saving a configuration parameter. (Refer to the <i>Setup Guide</i> .) |

PARAMETER ERROR SCS COMMAND ERROR

| Instruction | Indication | Yes | No |
|--|---|--|-------------------------------------|
| 1. Run the same job that generated the error message. | SCS COMMAND or PARAMETER ERROR message. | Verify host data are correct and there are no invalid characters. | Return printer to normal operation. |
| 2. Ask the system operator to verify printer's Device ID is set to the correct emulation with respect to the host configuration. | SCS COMMAND or PARAMETER ERROR message. | Replace one at a time until message is gone: a) coax or twinax cable b) controller board | Return printer to normal operation. |

Serial Interface Messages

| Instruction | Indication | Yes | No |
|---|--|-------------------------------------|---|
| 1. a) Make a configuration printout. (Ref.: <i>Setup Guide</i>) b) Verify that host and printer serial interface configuration settings match for: — Baud Rate — Data Bits — Stop Bits — Parity | Host and printer serial interface parameters match. | Go to step 2. | Set printer serial interface parameters to match those of the host. (Ref.: <i>Setup Guide</i>) |
| 2. Send a print job to the printer. | Job prints OK and no serial interface fault messages appear. | Return printer to normal operation. | Replace one at a time until message is gone: a) controller board b) Multi I/O Assembly |

Symptoms Not Indicated by Fault Messages

Use standard fault-isolation techniques to troubleshoot malfunctions not indicated by fault messages:

1. Ask the operator to describe the problem.
2. Verify the fault by running diagnostic tests or replicating conditions reported by the user.
3. Look for a match in the "Symptoms Not Indicated by Fault Messages Troubleshooting Table" (page 4-30), and follow the instructions given.
4. Locate the malfunction using the half-split method:
 - a. Start at a general level and work down to details.
 - b. Isolate faults to half the remaining system at a time, until the final half is a field-replaceable part or assembly. (Troubleshooting aids are listed on page 4-3.)
5. Replace the defective part or assembly.

IMPORTANT

DO NOT attempt field repairs of electronic components or assemblies. Replace a malfunctioning electronic assembly with an operational spare. Most electronic problems are corrected by replacing the printed circuit board assembly (PCBA), sensor, or cable that causes the fault indication. The same is true of failures traced to the hammer bank: replace the entire shuttle frame assembly. It is not field repairable.

6. Test printer operation after every corrective action.
7. Stop troubleshooting and return the printer to normal operation when the reported symptoms disappear.

Symptoms Not Indicated by Fault Messages Troubleshooting Table

| Symptom | Instruction |
|---|---|
| No power, operator panel LCD and LEDs blank, card cage fan not running. | 1. +5 volt distribution problem to the LP30 backplane board. (Refer to the Power Distribution Diagram on page NO TAG.) |
| Power on hang condition. | 1. Perform a diagnostic check of the controller board (page 4-35). |
| Blank or single line of black squares across top row of operator panel LCD. | <ol style="list-style-type: none"> 1. Perform a diagnostic check of the controller board (page 4-35). 2. Power off printer. Check that the operator panel cable is fully seated in connector J3 on the LP30 backplane board. Do step 1 again. If the display is still blank, or has a black line, and the DPU LEDs light and turn off, the operator panel or its cable are defective. |
| Operator Panel key failure. | 1. Replace one at a time until the problem is fixed: <ol style="list-style-type: none"> a) operator panel assembly b) controller board c) LP30 backplane board c) operator panel cable assembly |
| Ribbon folding or feed problems. | <ol style="list-style-type: none"> 1. Clean the shuttle frame assembly (page 3-3). 2. Check the left and right ribbon guide alignment (page 5-18). |
| Printer appears normal, but does not print data sent from the host. | <ol style="list-style-type: none"> 1. Perform a printer confidence check (page 4-34). 2. Power off printer and disconnect the AC power cable. 3. Check the host data cable connection at the rear of the printer. 4. If the printer interface is RS-232, interchange the wires to pins 2 and 3. This is the most common cause of a completely inoperative RS-232 cable. Make sure the printer and host have the same baud rate, number of data bits, number of stop bits, and parity. In RS-232, configure the host for XON/XOFF if possible; this requires the least complex cable. 5. Replace one at a time until the problem is fixed: <ol style="list-style-type: none"> a) controller board b) multi I/O assembly c) LP30 backplane board |

| Symptom | Instruction |
|--|---|
| Printer prints data sent from the host, but occasionally prints double characters or loses blocks of data. | <ol style="list-style-type: none"> 1. Perform a diagnostic check of the controller board (page 4-35). 2. If the printer prints from the host, but occasionally loses blocks of data, the most likely cause is the host not responding to "send no more data" signals from the printer. With a PC Parallel interface, this means the host is ignoring BUSY; in RS-232, the host is ignoring the XOFF character or "Data Terminal Ready" signal (pin 20). Sometimes the cable is not conveying the necessary signals. Test this by using a serial line analyzer and software or test equipment that displays the data and handshake lines of the printer. A breakout box works, but will not debug XON/XOFF or other RS-232 data protocols. If the printer is sending XOFF with one stop bit, the host may not be receiving it if the host requires 1.5 or 2 stop bits. 3. <ol style="list-style-type: none"> a) If the printer prints from the host, but occasionally prints double characters, there is probably a noise problem at the interface or the host computer is sending an inverted strobe. This problem can occur on PC Parallel or Dataproducts interfaces, never on RS-232. What happens is that the strobe signal registers logic 1 more than once for a certain character. To fix this, change the strobe to trailing edge or invert the strobe polarity. (Refer to the <i>Setup Guide</i>.) b) Also check that the terminating resistors are present on the controller board (page 6-47). You can correct some noise problems by using a shielded data cable or by changing the terminating resistors. The standard terminating resistors are optimized for high speed data transfer for cables between 1 and 5 meters long; you can change them for slower operation, which will provide slightly more noise immunity. c) Noise is caused by static, a floating logic ground, unshielded cable, changes in ground voltage from nearby equipment, or capacitively- or magnetically-induced noise. On very long cables, capacitively-induced noise from the other signals of the cable (especially PC Parallel "ACK" or Dataproducts "DEMAND") can cause false strobes. Unshielded and flat ribbon cables are much more prone to problems due to increased length. The best solution is to shorten cable, shield it, and reduce local electromagnetic noise. Also, make sure that both the printer and the host computer are properly grounded. |

| Print Quality Problems | |
|---|---|
| Missing, light, or smeared characters or dots: | <ol style="list-style-type: none"> 1. Check the forms thickness lever setting. 2. Check the ribbon for folds or tears. 3. Clean the shuttle frame assembly (page 3-3). 4. Check the platen gap adjustment (page 5-14). 5. Reverse the hammer bank flex circuit cables in the connectors on the base casting. NOTE: Hammer number 48 is a permanently non-printing hammer. Keep this in mind when reversing cables. 6. Run an operator print test. If the failing position(s) move, replace the mechanism driver board (page 6-18). 7. Return the hammer bank flex cables to the original positions. 8. Swap hammer spring assemblies for the failing position(s) with one from working position(s). 9. Run an operator print test. If the failing position(s) move, replace the hammer spring assembly. 10. Replace the shuttle frame assembly (page 6-55). |
| All characters or dots are too light or too dark. | <ol style="list-style-type: none"> 1. Check the forms thickness lever setting. 2. Clean the shuttle frame assembly (page 3-3). 3. Check the platen gap adjustment (page 5-14). 4. Install a new ribbon. 5. Replace one at a time until problem is fixed: <ol style="list-style-type: none"> a) mechanism driver board (page 6-18) b) shuttle frame assembly (page 6-55) |
| Horizontal misalignment. (Dots or characters move left or right from dot row to dot row or line to line.) | <ol style="list-style-type: none"> 1. If all dots between alternate rows are misaligned, check hammer phasing (page 5-27). 2. Clean the shuttle frame assembly (page 3-3). 3. Check the MPU gap adjustment (Ref: page 6-32). 4. Replace one at a time until problem is fixed: <ol style="list-style-type: none"> a) MPU (page 6-32) b) mechanism driver board (page 6-18) c) shuttle frame assembly (page 6-55) |
| Vertical misalignment: 1. Dots or characters move up or down from dot row to dot row or line to line. 2. Incorrect spacing from dot row to dot row or line to line. | <ol style="list-style-type: none"> 1. Check paper feed motor belt (page 5-4). 2. Check platen gap adjustment (page 5-14). 3. Replace one at a time until problem is fixed: <ol style="list-style-type: none"> a) tractors (page 6-62) b) mechanism driver board (page 6-18) c) paper feed motor (page 6-34) d) controller board (page 6-14) e) power supply board (page 6-20) |

| Print Quality Problems | |
|--|---|
| Randomly misplaced dots. | <ol style="list-style-type: none"> 1. Check platen gap adjustment (page 5-14). 2. Check printer grounding (page NO TAG). 3. Replace one at a time until problem is fixed: <ol style="list-style-type: none"> a) controller board (page 6-14) b) power supply board (page 6-20) c) shuttle frame assembly (page 6-55) |
| Garbled print or paper slews uncontrollably. | <ol style="list-style-type: none"> 1. Perform a diagnostic check of the controller board (page 4-35). 2. <ol style="list-style-type: none"> a) Put the printer into hex dump mode and analyze the binary data. One cause of garble is the host interface or cable not transmitting all 8 data bits. When this occurs, the PC Parallel or Dataproducts interface receives a 1 on every unconnected data line. Uncontrolled slewing is often caused by enabling PI (Paper Instruction) in the printer when the host lacks a PI signal. (PI shows as "p" on the hex dump.) Some RS-232 and Dataproducts interfaces only send 7 data bits. In this case, the eighth bit will be received as a one. b) In RS-232, a common cause of garble is the interface set to the wrong baud rate or parity. Sometimes the host sends 1.5 or 2 stop bits; in this case, the printer's "1-stop-bit" setting will accept both 1.5 and 2 stop bit data. Sometimes the data may "fade" or "persist" from one character to the next. This reveals a problem with PC Parallel or Dataproducts terminating resistors on the controller board—especially if they are absent. Garble also can result from failed termination resistors or parallel logic, but this is rare. |

Printer Confidence Check

| Instruction | Indication | Yes | No |
|---|--|---|---|
| 1. Check that printer is plugged into correct power source. | Power cable installed correctly to proper source. | Power off printer. Go to step 2. | Set power switch to O (off). Connect printer to correct power source. |
| 2. Power on the printer. | Printer goes READY. | Go to step 3. | Troubleshoot the fault message (page 4-4). |
| 3. Run an operator print test (page 4-37). | Printer operates correctly | Go to step 4. | Troubleshoot the fault message (page 4-4). |
| 4. Make a configuration printout. (Ref.: <i>Setup Guide</i>) | a) Configuration is correct for the user's application. b) Host computer and printer are using the same protocol (emulation). c) Configuration has not been inadvertently changed by user. | Go to step 5. | Reconfigure the printer. (Ref.: <i>Setup Guide</i>) |
| 5. a) Power off printer. b) Check alignments and adjustments. (Chapter 5.) | Assemblies and components are adjusted in accordance with Chapter 5. | Go to step 6. | Adjust all assemblies that are out of spec. |
| 6. a) Power off printer. b) Remove paper guide assembly (page 6-40). c) Check all electrical connectors. | Connections are clean and tight. Wires are not stripped, frayed, or out of connectors. | Go to step 7. | Replace stripped, frayed, or broken wires. |
| 7. Check that all printed circuit boards are seated correctly and cable connections are correct. (Ref.: Appendix A) | Printed circuit boards are firmly seated and all cables are correctly attached. | Go to step 8. | Unseat and reseat each board, one board at a time. Check and correct the cable attachments. |
| 8. Inspect for debris that could cause short circuits (loose fasteners, foil, etc.). | Metallic debris. | Remove debris. Clean the printer. (Chapter 3.) | Go to step 9. |
| 9. a) Install paper guide assembly (page 6-40). b) Power on printer. | Printer powers up and initializes properly. | Printer checks out OK. Fault may not be in printer. Check host computer, applications software, cabling, etc. | Troubleshoot the fault message (page 4-4). |

Controller Board Diagnostic Check

You can check the operation of the controller board by monitoring its six diagnostic LEDs as the printer powers up. (These LEDs are *only* valid during system startup.) The LEDs are mounted along the top right edge of the board. (See Table 4-2.)


The DPU, RTPU, and the BCP each control two LEDs. The lighting patterns of the LEDs as the printer powers up indicate the status of the board.

Follow the steps below to make a diagnostic check of the controller board.

1. Power off the printer.
2. Remove the paper guide assembly (page 6-40).
3. Make sure all cable connections to the controller board are correct. (See Appendix A.)
4. Power on the printer and watch the diagnostic LEDs as the printer initializes:
 - a. Note the final on/off pattern of LEDs.
 - b. Using Table 4-2, find the LED pattern you observed and follow the instructions for solving the problem.
5. Install the paper guide assembly (page 6-40).
6. Return the printer to normal operation.

Table 4-2. Controller Board Diagnostic LED During Power-Up

| LED Pattern | | | Explanation | Solution |
|-------------|--------|-------|--|--|
| (DPU) | (RTPU) | (BCP) | | |
| | | | DPU failed to execute startup code. | Replace: 1) boot ROM (page 6-46) 2) Controller board (page 6-14) |
| | | | RTPU could not handshake with DPU. Handshake is done in DPMC shared memory. | Replace: 1) RTPU PROM (page 6-46) 2) Controller board (page 6-14) |
| | | | DPU failed memory test or floppy memory failure. | Replace controller board (page 6-14) |
| | | | PFC failed. | Replace: 1) PFC PROM (page 6-46) 2) Controller board (page 6-14) |
| | | | RTPU cannot communicate with RSP on the mechanism driver board. | Replace: 1) RSP PROM (page 6-48) 2) Mech Driver Board 3) Controller board |
| | | | Diskette failed to load data and programs properly. | 1) Verify that diskette installs properly in drive. 2) Replace diskette |
| | | | BCP failed. | Replace controller board (page 6-14) |
| | | | Problem exists in diagnostic code, or the BCP did not finish internal diagnostics or request normal operating code from DPU. | Replace controller board (page 6-14) |
| | | | Controller components initialized correctly. | None required. Board is operational. |



Operator Print Tests

A set of print tests is included in the configuration menu structure for use as diagnostic tools. These are called the “Operator Print Tests” because they are available to the user. You can use these print tests to check the print quality and basic operation of the printer.

The Operator Print Tests are summarized below.

NOTE: Under the description of some of the tests is a list of items that may need to be adjusted or replaced if the test produces a bad print pattern. Items are listed in the order you should check them: simplest items first, complex items last.

- ♦ **Printer Demonstration** Prints a sample of the printer’s capabilities.
- ♦ **Print Error Log** Prints the contents of the error log. The error log automatically records error conditions as they occur in the printer, and save them in NVRAM. Errors are printed from the oldest to most recent, in the order in which they occurred.
- ♦ **Ripple Print** A “sliding” alphanumeric pattern useful for identifying missing or malformed characters, improper vertical alignment, or vertical compression.
 - Hammer bank cover
 - Hammer spring
 - Shuttle frame assembly
- ♦ **All E's** A pattern of all uppercase letter E’s useful for identifying missing characters, misplaced dots, smeared characters, improper phasing, or light/dark character variations.
 - Ribbon
 - Splined shaft skew adjustment
 - Hammer bank cover
 - MPU sensor
 - Hammer spring
 - Hammer coil (shuttle frame assembly)
- ♦ **All H's** A pattern of all uppercase letter H’s useful for detecting missing characters or dots, smeared characters, or improper phasing.

Ribbon
Hammer bank cover
MPU sensor
Hammer spring
Hammer coil (shuttle frame assembly)


















- ♦ **E's + FF** A pattern of all E's repeated for ten lines and followed by a form feed to the top of the next page. This test is useful for identifying paper motion or paper feed problems.

Hammer bank cover
Power supply board
Mechanism Driver board
Paper motion sensor or cable
Paper feed belt or motor
Splined shaft bearings
Tractors or tractor belts

- ♦ **Underlines** An underline pattern useful for identifying hammer bank misalignment.

Mechanism Driver board
Hammer bank cover
Hammer tips
Paper feed belt or motor
Splined shaft bearings
Tractor bearings or belts

Selecting and Running Operator Print Tests

| Step | Key | Displayed Result | Notes |
|------|--|--|---|
| 1. | Make sure that the printer ribbon is installed in the printer and the printer is powered on and is loaded with paper. | | |
| 2. | Press:  |  | Places the printer in Not Ready mode. |
| 3. | Press:  +  |  | Press both keys at the same time. Unlocking the Enter key allows you to test your printer. |
| 4. | Press:  |  | First of the series of configuration menus. |
| 5. | Press:  UNTIL |  | Advances to the Operator Printer Tests menu. |
| 6. | Press:  |  | Advances to Printer Demonstration, the first option in Operator Printer Tests menu. |
| 7. | Press:  UNTIL |  | Cycles through the list of Printer Tests. Stop when the name of the test you wish to run displays (will print at either 80 or 132 columns, as specified). |
| 8. | Press:  |  | The printer test you have selected starts printing. |
| 9. | Press:  |  | The printer test stops printing. |

Customer Engineer Tests

A set of printer tests is included in the configuration menu structure for use as maintenance tools. These tests are called the “Customer Engineer Tests” (CE Tests) because they are for your use—they are not available to the user through his documentation. You will use these tests in various troubleshooting and adjustment procedures.




Figure 4-1. CE Tests Menu

Figure 4-1 illustrates the CE Tests, which are summarized below.

Printer Mechanism Tests:

- ♦ **Burn In Test** Use of this test is *not recommended*. This test is used by the manufacturer to burn in the printer prior to shipment, and has no value as a maintenance tool.
- ♦ **Plot Test** Prints all dot positions, creating a solid black band. Exercises shuttle and hammer bank at maximum capacity.
 - Mechanism Driver board
 - Power Supply board
 - Hammer bank cover
 - Hammer springs
 - Hammer coils (the shuttle frame assembly)
- ♦ **Shuttle Only** This test runs only the shuttle.
- ♦ **Shuttle Slow** Verifies proper operation by exercising the shuttle and ribbon mechanisms at low speed. You can also use this test to check ribbon tracking and reversing.

- ♦ **Shuttle Fast** Verifies proper operation by exercising the shuttle and ribbon mechanisms at high speed. You can also use this test to check ribbon tracking and reversing.
- ♦ **Hammer Phasing** A hammer timing parameter that permits you to adjust the vertical alignment of dots in character printing.
- ♦ **End of Forms Adjust** A vertical comb pattern used to determine the number of dot rows from the completion of a paper out fault to the end of the paper.

Hammer Phase Value:

The hammer phase value is a timing parameter that permits you to adjust the vertical alignment of dots in character printing. The numerical units are relative; they do not represent a physical measurement or value. There is no "correct" value or range.

End of Forms Adjustment Value:

This parameter determines where on the paper the printer will stop printing when an out of paper fault is detected. The unit of measurement is dot rows. The number of dot rows may be adjusted up or down 1/2 inch from the factory default of 40 dots.

Clear Error Log:

This menu selection enables you to delete the stored contents of the error log. (The error log automatically records attention and unit check conditions as they occur in the printer.)

Selecting and Running CE Tests

1. If the **Ready** indicator is on, press the **Stop** key. The printer must be in NOT READY state to access the CE Tests.
2. Press **Scroll↑ + Scroll↓** to unlock the **Enter** key.
3. Press **Scroll↑ + Scroll↓ + Return + Enter**. (Press all four keys at the same time.)
4. The first menu item is "PRINTER MECHANISM TESTS." To view the different mechanism tests, press **Enter**.
5. Scroll to the desired test by using the **Scroll↑** or **Scroll↓** key.
6. Press **Enter**. The selected test begins. You can select other tests by going back to step 5. To end the test, press the **Enter** key.

NOTE: See Chapter 5 for special instructions in the use of the Hammer Phasing and End of Forms Adjust tests.

7. Press **Stop** to halt any test, exit the menu, perform a warm start, and put the printer in the NOT READY state.
8. Press **Start** to halt any test, exit the menu, perform a warm start, and put the printer in the READY state.














Hex Code Printout












A hex code printout ("hex dump") lists each ASCII data character received from the host computer, along with its corresponding two-digit hexadecimal code. Hex dumps can be used to troubleshoot some types of printer data reception problems.

To convert an ASCII character to its corresponding hex code (or vice-versa), refer to the ASCII code chart on page 4-45.


Every printable character is printed both as its assigned symbol and as its hex equivalent. Each nonprintable (ASCII control) character prints both as a period (.) and as its hex equivalent.

When using a parallel interface, the letter "p" before a hex code indicates an active Paper Instruction (PI) line and a blank space before a hex code indicates an inactive PI line.

| Step | Key | Displayed Result | Notes |
|-----------|---|--|--|
| 1. Press: |  |  | Places the printer in Not Ready mode. |
| 2. Press: |  +  |  | Press both keys at the same time. Unlocking the Enter key allows you to test the printer. |
| 3. Press: |  |  | First of the series of configuration menus. |
| 4. Press: |  |  | Moves down to the Interface Selection option. |
| 5. Press: |  UNTIL |  | Moves down to the Hex Print Mode option. |
| 6. Press: |  |  | Moves down to Disable, the active option. |

| Step | Key | Displayed Result | Notes |
|------------|---|--|--|
| 7. Press: |  |  | Moves down to Enable, the alternate option. |
| 8. Press: |  |  | Asterisk (*) indicates this choice is now active. |
| 9. Press: |  |  | Returns the printer to Not Ready mode. |
| 10. Press: |  +  |  | Press both keys at the same time to relock the Enter key. |
| 11. Press: |  |  | Puts the printer back to Ready mode. |

ASCII Character Set



| BITS B7 B6 B5 B4 B3 B2 B1 | ROW | COLUMN | | | 0 | | 1 | | 2 | | 3 | | 4 | | 5 | | 6 | | 7 | |
|------------------------------|-----|--------|----|----|------------|----|----|----|----|----|---|----|---|----|---|----|---|-----|-----|-----|
| | | 0 | 1 | 2 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 |
| 0 0 0 0 | 0 | NUL | 0 | 0 | DLE | 16 | 20 | SP | 32 | 40 | 0 | 48 | @ | 64 | P | 80 | \ | 96 | p | 112 |
| 0 0 0 1 | 1 | SOH | 1 | 1 | DC1 (XON) | 17 | 21 | ! | 33 | 41 | 1 | 49 | A | 65 | Q | 81 | a | 97 | q | 113 |
| 0 0 1 0 | 2 | STX | 2 | 2 | DC2 | 18 | 22 | " | 34 | 42 | 2 | 50 | B | 66 | R | 82 | b | 98 | r | 114 |
| 0 0 1 1 | 3 | ETX | 3 | 3 | DC3 (XOFF) | 19 | 23 | # | 35 | 43 | 3 | 51 | C | 67 | S | 83 | c | 99 | s | 115 |
| 0 1 0 0 | 4 | EOT | 4 | 4 | DC4 | 20 | 24 | \$ | 36 | 44 | 4 | 52 | D | 68 | T | 84 | d | 100 | t | 116 |
| 0 1 0 1 | 5 | ENQ | 5 | 5 | NAK | 21 | 25 | % | 37 | 45 | 5 | 53 | E | 69 | U | 85 | e | 101 | u | 117 |
| 0 1 1 0 | 6 | ACK | 6 | 6 | SYN | 22 | 26 | & | 38 | 46 | 6 | 54 | F | 70 | V | 86 | f | 102 | v | 118 |
| 0 1 1 1 | 7 | BEL | 7 | 7 | ETB | 23 | 27 | , | 39 | 47 | 7 | 55 | G | 71 | W | 87 | g | 103 | w | 119 |
| 1 0 0 0 | 8 | BS | 8 | 8 | CAN | 24 | 28 | (| 40 | 48 | 8 | 56 | H | 72 | X | 88 | h | 104 | x | 120 |
| 1 0 0 1 | 9 | HT | 9 | 9 | EM | 25 | 29 |) | 41 | 49 | 9 | 57 | I | 73 | Y | 89 | i | 105 | y | 121 |
| 1 0 1 0 | 10 | LF | 10 | 0A | SUB | 26 | 30 | * | 42 | 50 | : | 58 | J | 74 | Z | 90 | j | 106 | z | 122 |
| 1 0 1 1 | 11 | VT | 11 | 0B | ESC | 27 | 31 | + | 43 | 51 | ; | 59 | K | 75 | [| 91 | k | 107 | { | 123 |
| 1 1 0 0 | 12 | FF | 12 | 0C | FS | 28 | 32 | , | 44 | 52 | < | 60 | L | 76 | \ | 92 | l | 108 | | 124 |
| 1 1 0 1 | 13 | CR | 13 | 0D | GS | 29 | 33 | - | 45 | 53 | = | 61 | M | 77 |] | 93 | m | 109 | } | 125 |
| 1 1 1 0 | 14 | SO | 14 | 0E | RS | 30 | 34 | . | 46 | 54 | > | 62 | N | 78 | ^ | 94 | n | 110 | ~ | 126 |
| 1 1 1 1 | 15 | SI | 15 | 0F | US | 31 | 35 | / | 47 | 55 | ? | 63 | O | 79 | _ | 95 | o | 111 | DEL | 127 |

Soft vs. Hard Reset

Soft Reset

A soft(ware) reset clears printer memory and reloads the most recently saved configuration into memory. It is called a soft reset because no hardware is tested—all diagnostic and initialization tests are bypassed and memory is simply refreshed with the most recent printer configuration.

You must put the printer in the NOT READY state to perform a soft reset:

| Step | Key | Displayed Result | Notes |
|-----------|------------------------------------|--|--|
| 1. Press: | <div>Stop</div> | <div>NOT READY</div> | Takes the printer off-line from the host. |
| 2. Press: | <div>Stop</div> + <div>Enter</div> | <div>STANDBY ...</div> <div>SOFT RESET</div> | Printer loads most recently saved configuration from diskette. |

Hard Reset

A hard(ware) reset runs all initialization and diagnostic routines. To do a hard reset, power off the printer, wait 15 seconds, then power the printer on.

5

Adjustment Procedures

Chapter Contents

| | |
|---|------|
| Preparing the Printer for Maintenance | 5-2 |
| Returning the Printer to Normal Operation | 5-3 |
| Belt, Paper Feed Timing, Adjustment | 5-4 |
| Belt, Platen Open, Adjustment | 5-6 |
| Paper Drive Motor Pulley Alignment | 5-8 |
| Paper Scale Alignment | 5-10 |
| Platen Angle Adjustment | 5-12 |
| Platen Gap Adjustment | 5-14 |
| Platen Open Motor Pulley Alignment | 5-16 |
| Ribbon Guide Alignment | 5-18 |
| Splined Shaft Skew Adjustment | 5-20 |
| Adjusting the End of Forms Distance | 5-22 |
| Hammer Phasing Adjustment | 5-27 |

Preparing the Printer for Maintenance

DANGER

Unplug the printer power cord from the power outlet before doing any maintenance procedure. Failure to remove power could result in injury to you or damage to equipment. If you must apply power during maintenance, you will be instructed to do so in the maintenance procedure.

To prepare the printer for maintenance, do the following steps *before* making an adjustment:

1. Set the printer power switch to O (off).
2. Unplug the printer power cord from the AC power source.
3. Unload paper.
4. Read the entire adjustment procedure before you begin working on the printer.
5. Gather the necessary parts before you begin working on the printer.

Returning the Printer to Normal Operation

When you are finished servicing the printer, restore it to operation by following the steps below:

1. Install the ribbon.
2. Plug the AC power cord into the printer and the power source.
3. Set the printer power switch to 1 (on).
4. Load paper.
5. Close the cabinet doors and the printer cover.
6. Test printer operation by selecting and running one of the operator print tests.
7. Select the emulation. (Refer to the *Operator's Guide*.)
8. Set the top-of-form. (Refer to the *Operator's Guide*.)

Belt, Paper Feed Timing, Adjustment (Figure 5-1)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the paper guide assembly (page 6-40).
4. Remove four screws and the barrier shield (page 6-75, Figure 6-10).
5. Remove the timing belt cover (1) by squeezing the top and bottom to release the plastic tabs from the slots in the side plate.
6. Loosen (do not remove) the motor mount bolts (2).
7. Using the straight end of a force gauge, apply 12 pounds (53.4 N) of pressure to the paper feed drive motor (3). Use the splined shaft (4) to steady the gauge.
8. Reduce tension to 9 pounds (40.0 N) and torque the paper feed motor mount bolts (2) to 18 ± 2 inch-pounds ($2.03 \pm 0.23 \text{ N}\cdot\text{m}$).
9. Snap the timing belt cover (1) into the slots in the side plate.
10. Install the barrier shield and four screws (page 6-75, Figure 6-10).
11. Install the paper guide assembly (page 6-40).
12. Return the printer to normal operation (page 5-3).




Figure 5-1. Paper Feed Timing Belt Adjustment


Belt, Platen Open, Adjustment (Figure 5-2)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the platen open belt cover (1) by squeezing the top and bottom to release the plastic tabs from the slots in the side plate.
4. Loosen the motor mount screws (2).
5. Close the forms thickness lever all the way.

WARNING

Too much tension on the platen open belt can cause the platen gap to change, which can lead to premature wear of the platen, damaged hammer tips, and poor print quality.

6. Using a force gauge, apply 10 ± 1 pounds (44.48 ± 4.45 N) of tension to the platen open motor shaft (3), pulling away from the large platen pulley.
7. Reduce tension to 5 ± 1 pounds (22.24 ± 4.45 N) and torque the motor mount screws (2) to 11 ± 2 inch-pounds (1.24 ± 0.23 N•m).
8. Check the platen gap (page 5-14). Loosen the belt and readjust the gap if necessary.
9. Snap the platen open belt cover (1) into the slots in the side plate.
10. Return the printer to normal operation (page 5-3).



- 1. Belt Cover
- 2. Motor Mount Screw
- 3. Platen Open Motor Shaft




Figure 5-2. Platen Open Belt Adjustment

Paper Drive Motor Pulley Alignment (Figure 5-3)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the timing belt cover (1) by squeezing the top and bottom to release the plastic tabs from the slots in the side plate.
4. Loosen the set screw (2) in the motor pulley collar (3).
5. Align the paper drive motor pulley (4) with the splined shaft pulley (5).

WARNING

Make sure there is at least 0.010 inches (0.25 mm) of clearance between the collar/pulley and the motor face plate.

6. Hold the collar (3) flush against the motor pulley (4) and tighten the set screw (2):
 - a. If the pulley (4) is black (aluminum), torque the set screw to 11 \pm 2 inch-pounds (1.24 \pm 0.23 N•m).
 - b. If the pulley (4) is silver (steel), torque the set screw to 25 \pm 2 inch-pounds (2.82 \pm 0.23 N•m).
7. Check for correct tension on the paper feed timing belt (page 5-4). Adjust if necessary.
8. Snap the timing belt cover (1) into the slots in the side plate.
9. Return the printer to normal operation (page 5-3).





Figure 5-3. Paper Drive Motor Pulley Alignment

Paper Scale Alignment (Figure 5-4)

1. Load paper and ribbon.
2. Connect the power cord to the AC power source.
3. Set the printer power switch to 1 (on).
4. Open the printer cover.
5. Verify that the shuttle cover (1) is properly installed (page 6-23).
6. Print a full 132 column line by selecting and running one of the diagnostic self-tests. (See Chapter 4.)
7. Check alignment of the scale to the print at column positions 1 and 132.
8. If adjustment is necessary, loosen the three button-head $5/64$ inch hex screws (2).
9. Position the scale (3) so that column positions 1 and 132 line up with the first and last characters on the 132 character printout.
10. Tighten the button-head screws (2).
11. Close the printer cover.



1. Shuttle Cover
2. Screw, Button-Head, 5/64 inch hex (3)
3. Paper Scale

Figure 5-4. Paper Scale Alignment

Platen Angle Adjustment (Figure 5-5)

1. Prepare the printer for maintenance (page 5-2).
2. Remove the shuttle frame assembly (page 6-55).
3. Close the forms thickness lever (1) all the way. (Position 'A' on the scale.)
4. Install the platen position gauge (2) and check the angle of the platen (3): forms thickness lever should be against the platen stop, the flat surface of the platen flush with the position gauge, and the position gauge flat on the mechanism base.
 - a. If the angle is correct, no adjustment is necessary. Go to step 7.
 - b. If the angle is incorrect, loosen the clamp screw (4) and set screw (5).
5. Position the platen (3) at the correct angle.
6. Slide the platen (3) to the right and the forms thickness lever (1) to the left to remove end play. Ensure that the forms thickness lever is fully closed. Tighten the clamp screw (4), then tighten the setscrew (5).
7. Remove the platen position gauge (2).
8. Check the platen gap adjustment (page 5-14).
9. Install the shuttle frame assembly (page 6-55).
10. Check the hammer phasing adjustment (page 5-27).
11. Return the printer to normal operation (page 5-3).

1. Forms Thickness Lever
2. Platen Position Gauge
3. Platen
4. Clamp Screw
5. Setscrew




Figure 5-5. Platen Angle Adjustment

Platen Gap Adjustment (Figure 5-6)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the shuttle cover assembly (page 6-23).
4. Remove the ribbon.
5. Loosen the platen open belt (page 5-6, steps 3. and 4.).
6. Raise the forms thickness lever (1) to the fully open position.

WARNING

Do not force the platen against the feeler gauge. Damage to the printer will result.

7. Insert a 0.010 inch (0.25 mm) flat feeler gauge (2) straight down between the hammer bank cover plate (3) and ribbon mask (4), within four hammer positions of the left end of the hammer bank.
8. Gently close the forms thickness lever (1). As the platen is closing, gently slide the feeler gauge up and down, keeping it between the hammer tip and ribbon mask. If the feel is too tight when the platen is being closed, adjust the set screw (5) at the end of the platen counterclockwise. If the feel is too loose, adjust the set screw clockwise. With the forms thickness lever closed all the way, the feeler gauge should contact both the tips and the ribbon mask and move with light friction. Shift the gauge slightly to verify.
9. Repeat steps 6. through 8. at the right end of the hammer bank.
10. After adjusting both sides, check the gap again at both ends. Readjust if necessary.
11. When the platen gap is correct at both ends of the platen, adjust the platen open belt (page 5-6).
12. Install the shuttle cover assembly (page 6-23).
13. Check the hammer phasing adjustment (page 5-27).
14. Return the printer to normal operation (page 5-3).




Figure 5-6. Platen Gap Adjustment

Platen Open Motor Pulley Alignment (Figure 5-7)

1. Prepare the printer for maintenance (page 5-2).
2. Open the printer cover.
3. Remove the platen open belt cover (1) by squeezing the top and bottom to release the plastic tabs from the slots in the side plate.
4. Loosen the set screw (2) in the motor pulley.
5. Align the platen open motor pulley (3) with the platen shaft pulley (4) and tighten the set screw (2) to 9 ± 2 inch-pounds (1.02 ± 0.23 N•m).
6. Check the platen open belt tension (page 5-6). Adjust if necessary.
7. Snap the platen open belt cover (1) into the slots in the side plate.
8. Return the printer to normal operation (page 5-3).







Figure 5-7. Platen Open Motor Pulley Alignment

Ribbon Guide Alignment (Figure 5-8)

1. Open the printer cover.
2. Load paper and install the ribbon. To adjust the left ribbon guide, the ribbon should have a full spool on the right hub (1).
3. Run a ribbon and shuttle diagnostic self-test. (See Chapter 4.)
4. To adjust the left ribbon guide, momentarily short between the left ribbon guide skid screws (2) to assure right to left motion of the ribbon.
5. Observe how the ribbon (3) is passing around the left ribbon guide (4). It should be centered and not folding against either of the two white nylon washers.
6. If the ribbon is not centered, loosen the retaining screws (5) just enough so that the ribbon guide (4) can be rotated to new positions, but remains in place once moved.
7. Rotate the ribbon guide (4) as necessary to center the ribbon (3).
8. Observe how the ribbon (3) is winding on the left spool (6). If the ribbon is interfering with the flange of the spool, make sure the ribbon hub and spool are mounted correctly.
9. Tighten the screws (5).
10. Allow most of the ribbon to accumulate on the left spool (6). Repeat steps 3 through 9 for the right ribbon guide (7).




1. Right Hub
2. Screw, Left Ribbon Guide Skid (2)
3. Ribbon
4. Ribbon Guide, Left
5. Screw, Retaining (2)
6. Left Ribbon Spool
7. Ribbon Guide, Right

Figure 5-8. Ribbon Guide Alignment

Splined Shaft Skew Adjustment (Figure 5-9)

If lines of print are not parallel with the edge perforations on the paper, perform the following adjustment.

1. Prepare the printer for maintenance (page 5-2).
2. Loosen the screw (1) securing the adjusting link (2).
3. Adjust the link (2) by raising or lowering the horizontal adjustment knob (3) to obtain print parallel with paper perforations. Tighten the screw (1).
4. Return the printer to normal operation (page 5-3).



- 1. Screw
- 2. Adjusting Link
- 3. Horizontal Adjustment Knob

Figure 5-9. Splined Shaft Skew Adjustment

Adjusting the End of Forms Distance

This procedure tests and sets the distance from the page perforation at which an END OF FORMS fault message is triggered. This adjustment prevents printing on the platen when the printer runs out of paper. The measurement units are dot rows.

You will use the dot row patterns printed by the END OF FORMS ADJUST self-test to verify that this parameter is set correctly.

NOTE: Do this procedure only if a new paper detector switch assembly has been installed, or if you are sure that the end of forms adjustment is incorrect. An END OF FORMS triggering distance of 1 or 2 dot rows from the perforation is acceptable; 5 to 7 dot rows off indicates adjustment is required.

Also, although it is not required, it is advisable to test the End of Forms distance with 6-part paper, in order to verify correct printing with multi-part forms.

The procedure below describes how to run the END OF FORMS ADJUST printer test and modify the END OF FORMS ADJUSTMENT VALUE.

1. Power on the printer.
2. Load paper and set the top of form. Make sure the forms thickness lever is closed. Open the cabinet front door.
3. On the paper just below the paper entrance slot, tear a four-inch square on the left side, immediately below the perforation. (See Figure 5-10.) This creates a hole that will trigger an END OF FORMS condition, but allows printing to the right of the hole (which would normally be on the platen).





Figure 5-10. Paper Preparation for Paper Out Adjustment Test

4. Tear a four inch square in the manner described above, on every third sheet, until you have made 3 or 4 holes.
5. If the printer is in **READY** mode, press **Stop** to put it into **NOT READY** mode.
6. Press **Scroll↑ + Scroll↓** to unlock the **Enter** key.
7. Press **Scroll↑ + Scroll↓ + Return + Enter** to enter the **CE Tests** menu. (Press all four keys at the same time.)
8. The display will show "**SERVICE / PRINTER MECHANISM TESTS**," the first menu item. Press **Enter** to enter the mechanism tests menu.
9. Press **Scroll↑** or **Scroll↓** until "**PRINTER MECHANISM TESTS / END OF FORMS ADJUST**" is on the display.

This test will print a vertical "comb" pattern at around column 70, each long bar separated by 4 dot rows. (An enlarged example of the comb pattern is shown below.)



10. Press **Enter** until the **END OF FORMS ADJUST** test starts. The comb pattern will print until the display shows "**001 END OF FORMS / LOAD FORMS**" and (if enabled) the audible alarm sounds. If the alarm sounds, press **Stop** to silence it.
11. Remove the paper from the tractors and examine the area of the page perforation. (If the alarm sounds when you open the platen, press **Stop** to silence it.)

If a long bar just meets the perforation, the end of forms adjustment distance is correct. (1 or 2 dot rows off is OK; 5 to 7 dot rows off is too much.) Unless you wish to restart the procedure with 6-part paper, you may stop the test here, and skip to step 22. (See the note at the beginning of this procedure.)

If the comb pattern stopped short of the perforation or printed beyond the perforation, go to step 12.

12. Measure how short or long the comb pattern printed by counting the number of dot rows needed to reach the perforation, or the number of dot rows that printed beyond the perforation.

NOTE: You can use the long bars to count the dot rows quickly. There are three dot rows between each long bar, so each long bar increases the number of dot rows by four. You can also tear off a small piece of the comb pattern from the beginning of the pattern and use it as a ruler to help you measure the dot rows required either to reach the perforation or back up to it.

13. Reload the paper and set the top of form.
14. Press **Scroll↑ + Scroll↓ + Return + Enter** to enter the CE Tests menu. (Press all four keys at the same time.)
15. The display will show "SERVICE / PRINTER MECHANISM TESTS," the first menu item. Press **Scroll↑** or **Scroll↓** until "SERVICE / END OF FORMS ADJUSTMENT VALUE" is on the display.
16. Press **Enter**. The top line of the display will show "END OF FORMS ADJUSTMENT VALUE" and the bottom line will show the current setting for the number of dots.
17. Press **Enter**. The number of dots will move up to the top line of the display.
18. Using the **Scroll↑** or **Scroll↓** key, adjust the **XX DOTS** value up or down by the number of dots you counted in step 12. (If the comb pattern stopped short of the perforation, increase the number of dots. If the comb pattern printed beyond the perforation, decrease the number of dots.)
19. Press **Enter** to select the new number of dots as the active value. (The asterisk that appears tells you that it is now the active value.)
20. Press **Stop** to put the printer into NOT READY mode.
21. Run the **END OF FORMS ADJUST** and the **END OF FORMS ADJUSTMENT VALUE** tests until the comb pattern prints at an acceptable distance from the page perforation. (Return to step 7.)
22. When the End of Forms Adjustment is acceptable, reload the paper, feed it past any remaining unused holes that you tore in it, and set the top of form.

23. Press **Scroll↑ + Scroll↓** to lock the **Enter** key.
24. Press **Start** to put the printer into **READY** mode.

Hammer Phasing Adjustment

Hammer phasing must be checked and adjusted if PROMs on the controller board are replaced.

Phasing should be adjusted with the printer printing at full paper width.

The procedure is as follows:

1. Power on the printer.
2. Install the ribbon.
3. Load full width (132 column) paper and set the top of form.
4. Press **Stop** to put the printer into NOT READY mode.
5. Press **Scroll**↑ + **Scroll**↓ to unlock the **Enter** key.
6. Press **Scroll**↑ + **Scroll**↓ + **Return** + **Enter** to enter the CE Tests menu.
(Press all four keys at the same time.)
7. The display will show "SERVICE / PRINTER MECHANISM TESTS," the first menu item. Press **Enter** to enter the mechanism tests menu.
8. Press **Scroll**↑ or **Scroll**↓ until "PRINTER MECHANISM TESTS / HAMMER PHASING" is on the display.
9. Press **Enter**. The printer begins printing all Hs, each line preceded by the phasing index number.
10. Press **Return**. The display will show "SERVICE / PRINTER MECHANISM TESTS".
11. Press **Scroll**↑ or **Scroll**↓ until "SERVICE / HAMMER PHASE VALUE" is on the display.
12. Press **Enter**. The top line of the display will show "HAMMER PHASE VALUE" and the bottom line will show the current phasing index number.
13. Press **Enter**. The phasing index (followed by an asterisk) will move up to the top line of the display.

14. Press **Scroll↑** or **Scroll↓** to increase or decrease the phasing index, followed by pressing **Enter**, which activate the value as it prints. Continue to increase or decrease the phasing index until the pattern of Hs appears as shown below:



15. When the print pattern is acceptable, press **Stop**. Printing stops, and the printer automatically enters the current phase index value into NVRAM. The display shows "NOT READY".
16. Press **Scroll↑ + Scroll↓** to lock the **Enter** key.
17. Close the printer cover. Press **Start** to put the printer into READY mode.

6

Replacement Procedures and Illustrated Parts List

Chapter Contents

| | |
|--|------------|
| Organization of This Chapter | 6-3 |
| Section I: Replacement Procedures | 6-4 |
| Preparing the Printer for Maintenance | 6-4 |
| Belt, Paper Feed Timing | 6-5 |
| Belt, Platen Open | 6-6 |
| Cable Assembly W4, Hammer Bank | 6-8 |
| Cable Assembly W5, Intermediate | 6-10 |
| Cable Assembly, Multi I/O | 6-12 |
| Circuit Board: Controller | 6-14 |
| Circuit Board: LP30 Backplane | 6-16 |
| Circuit Board: Mechanism Driver | 6-18 |
| Circuit Board: Power Supply | 6-20 |
| Circuit Breaker | 6-21 |
| Cover Assembly, Hammer Bank | 6-22 |
| Cover Assembly, Shuttle | 6-23 |
| Diskette Drive Assembly | 6-24 |
| Fan Assembly, Card Cage | 6-26 |
| Fan Assembly, Cabinet Exhaust | 6-27 |
| Fan Assembly, Hammer Bank | 6-28 |
| Hammer Spring Assembly | 6-29 |

| | |
|---|------|
| Magnetic Pick-up (MPU) Assembly | 6-32 |
| Motor Assembly, Ribbon Drive | 6-33 |
| Motor Assembly, Paper Feed | 6-34 |
| Motor Assembly, Platen Open | 6-36 |
| Operator Panel Assembly | 6-38 |
| Paper Guide Assembly | 6-40 |
| Paper Ironer | 6-41 |
| Paper Stacker Assembly | 6-42 |
| Platen | 6-43 |
| PROMs and Modules on the Controller Board | 6-46 |
| PROMs on the Mechanism Driver Board | 6-48 |
| Ribbon Hub | 6-50 |
| Ribbon Guide Assembly (L/R) | 6-51 |
| Security Module | 6-46 |
| Shaft, Splined | 6-52 |
| Shaft, Support | 6-54 |
| Shuttle Frame Assembly | 6-55 |
| Spring Assembly, Gas | 6-57 |
| Spring, Extension | 6-58 |
| Switch Assembly, Cover Open | 6-59 |
| Switch Assembly, Paper Detector | 6-60 |
| Switch Assembly, Platen Interlock | 6-61 |
| Tractor (L/R) | 6-62 |
| Returning the Printer to Normal Operation | 6-63 |

Section II: Illustrated Parts List 6-65

| | |
|---|------|
| Figure 6-6. Top Cover, Doors, and Casters | 6-67 |
| Figure 6-7. Paper Stacker Tray Assembly and Paper Chains | 6-69 |
| Figure 6-8. Operator Panel and Cabinet Details | 6-71 |
| Figure 6-9. Floppy Diskette Drive | 6-73 |
| Figure 6-10. Covers | 6-75 |
| Figure 6-11. Print Mechanisms and Card Cage | 6-77 |
| Figure 6-13. Magnetic Pickup Unit (MPU) and Extension Spring .. | 6-81 |
| Figure 6-14. Tractor Shafts | 6-83 |
| Figure 6-15. Platen | 6-85 |
| Figure 6-16. Motors, Card Cage Fan, and Paper Detector Switch .. | 6-87 |
| Figure 6-17. Circuit Breaker and Line Filter | 6-89 |
| Figure 6-18. Cable Assembly W4, Hammer Bank | 6-91 |
| Figure 6-19. Cable Assembly W5, Intermediate, and Cover Open Switch Assembly | 6-93 |

Organization of This Chapter

This chapter is divided into two sections.

♦ Section I: Replacement Procedures

Written procedures for removing and installing components that are replaceable at the field service level of maintenance. Section I begins on page 6-4.

The procedures refer you to the illustrations in Section II.

♦ Section II: Illustrated Parts List

Drawings of all assemblies comprising the printer. On the page facing each illustration is a list of the illustrated parts and their part numbers. Section II begins on page 6-65.

Section I: Replacement Procedures

IMPORTANT

The components specified in this chapter are field replaceable units (FRUs). FRUs must be repaired at the factory. Do not attempt field repair of these items.

Preparing the Printer for Maintenance

DANGER

Unplug the printer power cord from the power outlet before doing any maintenance procedure. Failure to remove power could result in injury to you or damage to equipment. If you must apply power during maintenance, you will be instructed to do so in the maintenance procedure.

1. Set the printer power switch to O (off).
2. Unplug the printer power cord from the AC power source.
3. Open the printer cover.
4. Unload paper.
5. Read the entire replacement procedure before you begin working on the printer. The procedure refers you to the appropriate illustration.
6. Gather the necessary replacement part(s) before you begin the procedure.

Belt, Paper Feed Timing

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the paper guide assembly (page 6-40).
4. Remove four screws and the barrier shield (page 6-75, Figure 6-10).
5. Remove the timing belt cover by squeezing the top and bottom to release the plastic tabs from the slots in the side plate (page 6-75, Figure 6-10).
6. Loosen (do not remove) the paper feed motor mount screws (page 6-87, Figure 6-16).
7. Remove the paper feed timing belt by working the side of the belt onto the lip of the motor pulley and rotating the pulleys until the belt rolls off.

Installation

1. Install the paper feed timing belt over the splined shaft pulley and the lip of the motor pulley and rotate the pulleys until the belt rolls onto the motor pulley.
2. Using the straight end of a force gauge, apply 12 pounds (53.38 N) of pressure to the paper feed drive motor. Use the splined shaft to steady the gauge.
3. Reduce pressure to 9 pounds (40.03 N) and torque the paper feed motor mount screws to 18 ± 2 inch-pounds ($2.03 \pm 0.23 \text{ N}\cdot\text{m}$).
4. Snap the timing belt cover into the slots in the side plate (page 6-75, Figure 6-10).
5. Install the barrier shield and four screws.
6. Install the paper guide assembly (page 6-40).
7. Return the printer to normal operation (page 6-63).

Belt, Platen Open

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the platen open belt cover by squeezing the top and bottom to release the plastic tabs from the slots in the side plate (page 6-85, Figure 6-15).
4. Loosen (do not remove) the two motor mount screws (page 6-87, Figure 6-16).
5. Push the motor toward the front of the printer to loosen the platen open belt.
6. Remove the platen open belt from the motor pulley and platen pulley.

Installation

1. Slide the platen open belt over the motor pulley and platen pulley.
2. Close the forms thickness lever all the way.
3. Make sure the collar of the platen pulley clears the left ribbon guide with the platen fully closed.
 - a. If it does not, rotate the platen pulley until the collar clears the left ribbon guide and tighten the set screw to 11 ± 2 inch-pounds ($1.24 \pm 0.23 \text{ N}\cdot\text{m}$). Go to step 4.
 - b. If the collar clears the ribbon guide with the forms thickness lever closed, go to step 4.

WARNING

Too much tension on the platen open belt can cause the platen gap to change, which can lead to premature wear of the platen, damaged hammer tips, and poor print quality.

4. Using a force gauge, apply 10 pounds (44.48 N) of tension to the motor shaft by pulling away from the large platen pulley.
5. Reduce tension to 5 pounds (22.24 N) and torque the motor mount screws to 11 ± 2 inch-pounds ($1.24 \pm 0.23 \text{ N}\cdot\text{m}$).
6. Check the platen gap (page 5-14). Loosen the belt and readjust if necessary.
7. Snap the platen open belt cover into the slots in the side plate.
8. Return the printer to normal operation (page 6-63).

Cable Assembly (W4), Hammer Bank

Removal

NOTE: This procedure removes the left hammer bank cable assembly. The procedure for removing the right cable assembly is the same.

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the shuttle cover assembly (page 6-23).
4. Remove the paper guide assembly (page 6-40).
5. Remove the controller board (page 6-14).
6. Remove the mechanism driver board (page 6-18).
7. Remove the power supply board (page 6-20).
8. Remove two screws securing the connector to the bottom of the card cage (page 6-91, Figure 6-18).
9. Remove two screws securing the connector to the base casting.
10. Note the location and number of tie wraps, then remove them.
11. Feed the hammer bank cable assembly down through the base casting, then out of the card cage.

Installation

WARNING

Be careful not to damage the ribbon cable on the card cage or base casting. Make sure the protective barrier is on top of the ribbon cables at the card cage bottom.

NOTE: This procedure installs the left hammer bank cable assembly. The procedure for installing the right cable assembly is the same.

1. Feed the hammer bank cable assembly down through card cage, around the printer, then up through the base casting.
2. Install two screws securing the connector to the base casting (page 6-91, Figure 6-18).
3. Install two screws securing the connector to the bottom of the card cage.
4. Install tie wraps to join left and right hammer bank cable assemblies. (See Removal step 10.)
5. Install the power supply board (page 6-20).
6. Install the mechanism driver board (page 6-18).
7. Install the controller board (page 6-14).
8. Install the paper guide assembly (page 6-40).
9. Install the shuttle cover assembly (page 6-23).
10. Return the printer to normal operation (page 6-63).

Cable Assembly W5, Intermediate

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the paper guide assembly (page 6-40).
4. Remove the controller board (page 6-14).
5. Remove the mechanism driver board (page 6-18).
6. Remove the screws securing the intermediate cable assembly connector P1 to the bottom of the card cage. Loosen the screw securing the ground lug, and remove the ground lug (page 6-93, Figure 6-19).
7. Disconnect connector P1(P) from the platen interlock switch assembly.
8. Disconnect connector PMD from paper detector switch assembly connector PMD(P).
9. Remove the cover open switch assembly and disconnect connectors CO+ and CO- (page 6-59).
10. Note the location of cable runs and restraints, cut the tie wraps, and remove the intermediate cable assembly through the card cage.

Installation

1. Feed the intermediate cable assembly through the card cage opening and install tie wraps and cable restraints. (See removal step 10.)
2. Connect connectors CO+ and CO- and install the cover open switch assembly (page 6-59).
3. Connect connector PMD to paper detector switch assembly connector PMD(P).
4. Connect connector P1(P) to the platen interlock switch assembly.
5. Install the screws securing the intermediate cable assembly connector P1 to the bottom of the card cage (page 6-93, Figure 6-19).
6. Insert the ground lug under the screw and tighten the screw.
7. Install the mechanism driver board (page 6-18).
8. Install the controller board (page 6-14).
9. Install the paper guide assembly (page 6-40).
10. Return the printer to normal operation (page 6-63).

Cable Assembly, Multi I/O

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Disconnect the host interface cables from the printer.
3. Remove the paper guide assembly (page 6-40).
4. Open the cabinet doors.
5. Remove the paper stacker assembly (page 6-42).
6. Remove screws and move the service panel aside. (See Figure 6-8, page 6-71.)
7. Remove the I/O cable from the restraints on the upper right and upper rear walls of the cabinet.
8. Remove the controller board (page 6-14).
9. Disconnect the parallel/serial cable connector P4 from connector J4 on the LP30 backplane board. (See Figure 6-11, page 6-77.)
10. Release the I/O cable from the holders on the rear wall of the card cage.
11. Feed the I/O cable through the card cage and down into the cabinet.
12. Remove four screws securing the I/O cable assembly mounting plate.
13. Remove the multi I/O cable assembly.

Installation

1. Feed the multi I/O cable from the lower cabinet up into the opening at the right rear of the card cage. Route the cable against the right rear wall of the cabinet. (See Figure 6-8, page 6-71.)
2. Install four screws securing the multi I/O cable assembly mounting plate.
3. Slide the I/O cable carefully into the cable restraints located on the upper rear and upper right cabinet walls.
4. Engage the I/O cable in the holders on the rear wall of the card cage. Remove the mechanism driver board if necessary to gain clearance (page 6-18).
5. Connect the parallel/serial cable connector P4 to connector J4 on the LP30 backplane board. (See Figure 6-11, page 6-77.)
6. Install the controller board (page 6-14).
7. Connect the I/O cable connector to connector J1 on the controller board. (See Figure 6-11, page 6-77, detail C.)
8. Move the service panel into position and install the screws.
9. Install the paper stacker assembly (page 6-42).
10. Close the cabinet doors.
11. Install the paper guide assembly (page 6-40).
12. Return the printer to normal operation (page 6-63).

Circuit Board: Controller

WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit boards.

Removal

1. Make a configuration printout. (Refer to the *Operator's Guide*.)
2. Prepare the printer for maintenance (page 6-4).
3. Remove the paper guide assembly (page 6-40).
4. Disconnect the CCB/Mech Driver cable from connector J3 (page 6-77, Figure 6-11, item 5).
5. Disconnect the I/O cable connector from connector J1 on the controller board.
6. Grasp the controller board by the ejection levers and pull it up and out of the card cage. (See page 6-77, Figure 6-11, item 13.)
7. Remove the Boot PROM, RTPU PROM, and PFC PROM from the controller board from the controller board (page 6-46).
8. If there is optional memory on the controller board (IPDS models only), remove this memory using module extraction tool 75X5893 (page 6-46).

Installation

WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit boards.

1. Make sure the Boot PROM, RTPU PROM, PFC PROM and any optional memory are installed on the replacement controller board (page 6-46).
2. Slide the controller board down into the card cage. Engage edge connector J5 in connector J8 of the LP30 backplane and connector P1 in connector P1 of intermediate cable assembly W5. (See page 6-77, Figure 6-11, item 13.)
3. Gently push the controller board down until it is fully seated in the edge connectors.
4. Connect the CCB/Mech Driver cable connector to connector J3. (See page 6-77, Figure 6-11, item 5.)
5. Connect the I/O cable connector to connector J1 on the controller board. (See also the connector detail on pages 6-77 and NO TAG.)
6. Install the paper guide assembly (page 6-40).
7. Adjust the hammer phasing (page 5-27).
8. Return the printer to normal operation (page 6-63).
9. Using the configuration printout you made as step 1 of the removal procedure, reset and save the printer configuration.

Circuit Board: LP30 Backplane

WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit boards.

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the paper guide assembly (page 6-40).
3. Remove the controller board (page 6-14).
4. Remove the mechanism driver board (page 6-18).
5. Disconnect the cables from the LP30 backplane board: (See page 6-77, Figure 6-11, item 14.)
 - a. Disconnect Power Supply connector P5 from LP30 backplane connector J2.
 - b. Disconnect floppy drive connector J6 from LP30 backplane connector J5.
 - c. Disconnect multi I/O interface connector J1 from LP30 backplane connector J4.
 - d. Disconnect floppy power connector P9 from LP30 backplane connector J1.
 - e. Disconnect control panel connector P1 from LP30 backplane connector J3.
 - f. Disconnect security backplane cable connector P1 from LP30 backplane connector J6.
6. Remove four screws and the LP30 backplane board.

Installation

WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit boards.

1. Position the LP30 backplane board over the mounting studs on the card cage floor and install the four screws. (See page 6-77, Figure 6-11, item 14.)
2. Connect the cable assemblies to the LP30 backplane board:
 - a. Connect security backplane cable connector P1 to LP30 backplane connector J6.
 - b. Connect control panel connector P1 to LP30 backplane connector J3.
 - c. Connect floppy power connector P9 to LP30 backplane connector J1.
 - d. Connect multi I/O interface connector J1 to LP30 backplane connector J4.
 - e. Connect floppy drive connector J6 to LP30 backplane connector J5.
 - f. Connect PSA/Power Supply connector P5 to LP30 backplane connector J2.
3. Install the mechanism driver board (page 6-18).
4. Install the controller board (page 6-14).
5. Install the paper guide assembly (page 6-40).
6. Return the printer to normal operation (page 6-63).

Circuit Board: Mechanism Driver

WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit boards.

Do not flex the mechanism driver board or grasp components on the board as you remove it. Damage to components may result. Handle the board carefully by the ejections levers, sides, or the heat sink.

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the paper guide assembly (page 6-40).
3. Disconnect the CCB/Mech Driver ribbon cable from connector J6. (See page 6-77, Figure 6-11, item 5.)
4. Grasp the mechanism driver board by the ejection levers and pull it up and out of the card cage. (See page 6-77, Figure 6-11, item 12.)
5. Remove the RSP PROM (page 6-48).

Installation

WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit boards.

Do not flex the mechanism driver board or grasp components on the board as you install it. Damage to components may result. Handle the board carefully by the ejections levers, sides, or the heat sink.

1. Install the RSP PROM (page 6-48) onto the replacement mechanism driver board.
2. Slide the mechanism driver board down into the card cage. Engage the card edge connectors in the connectors at the bottom of the card cage. (See page 6-77, Figure 6-11, item 12.)
3. Gently push the mechanism driver board down until it is fully seated in the edge connectors.
4. Connect the CCB/Mech Driver ribbon cable to connector J6. (See page 6-77, Figure 6-11, item 5.)
5. Install the paper guide assembly (page 6-40).
6. Return the printer to normal operation (page 6-63).

Circuit Board: Power Supply

CAUTION

To prevent injury from electric shock, wait at least one minute after shutting off power before removing the power supply board. Do not touch components or flex the board during removal/installation. Handle the board by the ejection levers and the sides. Wear a properly grounded static wrist strap when handling the power supply board.

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the paper guide assembly (page 6-40).
3. Disconnect the + 5V power supply cable from connector J102 on the power supply board. (See 6-77, Figure 6-11, item 11.)
4. Grasp the power supply board by the ejection levers and pull it up approximately four inches. (See 6-77, Figure 6-11, item 4.)
5. Disconnect the AC/ground cable from connector J1 on the power supply board. (See 6-77, Figure 6-11, item 3.)
6. Remove the power supply board from the card cage.

Installation

1. Connect the AC/ground cable to connector J1 on the power supply board. (See 6-77, Figure 6-11, item 3.)
2. Slide the power supply board into the card cage, engaging the card edge connector at the bottom of the card cage. (See 6-77, Figure 6-11, item 4.)
3. Connect the + 5V power supply cable to connector J102. (Make sure the locking edge is oriented properly to connector J102.) (See 6-77, Figure 6-11, item 11.)
4. Seat the power supply board in the edge connector on the bottom of the card cage.
5. Install the paper guide assembly (page 6-40).
6. Return the printer to normal operation (page 6-63).

Circuit Breaker

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open both cabinet doors.
3. Remove the paper stacker assembly (page 6-42).
4. Remove six screws and move the service panel aside. (See Figure 6-17, page 6-89.)
5. Disconnect the four circuit breaker electrical leads.
6. Press in on the spring clips and push the circuit breaker out of the cabinet.

Installation

1. Press the circuit breaker (5) into the cabinet until the spring clips (4) snap into place. (See Figure 6-17, page 6-89.)

WARNING

Make sure the four leads are connected as shown on page 6-89 (Figure 6-17).

2. Connect the four circuit breaker electrical leads (3) as shown on page 6-89, Figure 6-17.
3. Move the service panel back into position and install the six screws.
4. Install the paper stacker assembly (page 6-42).
5. Return the printer to normal operation (page 6-63).

Cover Assembly, Hammer Bank

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the shuttle frame assembly (page 6-55).
3. Lift the thick plate of the hammer bank cover assembly at one end, and peel the cover away from hammer bank magnets (page 6-77, Figure 6-11).

Installation

WARNING

The hammer bank contains a strong magnet. To prevent damage to the hammer tips, do not let the hammer bank cover assembly snap into place as the hammer bank magnet attracts it. Any impact of the cover against the hammer bank can break hammer tips.

1. With the thick plate facing the hammer bank, engage the bottom edge of the hammer bank cover assembly on the alignment pins (page 6-77, Figure 6-11).
2. Gently lower the hammer bank cover assembly until it lies flush on the hammer bank. Check that the hammer bank cover assembly is properly positioned over the alignment pins and hammer tips.
3. Install the shuttle frame assembly (page 6-55).
4. Return the printer to normal operation (page 6-63).

Cover Assembly, Shuttle

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the ribbon spools.
4. Loosen the shuttle cover screws (page 6-75, Figure 6-10).
5. Grasping the edges of the shuttle cover assembly, tilt up the rear edge and lift the shuttle cover assembly out of the printer.

Installation

1. Place the shuttle cover assembly in the printer. Tilt the forward edge of the cover down slightly and work the cover into position (page 6-75, Figure 6-10).

NOTE: Make sure the holes in the cover are over the locating pins.

2. Tighten the shuttle cover screws.
3. Return the printer to normal operation (page 6-63).

Diskette Drive Assembly


Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the cabinet rear door.
3. Loosen, but do not remove, four screws securing the disk drive mounting bracket to the printer frame. The mounting bracket has keyways which enable you to remove it without removing the mounting screws. (See Figure 6-9, page 6-73.)
4. Slide the disk drive mounting bracket off the mounting screws.
5. Disconnect the floppy interface cable connector from the rear of the floppy diskette drive assembly.
6. Disconnect the floppy power cable connector from the rear of the floppy diskette drive assembly.
7. Remove four screws securing the diskette drive assembly to the mounting bracket.


Installation

1. On the disk drive unit, set the jumpers for Drive 0, according to the manufacturer's pattern shown in Figure 6-1.
2. Position the diskette drive assembly in the mounting bracket and install four screws securing the drive to the bracket. (See Figure 6-9, page 6-73.)
3. Connect the floppy interface cable connector to the rear of the floppy diskette drive assembly. (See Figure 6-9, page 6-73.)
4. Connect the floppy power cable connector to the rear of the floppy diskette drive assembly. (See Figure 6-9, page 6-73.)
5. Slip the bracket keyways over the mounting screws on the underside of the printer frame and slide the bracket to lock it in position.
6. Tighten the four bracket mounting screws.
7. Return the printer to normal operation (page 6-63).


**Alps
Model DFR823**



Alps
Model DFR883



Sony
Model MP-F40W-15



Teac
Model FD-235J




Figure 6-1. Disk Drive Jumper Locations

Fan Assembly, Card Cage

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the paper guide assembly (page 6-40).
4. Remove the two fan mounting screws (page 6-87, Figure 6-16).
5. Disconnect the fan cable connector.
6. Remove the card cage fan assembly and fan guard from the card cage.

Installation

WARNING

Make sure to install the fan so the label is against the card cage. Air flow is INTO the card cage.

1. Connect the fan cable connector (page 6-87, Figure 6-16).
2. Position the card cage fan assembly and fan guard in the card cage.
3. Install the two fan mounting screws.
4. Install the paper guide assembly (page 6-40).
5. Return the printer to normal operation (page 6-63).

Fan Assembly, Cabinet Exhaust

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the floor cabinet doors.
3. Remove the stacker assembly (page 6-42).
4. Remove six screws and move the service panel aside (page 6-71, Figure 6-8).
5. Remove the two fan mounting screws.
6. Disconnect the fan cable connector.
7. Remove the cabinet exhaust fan assembly and fan guard.

Installation

WARNING

Make sure to install the fan so the label is down. Air flow is down.

1. Connect the fan cable connector (page 6-71, Figure 6-8).
2. Position the cabinet exhaust fan assembly and fan guard on the cabinet floor.
3. Install the two fan mounting screws.
4. Move the service panel back into position and install the six screws.
5. Install the stacker assembly (page 6-42).
6. Return the printer to normal operation (page 6-63).

Fan Assembly, Hammer Bank

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the shuttle cover assembly (page 6-23).
3. Remove the operator panel bracket assembly (page 6-71, Figure 6-8).
4. Remove the two screws securing the fan to the base casting (page 6-77, Figure 6-11).
5. Reach under the base casting and disconnect the hammer bank fan cable connector.
6. Angle the hammer bank fan assembly up and out from under the shuttle motor and feed the motor wires and cable connector out from between the base casting and the foam air shroud.

Installation

WARNING

Make sure to install the fan so the label faces up. Air flow is up.

NOTE: The hammer bank fan assembly is installed by angling it down and under the shuttle motor.

1. Feed the hammer bank fan cable connector and motor wires between the fan well of the base casting and the foam air shroud (page 6-77, Figure 6-11).
2. Reach up under the base casting and route the fan cable to the right and angle the hammer bank fan assembly down into the fan well.
3. Route the motor wires as shown in Figure 6-11 (page 6-77) connect the hammer bank fan cable connector.
4. Install two screws in the locations shown in Figure 6-11 (page 6-77).
5. Install the operator panel bracket assembly (page 6-71, Figure 6-8).
6. Install the shuttle cover assembly (page 6-23).
7. Return the printer to normal operation (page 6-63).

Hammer Spring Assembly

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the shuttle frame assembly (page 6-55).
3. Remove the hammer bank cover assembly (page 6-22).
4. Remove the three socket head screws from the old hammer fret.
5. Using the pointed end of the nylon stick supplied in the hammer spring replacement kit, gently pry the old hammer fret off its mounting pins.
(See Figure 6-2, below.)
6. Discard the old hammer fret and mounting screws.




Figure 6-2. Hammer Spring Assembly, Removal

Installation

IMPORTANT

Fret one is mounted on the right end of the hammer bank as you face the hammer springs. Fret seven is mounted on the left end of the hammer bank.


1. If you are replacing an inner fret (frets 2 through 6), go to step 2.
If you are replacing fret 1 or 7:
 - a. Remove the hammer spring fret from the box. Hold the fret by the thick portion, and grab the hammer to be removed with a set of chain-nose pliers in the thin section, as shown in Figure 6-3 (overleaf).
 - b. Bend the hammer downward 90°, as shown in Figure 6-3.
 - c. Without removing the pliers, bend the hammer up, past the straight position approximately 45°, as shown in Figure 6-3.
 - d. Bend the hammer down again, as in substep b, and it will break off.
 - e. Go to step 3.
2. Remove the new fret and mounting screws from the box.

WARNING

Clean the hammer bank surface under the fret before installing a new fret. Dirt or debris between the fret and hammer bank can cause misalignment, degraded performance, or damage to the hammer springs.

3. Install the new fret on the hammer bank mounting pins and press it into position with the flat end of the nylon stick supplied in the hammer spring replacement kit.
4. Install the screws from the replacement kit. Using a Torx[®] T-10 bit adapter, torque each screw to 14 in-lbs (1.58 N•m) in the order shown in Figure 6-3.
5. Install the hammer bank cover assembly (page 6-22).
6. Install the shuttle frame assembly (page 6-55).
7. Return the printer to normal operation (page 6-63).

Preparation – Frets 1 and 7 only



Installation – All Frets





Figure 6-3. Hammer Spring Assembly, Installation

Magnetic Pick-up (MPU) Assembly

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the shuttle cover (page 6-23).
3. Disconnect the shuttle cable assembly connector (page 6-77, Figure 6-11).
4. Disconnect the magnetic pick-up (MPU) cable connector (page 6-77, Figure 6-11).
5. Loosen the 7/64 inch hex MPU clamp screw (page 6-81, Figure 6-13).
6. Unscrew the MPU assembly from the MPU bracket.

Installation

1. Install the MPU assembly by screwing it into the MPU bracket (page 6-81, Figure 6-13).
2. Using a feeler gauge, adjust the gap between the MPU assembly and the flywheel to 0.010 ± 0.001 inch (0.254 ± 0.025 mm). Torque the MPU clamp screw to 19 ± 1 inch-pounds (2.15 ± 0.11 N•m).
3. Check the gap between the MPU assembly and the flywheel with a feeler gauge:
 - a. If the gap is 0.010 ± 0.001 inch (0.254 ± 0.025 mm), go to step 4.
 - b. If the gap is not 0.010 ± 0.001 inch (0.254 ± 0.025 mm), loosen the MPU clamp screw and go back to step 2.

WARNING

In the next step, route the MPU cable under the extension spring and make sure it does not touch the spring after cable connection.

4. Connect the magnetic pick-up (MPU) cable connector.
5. Connect the shuttle cable assembly connector.
6. Install the shuttle cover (page 6-23).
7. Adjust the hammer phasing (page 5-27.)
8. Return the printer to normal operation (page 6-63).

Motor Assembly, Ribbon Drive

Removal

NOTE: The procedure below is the same for the left and right ribbon drive motor assemblies.

1. Prepare the printer for maintenance (page 6-4).
2. Remove the ribbon.
3. Remove the ribbon hub (page 6-50).
4. Remove two screws and washers (page 6-77, Figure 6-11).
5. Lift the ribbon drive motor and its cable from base casting.
6. Disconnect the ribbon motor cable connector.
7. Remove the ferrite with clamp from the motor cable.

Installation

NOTE: The procedure below is the same for the left and right ribbon drive motor assemblies.

WARNING

You must install a ferrite core on the ribbon motor cable assembly. Refer to Appendix C. Make sure the ferrite core does not pinch the ribbon motor cable wires and take care not to damage the cable wires when inserting the motor into the base casting.

1. Install the ferrite with clamp to the motor cable.
2. Connect the ribbon motor cable connector and position the ribbon drive motor in the base casting (page 6-77, Figure 6-11).
3. Install the screws and washers to secure the front right and rear left corners of the ribbon drive motor assembly.
4. Install the ribbon hub (page 6-50).
5. Return the printer to normal operation (page 6-63).

Motor Assembly, Paper Feed

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the paper guide assembly (page 6-40).
4. Remove four screws and the barrier shield (page 6-75, Figure 6-10).
5. Remove the timing belt cover by squeezing the top and bottom to release the plastic tabs from the slots in the side plate (page 6-75, Figure 6-10).
6. Loosen the paper feed motor mount screws (page 6-87, Figure 6-16).
7. Loosen the set screw (page 6-87, Figure 6-16, item 10) and remove the paper feed motor pulley, shaft collar, and paper feed timing belt.
8. Disconnect the paper feed motor electrical connector.
9. Remove the motor mount bolts and nuts.
10. Remove the paper feed motor assembly.

Installation

1. Position the paper feed motor assembly on the right side plate and install the motor mount bolts and nuts finger tight (page 6-87, Figure 6-16).
2. Connect the paper feed motor electrical connector.
3. Install the collar, paper feed motor pulley, and timing belt.
4. Align the paper feed motor pulley with the splined shaft pulley.

IMPORTANT

Make sure there is at least 0.010 inches (0.25 mm) of clearance between the collar/pulley and the motor face plate.

5. Hold the collar snug against the motor pulley and torque the set screw:
If the pulley is black (aluminum), torque the set screw to
11 \pm 2 inch-pounds (1.24 \pm 0.23 N•m). If the pulley is silver (steel),
torque the set screw to 25 \pm 2 inch-pounds (2.82 \pm 0.23 N•m).
6. Using the straight end of a force gauge, apply 12 pounds (53.4 N) of pressure to the paper feed motor. Use the splined shaft to steady the gauge.

7. Reduce pressure to 9 pounds (40.0 N) and torque the motor mount screws to 18 ± 2 inch-pounds ($1.36 \pm 0.23 \text{ N}\cdot\text{m}$).
8. Snap the timing belt cover into the slots in the side plate.
9. Install the barrier shield and four screws (page 6-75, Figure 6-10).
10. Install the paper guide assembly (page 6-40).
11. Return the printer to normal operation (page 6-63).

Motor Assembly, Platen Open

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the card cage fan assembly (page 6-26).
3. Remove the platen open belt cover (1) by squeezing the top and bottom to release the plastic tabs from the slots in the side plate (page 6-85, Figure 6-15).
4. Loosen the motor mount screws (page 6-87, Figure 6-16).
5. Remove the platen open belt.
6. Loosen the 1/16 hex pulley set screw and remove the motor pulley.
7. Disconnect the platen motor cable connector.
8. Remove the motor mount screws and nuts.
9. Remove the platen open motor assembly.

Installation

1. Position the platen open motor assembly with wires toward the rear.
2. Install the motor mount screws and nuts finger tight (page 6-87, Figure 6-16).
3. Install the motor pulley, align it with the platen pulley, and tighten the set screw to 9 ± 2 inch-pounds ($1.24 \pm 0.23 \text{ N}\cdot\text{m}$).
4. Connect the platen motor cable connector.
5. Install the platen open belt.
6. Close the forms thickness lever all the way.
7. Make sure the collar of the platen pulley clears the left ribbon guide with the platen fully closed.
 - a. If not, loosen the platen pulley set screw, rotate the platen pulley until the collar clears the left ribbon guide and tighten the set screw. Go to step 8.

- b. If the collar clears the ribbon guide with the forms thickness lever closed, go to step 8.
8. Using a force gauge, apply 10 pounds (44.48 N) of tension to the platen open motor shaft by pulling away from the large platen pulley, reduce tension to 5 pounds (22.24 N) and torque the motor mount screws to 11 \pm 2 inch-pounds (1.24 \pm 0.23 N•m).
9. Check the platen gap (page 5-14), and adjust if necessary.
10. Snap the platen open belt cover into the slots in the side plate.
11. Install the card cage fan assembly (page 6-26).
12. Return the printer to normal operation (page 6-63).

Operator Panel Assembly

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the paper guide assembly (page 6-40).
4. Remove the controller board (page 6-14).
5. Remove the mechanism driver board (page 6-18).
6. Disconnect the operator panel connector P1 from connector J3 on the LP30 backplane. (See page 6-77, Figure 6-11, item 14.)
7. Remove the operator panel ribbon cable from the card cage.
8. Remove the operator panel ribbon cable from the wire saddles on the mechanism base pan.
9. Remove the ferrite cores from the ribbon cable. (Note the number of turns.)
10. Slide the blade of a flat tip screwdriver between the operator panel plate and the latch on the rear top of the operator panel. (See Figure 6-8, page 6-71.)
11. Press the latch and slide the operator panel down and off the operator panel bracket.

Installation

IMPORTANT

You must install two ferrite cores on the control panel cable assembly. Refer to Appendix C.

1. Feed ribbon connector and the ribbon cable through the control panel bracket. (See page 6-71, Figure 6-8.)
2. Position the control panel assembly on the bracket and slide it upwards to engage the latch.
3. Route the control panel ribbon cable along the right side of the printer.
4. Install the ferrite cores. (Refer to Appendix C.)
5. Feed the ribbon cable and ribbon connector through the slot in the card cage. Tie wrap the round ferrite core to the card cage.
6. Connect the control panel connector P1 to connector J3 on the LP30 backplane. (See page 6-77, Figure 6-11, item 14.)
7. Insert the control panel ribbon cable into the wire saddles on the mechanism base pan.
8. Install the mechanism driver board (page 6-18).
9. Install the controller board (page 6-14).
10. Install the paper guide assembly (page 6-40).
11. Return the printer to normal operation (page 6-63).

Paper Guide Assembly

DANGER

Unless directed to do otherwise, always unplug the printer from the power source before performing a maintenance procedure. Failure to remove power could result in injury to persons or damage to equipment.

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the paper guide assembly hold-down screw (page 6-75, Figure 6-10).
4. Slightly lift the right end and slide the paper guide assembly to the left. Lift the paper guide assembly off the card cage.

Installation

1. Position the paper guide assembly offset slightly to the left on the card cage (page 6-75, Figure 6-10).
2. While holding the right end slightly elevated, slide the paper guide assembly to the right and engage the tabs on the underside of the paper guide assembly with the left edge of the card cage.
3. Slide the paper guide assembly to the right as far as it will go.
4. Lower the right end of the paper guide assembly and install the hold-down screw.
5. Return the printer to normal operation (page 6-63).

Paper Ironer

CAUTION

Over time, the upper edge of the paper ironer can become sharp. To avoid cutting yourself, handle the paper ironer on the sides.

Removal

1. Remove the shuttle frame assembly (page 6-55).
2. Move the forms thickness lever to the open position.

NOTE: The black tape on the paper ironer faces the paper motion detector.

3. Push the ends of the paper ironer toward the rear of the printer. disengage the tabs, then lift it up and out (page 6-85, Figure 6-15).

Installation

NOTE: The black tape on the paper ironer faces the paper detector switch assembly.

1. Position the paper ironer so that the black tape is on the side that faces the paper detector switch assembly. (See page 6-85, Figure 6-15.)
2. Push the paper ironer down into the slots until the tabs engage.
3. Install the shuttle frame assembly (page 6-55).
4. Return the printer to normal operation (page 6-63).

Paper Stacker Assembly

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the floor cabinet rear door.
3. Remove the stacker rails from the stacker runner risers. (See Figure 6-7, page 6-69.)
4. If required, remove the stacker runner risers by removing the screw holding each riser to the cabinet.
5. Remove the stacker wire frame assembly and stacker rails.

Installation

1. If required, install the stacker runner risers using the screw to hold each to the cabinet.
2. Install the stacker rails in the loops on the stacker wire frame assembly.
3. Place the stacker assembly and stacker rails in position and snap the rails into the stacker runner risers. (See Figure 6-7, page 6-69.)
4. Return the printer to normal operation (page 6-63).

Platen

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the shuttle frame assembly (page 6-55).
3. Remove the paper ironer (page 6-41).
4. Remove the paper ironer bracket assembly (page 6-85, Figure 6-15).
5. Remove the platen open belt (page 6-6).
6. Remove the platen pulley (page 6-85, Figure 6-15):
 - a. Loosen the collar clamp screw.
 - b. Pull the platen pulley off the platen shaft.
7. Remove the left side platen support spring:
 - a. Disconnect the left platen support spring from the spring hook on the side plate.
 - b. Pull the spring link and left platen support spring off the platen shaft.
8. Remove the forms thickness lever by loosening the set and clamp screws and pulling the lever off the platen shaft. (The lever may be hard to remove due to adhesive applied during factory assembly.)
9. Remove the right side platen support spring by repeating step 7. on the right side of the platen.
10. Remove the forms thickness indicator plate:
 - a. Disconnect the platen interlock switch connector from the connector in the right side plate.
 - b. Remove the screws securing the indicator plate.
 - c. Pull the indicator plate, with the interlock switch assembly attached, off the platen shaft.
11. Rotate the right side of the platen toward the front of the printer and move the platen to the right and out of the left side plate.

Installation

IMPORTANT

The dowel pins protruding from the ends of the platen are the platen shafts, and are not equal in length. The platen must be installed with the longer shaft on the right side.

1. Install two washers on the longer platen shaft (page 6-85, Figure 6-15).
2. Apply bearing lubricant to both platen shafts and to the mating diameters of the platen adjustment brackets.
3. Install the platen adjustment brackets onto the platen shafts with the set screws at the top of the brackets.
4. Make sure the two wear saddles are set flush into the corners of the mechanism base platen seat.
5. Apply a layer of bearing lubricant 1/4 inch high to the seat of each wear saddle, making the layer as wide as the saddle and touching the rear angled surface.
6. Insert the shorter platen shaft through the opening in the left side plate. Rotate the shaft into the opening in the right side plate and position the adjustment brackets so the mechanism base platen seats are between the flanges of the brackets.
7. Install the forms thickness indicator plate:
 - a. Slide the indicator plate, with the interlock switch assembly attached, onto the platen shaft and up against the right side plate.
 - b. Install the washers and screws securing the indicator plate.
 - c. Connect the platen interlock switch connector to the connector in the right side plate.
8. Apply bearing lubricant to the two platen shafts at the following locations:
 - a. On the left side, between the end of the platen and the platen adjustment bracket.
 - b. On the right end, between the two washers.
9. Apply bearing lubricant to the nylon bearings in the two spring links, slide the spring links onto the two platen shafts, and connect the springs to the spring hooks in the side plates.

Installation (continued)

10. Install the paper ironer bracket:
 - a. With the flat piece of the bracket facing the front of the printer, place the two hooks of the upper piece over the platen shafts. The left hook goes between the left platen adjustment bracket and the platen. The right hook goes between the two washers to the left of the right platen adjustment bracket (page 6-85, Figure 6-15).
 - b. Install and torque three paper ironer bracket screws to 20 ± 2 inch-pounds ($2.26 \pm 0.23 \text{ N}\cdot\text{m}$).
11. Install the forms thickness lever onto the right side platen shaft. (See Figure 6-15, page 6-85.)
12. Adjust the platen angle (page 5-12).
13. Install the platen shaft pulley.
14. Loosen the set screw in the platen open motor pulley.

WARNING

To prevent breakage, be careful not to overtighten the set screw in step 15.

15. Align the platen open motor pulley with the platen shaft pulley and tighten the set screw to 9 ± 2 inch-pounds ($1.02 \pm 0.23 \text{ N}\cdot\text{m}$).
16. Install, but do not adjust, the platen open belt (page 6-6).
17. Install the paper ironer (page 6-41).
18. Install the shuttle frame assembly (page 6-55).
19. Adjust the platen gap (page 5-14).
20. Adjust the platen open belt (page 5-6).
21. Return the printer to normal operation (page 6-63).

PROMs and Modules on the Controller Board

WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit boards and components.

Removal

1. Make a configuration printout. (Refer to the *Setup Guide*.)
2. Prepare the printer for maintenance (page 6-4).
3. Remove the controller board (page 6-14).
4. Using a chip puller, carefully remove the defective or incorrect PROM(s). Locations are shown in Figure 6-4, page 6-47.
5. If there is optional memory on the controller board (IPDS models only), remove this memory using module extraction tool 75X5893.

Installation


WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit boards and components.

1. Using a chip installation tool, install PROM(s). Locations are shown in Figure 6-4, page 6-47.
2. Install the controller board (page 6-14).
3. If you are installing a new controller board, adjust hammer phasing (page 5-27).
4. Return the printer to normal operation (page 6-63).
5. Using the configuration printout you made as step 1 of the removal procedure, reset and save the printer configuration. (Refer to the *Setup Guide*.)

| Diskette and Security Module Cross Reference | | |
|--|----------------------|------------------------------------|
| Printer Features | Diskette Part Number | Security Module IBM P/N / OEM P/N* |
| Base Machine | 14H7256(Twinax) | 57G1752/152541-001 |
| | 30H3963(Coax) | 57G1752/152541-001 |
| IGP-200 | 14H7258(Twinax) | 57G1663/151605-001 |
| | 30H3965(Coax) | 57G1663/151605-001 |
| Code V | 14H7257(Twinax) | 57G1663/151605-001 |
| | 30H3964(Coax) | 57G1663/151605-001 |
| IPDS | 14H7253(Twinax) | 57G1684/152543-001 |
| | 57G1696(Coax) | 57G1684/152543-001 |
| IGP-200 + IPDS | 14H7254(Twinax) | 57G1706/152539-001 |
| Code V + IPDS | 14H7255(Twinax) | 57G1706/152539-001 |

*PAL at board location J4 is marked with manufacturer's part number.



There are two possible configurations for the controller board RFI shield.





Figure 6-4. PROMs and Modules on the Controller Board

PROMs and Chips on the Mechanism Driver Board

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the mechanism driver board (page 6-18).

WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit boards and components.

3. Using a chip puller, remove the defective chip(s). Locations are shown in Figure 6-5, page 6-49.

Installation

WARNING

To prevent electrostatic damage to electronic components, wear a properly grounded static wrist strap when handling circuit board and components.

1. Using a chip installation tool, install chip(s). Locations are shown in Figure 6-5, page 6-49.
2. Install the mechanism driver board (page 6-18).
3. Return the printer to normal operation (page 6-63).

PROM Kit: 57G1762




Figure 6-5. PROMs and Chips on the Mechanism Driver

Ribbon Hub

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the printer ribbon.
3. Loosen the screw in the ribbon spool hub (page 6-77, Figure 6-11).
4. Remove the hub from the shaft of the ribbon drive motor.

Installation

1. Install the ribbon spool hub over the motor shaft (page 6-77, Figure 6-11).
2. Tighten the hub screw so that it contacts the flat section of the motor shaft.
3. Return the printer to normal operation (page 6-63).

Ribbon Guide Assembly (L/R)

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the printer ribbon.
4. Cut the tie-wrap and remove it from the tie wrap hole to free the ribbon guide cable (page 6-87, Figure 6-16).

NOTE: The right ribbon guide is shown in Figure 6-16. The removal procedure is the same for the left ribbon guide.

5. Disconnect the ribbon guide connector.
6. Remove the two screws and washers securing the ribbon guide assembly to the side plate.
7. Slide the ribbon guide assembly out of the side plate.

Installation

1. Slide the ribbon guide assembly into the side plate (page 6-87, Figure 6-16).

NOTE: The right ribbon guide is shown in Figure 6-16. The installation procedure is the same for the left ribbon guide.

2. Install two screws and washers securing the ribbon guide assembly to the side plate.
3. Connect the ribbon guide connector.
4. Tie-wrap the cable to the tie wrap hole.
5. Align the ribbon guides (page 5-18).
6. Return the printer to normal operation (page 6-63).

Shaft, Splined

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the paper feed timing belt (page 6-5).
4. Remove the ground clip (page 6-83, Figure 6-14).
5. With grip ring pliers, remove the grip ring from the splined shaft.
6. Pull the bearing and spring link with the spring off the splined shaft.
7. Unlock the left and right tractors and slide them to the center.
8. Remove the bearing clamp.
9. Grasping the vertical adjustment knob, slide the splined shaft out of the left and right side plates and the tractors.

Installation

1. Open the doors on the left and right tractors. Position the tractor belts so the alignment marks are at the top on both tractors.
2. Grasp the vertical adjustment knob and slide the splined shaft through the right side plate, the tractors, and the left side plate (page 6-83, Figure 6-14). Make sure the same spline passes the marked groove on each tractor.
3. Install the bearing clamp and screw.
4. Apply a thin film of bearing lubricant to the bearing.
5. Slide the spring link and bearing onto the splined shaft.
6. Attach the spring to the left side plate and the spring link.
7. Install the grip ring on the splined shaft with 0.010 inches of clearance between the grip ring and the nylon bearing.
8. Install the ground clip and screw.
9. Install the paper feed timing belt (page 6-5).
10. Set the paper feed timing belt tension (page 5-4).
11. Adjust splined shaft skew (page 5-20.)
12. Return the printer to normal operation (page 6-63).

Shaft, Support

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Unlock the tractors and slide them to the far right.
4. Remove the E-ring (page 6-83, Figure 6-14).
5. Slide the support shaft assembly — consisting of the support shaft, two curved washers, bushing, horizontal adjustment knob, washer and screw — to the left, out of the tractors and the left side plate.

Installation

1. Slide the support shaft assembly — consisting of the support shaft, two curved washers, bushing, horizontal adjustment knob, washer, and screw — into the left side plate. (See page 6-83, Figure 6-14.)
2. Slide the tractors onto the support shaft.
3. Slide the support shaft assembly through the right side plate.
4. While pushing on the knob to compress the curved washers, install the E-ring in the groove on the bushing.
5. Return the printer to normal operation (page 6-63).

Shuttle Frame Assembly

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the shuttle cover assembly (page 6-23).
3. Disconnect the MPU cable connector (page 6-81, Figure 6-13).
4. Disconnect the shuttle motor cable connector.
5. Disconnect the shuttle cable assembly connector.

WARNING

The hammer bank flex circuit ribbon cables can tear if handled roughly. Do not pull on the cables; grasp the connectors to disconnect the flex circuit ribbon cables. In the next step, disconnect the left and right flex ribbon connectors gently, and do not bend the cables unnecessarily.

6. Disconnect the left and right hammer bank flex circuit ribbon connectors.
7. Loosen the side 5/32 inch socket head clamp screws and pull the clamps back and off the guide shaft. Do not remove the clamps.
8. Loosen the center 5/32 inch socket head screw enough to release the shuttle frame assembly from the base casting.
9. Unlock and slide the tractors outward as far as they will go on the tractor support shaft.
10. Grasping the outer beam standoffs, lift the shuttle frame assembly out of the base casting. Lift it slowly and carefully: the shuttle frame assembly is heavy.

Installation

1. Install the hammer bank cover (page 6-22), if it was removed.
2. Holding the shuttle frame assembly by the outer beam standoffs, set it into the base casting. Use both hands: the shuttle frame assembly is heavy (page 6-77, Figure 6-11).
3. Align the center 5/32 inch socket head screw in the base casting and hand turn the screw until only two or three threads have started.

4. Pull the shuttle frame assembly toward the front of the printer and hold it in this position while you do step 5.
5. Slide the side clamps over the guide shaft and torque the 5/32 inch socket head clamp screws to 20 \pm 2 inch-pounds (2.26 \pm 0.23 N•m).
6. Lift up on the shuttle motor, then gently set it down to align the center screw guide.
7. Torque the center captive 5/32 inch socket head screw to 20 \pm 2 inch-pounds (2.26 \pm 0.23 N•m).
8. Connect the left and right hammer bank flex circuit ribbon connectors.
9. Connect the shuttle cable assembly connector.
10. Connect the shuttle motor cable connector.

WARNING

Make sure the MPU cable is below the extension spring and does not touch the spring after the cable is connected.

11. Connect the MPU cable connector (1).
12. Loosen the platen open belt (page 5-6, steps 3. and 4.).
13. Adjust the platen gap (page 5-14).
14. Adjust the platen open belt (page 5-6).
15. Check the platen gap again. Readjust if necessary (page 5-14).
16. Install the shuttle cover assembly (page 6-23).
17. Return the printer to normal operation (page 6-63).

Spring Assembly, Gas

Removal

NOTE: Two persons may be required to perform this procedure. Prop or hold the printer cover securely while disengaging the gas spring assembly.

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Open the floor cabinet rear door.
4. Pry back the spring retaining clips (page 6-71, Figure 6-8).
5. Remove the gas spring assembly from the ball studs.

Installation

NOTE: Two persons may be required to perform this procedure. Prop or hold the printer cover securely while disengaging the gas spring assembly.

1. Position the gas spring assembly against the ball studs on the upper and lower brackets (page 6-71, Figure 6-8).
2. Push the gas spring assembly onto the ball joints.
3. Close the printer cover. If necessary, adjust the position of the ball joint stud in the lower bracket to achieve smooth and complete closure.
4. Return the printer to normal operation (page 6-63).

Spring, Extension

WARNING

Do not let the hammer bank rotate toward the platen during spring replacement.

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the shuttle cover assembly (page 6-23).
4. Unhook the extension spring from the spring lugs on the hammer bank and shuttle frame. (See Figure 6-13, page 6-81.)

Installation

1. Apply a dab of IBM #20 bearing lubricant to both spring lugs.

WARNING

Make sure the extension spring does not touch the MPU cable after installation.

2. Hook the extension spring over the spring lugs. (See Figure 6-13, page 6-81.)
3. Install the shuttle cover assembly (page 6-23).
4. Return the printer to normal operation (page 6-63).

Switch Assembly, Cover Open

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Remove the shuttle cover assembly (page 6-23).
4. Carefully lift and pry the cover open switch assembly out of the base casting (page 6-93, Figure 6-19).
5. Disconnect the switch connectors from intermediate cable assembly connector CO+ and CO-.

Installation

1. Connect the switch connectors to intermediate cable assembly connector CO+ and CO- (page 6-93, Figure 6-19).
2. Remove the protective covering from the adhesive backing on the cover open switch assembly.
3. Position the cover open switch assembly in the base casting and press it into place.
4. Install the shuttle cover assembly (page 6-23).
5. Return the printer to normal operation (page 6-63).

Switch Assembly, Paper Detector

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the paper guide assembly (page 6-40).
3. Remove four screws and the barrier shield (page 6-75, Figure 6-10).
4. Remove the screws securing the paper detector switch assembly (page 6-87, Figure 6-16).
5. Disconnect the paper detector switch cable connector from the intermediate cable assembly connector PMD.
6. Cut the tie wraps securing the switch assembly cable to the front of the card cage and remove the paper detector switch assembly.

Installation

1. Holding the slotted wheel against the PMD sensor, position the paper detector switch assembly and install the screws securing it to the printer base (page 6-87, Figure 6-16).
2. Connect the paper detector switch cable connector to the intermediate cable assembly connector PMD.
3. Install tie wraps securing the switch assembly cable to the front of the card cage.
4. Install the barrier shield and four screws (page 6-75, Figure 6-10).
5. Install the paper guide assembly (page 6-40).
6. Check and adjust the End of Forms Distance (page 5-22).
7. Return the printer to normal operation (page 6-63).

Switch Assembly, Platen Interlock

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Open the printer cover.
3. Disconnect the platen interlock switch connector from connector P1(P) (page 6-85, Figure 6-15).
4. Fully close the forms thickness lever (position 'A').
5. Remove two screws securing the platen interlock switch assembly.
6. Remove the platen interlock switch assembly from the forms thickness indicator plate.
7. Remove the connector from the right side plate.

Installation

1. Fully close the forms thickness lever (position 'A').
2. Position the platen interlock switch assembly on the forms thickness indicator plate (page 6-85, Figure 6-15).
3. Install two screws securing the platen interlock switch assembly.
4. Install the connector to the right side plate.
5. Connect the platen interlock switch connector to connector P1(P).
6. Return the printer to normal operation (page 6-63).

Tractor (L/R)

Removal

1. Prepare the printer for maintenance (page 6-4).
2. Remove the splined shaft (page 6-52).
3. Remove the support shaft (page 6-54).
4. Remove the tractors.

Installation

1. Using the replacement tractors, install the support shaft (page 6-54).
2. Install the splined shaft (page 6-53).
3. Return the printer to normal operation. (See page 6-63.)

Returning the Printer to Normal Operation

When you finish servicing the printer, restore it to operation by following the steps below:

1. Install the ribbon.
2. Plug the printer power cord into the printer.
3. Plug the printer power cord into the AC power outlet.
4. Set the printer power switch to 1 (on).
5. Load paper.
6. Close both cabinet doors and the printer top cover.
7. Test printer operation by selecting and running one of the operator print tests. (See Chapter 4.)
8. Select the printer emulation. (Refer to the *Operator's Guide*.)
9. Set the top-of-form. (Refer to the *Operator's Guide*.)

Section II: Illustrated Parts List

List of Figures

| | |
|---|------|
| Figure 6-6. Top Cover, Doors, and Casters | 6-67 |
| Figure 6-7. Stacker Assembly and Paper Chains | 6-69 |
| Figure 6-8. Control Panel and Cabinet Details | 6-71 |
| Figure 6-9. Floppy Diskette Drive | 6-73 |
| Figure 6-10. Covers | 6-75 |
| Figure 6-11. Print Mechanisms and Card Cage | 6-77 |
| Figure 6-13. Magnetic Pickup Unit (MPU) and Extension Spring .. | 6-81 |
| Figure 6-14. Tractor Shafts | 6-83 |
| Figure 6-15. Platen | 6-85 |
| Figure 6-16. Motors, Card Cage Fan, and Paper Detector Switch .. | 6-87 |
| Figure 6-17. Circuit Breaker and Line Filter | 6-89 |
| Figure 6-18. Cable Assembly W4, Hammer Bank | 6-91 |
| Figure 6-19. Cable Assembly W5, Intermediate, and Cover Open Switch Assembly | 6-93 |

| Item No. | Part Number | Description | Notes |
|----------|-------------|--------------------------------|---|
| | 57G1594 | 6408-CTA Ship Kit | |
| 1 | 57G1525 | Top Cover | Order a new IBM logo (item 17) |
| 2 | 30H3962 | Window, Top Cover | Part of item 1 |
| 3 | | Nut, Hex | 312-18 |
| 4 | | Washer, Split Lock | 5/16 |
| 5 | 57G1566 | Wireform Paper Path | |
| 6 | | Brush | Attaches to item 5 Not visible in Figure 6-6 |
| 7 | | Screw, w/Washer (6) | 10-24x.50 |
| 8 | 57G1489 | Rear Door Assy <i>30H4009</i> | Not visible in Figure 6-6 |
| 9 | 57G1488 | Front Door Assy <i>30H4008</i> | |
| 10 | 57G1484 | Door Hinge | Two on each door |
| 11 | | Screw, w/Lock Washer (16) | 10-24X.50 |
| 12 | Ref | Retaining Cable (2) | One at top of each door |
| 13 | | Screw, Hex w/Lock Washer (4) | 6-32x.375 |
| 14 | | Star Washer (4) | #6 |
| 15 | 57G1485 | Caster, with Brake | Two at front |
| 16 | 57G1486 | Caster, without Brake | Two at rear |
| 17 | 08H7926 | IBM Logo | |




Figure 6-6. Top Cover, Doors, and Casters

| Item No. | Part Number | Description | Notes |
|----------|-------------|---------------------------|-------------------------|
| 1 | 57G7176 | Stacker Assembly | |
| 2 | 30H3981 | Runner, Stacker | |
| 3 | 04H4779 | Riser, Stacker Runner | |
| 4 | | Screw (4) | 6-32x.375 |
| 5 | 08H7956 | Chain Assy, Stacker Inner | |
| 6 | 57G1564 | Chain Assy, Stacker Outer | |
| 7 | 08H7955 | Hanger, Chain Assy | Not shown in Figure 6-7 |
| 8 | 57G1582 | Label, Forms Length | |




Figure 6-7. Paper Stacker Tray Assembly and Paper Chains

| Item No. | Part Number | Description | Notes |
|----------|-------------|---|-------------------------------------|
| 1 | 57G1418 | Operator Panel Assembly | |
| 2 | 57G1598 | Operator Panel Overlay | English |
| | 57G1599 | | Spanish |
| | 57G1600 | <i>op r</i> | French |
| | 57G1601 | | Italian |
| | 57G1602 | | German |
| | 57G1603 | | Dutch |
| | 57G1604 | <i>57G7265- short up panel cable</i> | Brazilian / Portuguese |
| | 57G1573 | <i>op panel cable - long conn to 6730</i> | |
| 3 | 57G1526 | Operator Panel Plate | |
| 4 | | Screw, w/Lock Washer (4) | 6-32x.375 |
| 5 | 57G1441 | Panel Bracket | |
| 6 | | Nut, Hex (2) | .312-18 |
| 7 | | Washer (2) | Split Lock, 5/16 |
| 8 | 57G1481 | Gas Spring Assembly | Includes two spring retaining clips |
| 9 | 57G1483 | Ball Stud (2) | |
| 10 | | Screw, w/Washer (6) | 10-24x.50 |
| 11 | Ref | Service Panel | |
| 12 | 14H7231 | Multi I/O Cable Assembly | |
| | 42F1814 | Clip, Parallel Port | |
| 13 | | Screw, w/Lock Washer (4) | 10-24x.38 |
| 14 | 43F1678 | Fan Guard | |
| 15 | | Screw, w/Lock Washer (4) | 6-32x2.00 |
| 16 | 57G1440 | Fan Assembly | |




Figure 6-8. Control Panel and Cabinet Details

| Item No. | Part Number | Description | Notes |
|----------|-------------|---------------------------------|--|
| 1 | 57G1753 | Cable Assy, Floppy Power | |
| 2 | 57G1764 | Cable Assy, Floppy Data | |
| 3 | 57G1750 | Disk Drive, Floppy 3.5, 2.88MB | |
| 4 | 57G1765 | Disk Drive Bracket | |
| 5 | | Screw w/Lockwasher (4) | 6-32x.50. Not shown in Figure 6-9. Holds disk drive to the bracket. |
| 6 | | Screw, thread-forming (4) | 6-32x.3125 |
| 7 | 57G1751 | Diskette, Base Machine | Not shown in Figure 6-9. Security modules listed on page 6-47 and in Appendix I. |
| | 57G1664 | Diskette, IGP-200 | |
| | 57G1674 | Diskette, Code V | |
| | 57G1685 | Diskette, IPDS Twinax | |
| | 57G1696 | Diskette, IPDS Coax | |
| | 57G1705 | Diskette, IGP-200 + IPDS Twinax | |
| | 57G1713 | Diskette, IGP-200 + IPDS Coax | |
| | 57G1720 | Diskette, Code V + IPDS Twinax | |
| | 57G1727 | Diskette, Code V + IPDS Coax | |




Figure 6-9. Floppy Diskette Drive

| Item No. | Part Number | Description | Notes |
|----------|-------------|---------------------------|---|
| 1 | 57G1508 | Shuttle Cover Assembly | (Air Shroud Assembly) |
| 2 | | Screw, Captive (2) | 10-24x.62 with O-ring, .125x.250x.06 |
| 3 | | Screw, Thread forming (4) | 6-32x.25 |
| 4 | Ref | Barrier Shield | |
| 5 | 08H7954 | Static Brush | Part of item 4. |
| | 08H7950 | RH Bracket | Part of static brush assy. |
| | 08H7951 | LH Bracket | Part of static brush assy. |
| 6 | Ref | Screw (2) | Part of item 4 |
| 7 | 57G1568 | Paper Guide Assembly | |
| 8 | | Screw, Hex, w/Lock Washer | 6-32x.25, with #6 Flat Washer |
| 9 | 57G1512 | Timing Belt Cover | |
| 10 | 57G1468 | Paper Feed Timing Belt | |
| 11 | Ref | Magnet | Part of item 1 |




Figure 6-10. Covers

| Item No. | Part Number | Description | Notes |
|----------|-------------|------------------------------|---|
| 1 | 57G1477 | Hammer Bank Cover Assy | Hammer Spring Replacement Kit: 57G1475 |
| 2 | 57G1443 | Shuttle Frame Assembly | |
| 3 | 57G1456 | Cable Assy, AC/Ground | |
| 4 | 57G1437 | PCBA, Power Supply | |
| 5 | 57G1454 | CCB/Mech. Driver Cable Assy | Cable Assy W1 |
| 6 | 57G1464 | Hammer Bank Fan Assy | |
| 7 | 57G1577 | Ribbon Drive Motor (2) | |
| 8 | | Screw, Hex w/Lock Washer | 6-32x.50, two per motor |
| 9 | | Washer, Flat #6 | Two per motor |
| 10 | 57G1479 | Ribbon Spool Hub Kit | Kit includes 6-19x.50 set screw |
| 11 | 08H7828 | Cable Assy, +5V Power Supply | |
| 12 | 57G1446 | PCBA, Mechanism Driver | |
| 13 | 57G1768 | PCBA, Controller | |
| 14 | 57G1769 | PCBA, LP30 Backplane | |
| 15 | | Screw, Hex w/Lock Washer (2) | 6-32x1.25 |
| 16 | 57G3753 | PCBA Rail | Not shown in Figure 6-11. |
| 17 | | Screw, w/Hex Lock Washer (4) | 6-32x.50 |
| 18 | 14H5211 | SIDE CLAMP | |




Figure 6-12. Print Mechanisms and Card Cage Details

This page intentionally blank.

| Item No. | Part Number | Description | Notes |
|----------|-------------|----------------------------|----------|
| 1 | 57G1476 | Magnetic Pickup Assy (MPU) | 6-32x.38 |
| 2 | 57G1572 | Bracket, MPU | |
| 3 | | Screw, socket cap | |
| 4 | 30H3985 | Extension Spring | |




Figure 6-13. Magnetic Pickup Unit (MPU) and Extension Spring

| Item No. | Part Number | Description | Notes |
|----------|-------------|---------------------------|--|
| 1 | | Screw, Socket Cap | 4-40x.25 |
| 2 | | Washer | Flat #4 |
| 3 | 57G1517 | Knob, Tractor Adjust | |
| 4 | 57G1520 | Bushing, Tractor Adjust | |
| 5 | 57G1516 | Washer, Curved Spring (2) | |
| 6 | 0311072 | Ring, Grip | |
| 7 | 57G1510 | Bearing, Nylon .376 | |
| 8 | 57G1473 | Link Spring | |
| 9 | 57G1524 | Spring, Extension 1.00L | |
| 10 | | Screw, Hex w/Lock Washer | 4-20x.50 |
| 11 | 57G1521 | Clip, Grounding | |
| 12 | 57G1460 | Shaft Assy, Splined | Includes vertical adjust knob (splined shaft pulley) 57G1461 |
| 13 | | Screw, Thread Forming | 6-32x.25 |
| 14 | 57G1474 | Clamp, Bearing | |
| 15 | 57G1519 | Tractor Support Shaft | |
| 16 | 57G1466 | Tractor Set, L/R | |
| 17 | 0264641 | E-Ring | |
| 18 | 3044017 | Bushing | |




Figure 6-14. Tractor Shafts

| Item No. | Part Number | Description | Notes |
|----------|-------------|------------------------------|---|
| 1 | | Set Screw (2) | Part of item 2 |
| 2 | 57G1472 | Bracket, Platen (2) | |
| 3 | 57G1469 | Ironer, Paper | |
| 4 | | Screw, Thread Forming (3) | 6-32x.25 |
| 5 | 57G1571 | Bracket, Ironer | Ironer Bracket Assy includes item 7. |
| 6 | | Plate, Ironer | Part of item 6. |
| 7 | 08H7936 | Platen | |
| 8 | | Washer (2) | Flat #5/16 |
| 9 | | Screw (2) | 6-32x.250 |
| 10 | | Washer (2) | Flat #4 |
| 11 | 57G1451 | Platen Interlock Switch Assy | Mounting screws: two 2-32x.625 |
| 12 | | Screw, Socket Cap | 6-32x.75 |
| 13 | | Washer | #6 |
| 14 | | Nut | 6-32 |
| 15 | 57G3899 | Lever, Platen | Forms Thickness Lever |
| 16 | 57G1522 | Spring, Extension 1.12L (2) | |
| 17 | 57G1523 | Link, Spring (2) | |
| 18 | 57G1510 | Bearing, Nylon .376 | |
| 19 | 57G1518 | Bracket, Switch Mount | |
| 20 | Ref | Wear Saddle, Platen (2) | |
| 21 | 57G1514 | Pulley, Platen Open | Includes item 23 |
| 22 | | Screw, Socket Cap | 6-32x.44 |
| 23 | 57G1467 | Platen Open Belt | |
| 24 | 57G1513 | Cover, Platen Open | |




Figure 6-15. Platen

| Item No. | Part Number | Description | Notes |
|----------|--------------------|--|---|
| 1 | | Screw, w/Lock Washer (4) | 6-32x2.00 |
| 2 | 43F1678 | Fan Guard | |
| 3 | 57G1440 | Fan Assembly, Card Cage | |
| 4 | | Motor Pulley, Platen Open | Part of Platen Open Motor Assy (57G1509) and includes collar set screw 6-32x.25 |
| 5 | 57G1463 | Platen Open Motor | Platen Open Motor Assy (57G1509) includes items 4 and 5 |
| 6 | | Nut, Hex (2) | 10-32 |
| 7 | 57G1453 57G3889 | Paper Detector Switch Assy Paper Detector Switch Assy | Black back forms |
| 8 | | Screw, Thread Forming | 6-32x.375 |
| 9 | Ref | Card Cage | |
| 10 | | Nut, Hex (2) | 10-32 |
| 11 | 57G1463 | Paper Feed Motor | Paper Feed Motor Assy (155005-001) includes items 11-13 |
| 12 | | Set Screw | 6-32x.51 |
| 13 | 57G1507 | Collar | |
| 14 | 57G1421 | Motor Pulley, Paper Feed | 25 TOOTH |
| 15 | 57G1421 57G1190 | " " 24 TOOTH - NO MARRING - SHINY NO BUL SILVER | |
| 15 | | Screw, Hex w/Lock Washer (2) | 10-32x.50 |
| 16 | 57G1449 57G1450 | Ribbon Guide Assy, Left Ribbon Guide Assy, Right | |
| 17 | | Washer (2) | Flat #4 |
| 18 | | Screw, Hex w/Lock Washer (2) | 4-40x.38 |
| 19 | | Screw, Hex w/Lock Washer (2) | 10-32x.50 |




Figure 6-16. Motors, Card Cage Fan, and Paper Detector Switch

| Item No. | Part Number | Description | Notes |
|----------|-------------|--------------------------|--|
| 1 | | Screw, w/Washer (6) | 10-24x.50 |
| 2 | Ref | Service Panel | |
| 3 | Ref | Electrical Lead (4) | See detail in Figure 6-17 for attachment |
| 4 | | Spring Clip (4) | Part of item 5 |
| 5 | 57G1438 | Circuit Breaker | |
| 6 | | Screw, w/Lock Washer (3) | 6-32x.375 |
| 7 | 57G3752 | Line Filter | |




Figure 6-17. Circuit Breaker and Line Filter

| Item No. | Part Number | Description | Notes |
|----------|-------------|-----------------------------|-----------------------------|
| 1 | 57G1448 | Cable Assy, Hammer Bank (2) | |
| 2 | | Screw, w/Lock Washer (4) | 4-40x.75 and #4 Flat Washer |

Printer viewed from above, circuit boards removed.




Figure 6-18. Cable Assembly W4, Hammer Bank

| Item No. | Part Number | Description | Notes |
|----------|-------------|------------------------------|--------------------------------------|
| 1 | | Screw, w/Lock Washer (2) | 4-40x.75 and #4 Flat Washer |
| 2 | | Connector P1 | Part of item 10 |
| 3 | | Connector P1(P) | Part of item 10 |
| 4 | 57G1451 | Platen Interlock Switch Assy | |
| 5 | | Connector PMD(J) | Part of item 10 |
| 6 | | Connector PMD(P) | Part of Paper Detect Switch Assembly |
| 7 | 57G1465 | Cover Open Switch Assy | |
| 8 | | Connector CO+ | Part of item 10 |
| 9 | | Connector CO- | Part of item 10 |
| 10 | 57G1452 | Intermediate Cable Assy W5 | |

Printer viewed from above, circuit boards removed.




Figure 6-19. Cable Assembly W5, Intermediate, and Cover Open Switch Assembly

7

Principles of Operation

Contents

| | |
|---|------|
| Functional Elements of the Printer | 7-2 |
| Operator Panel | 7-4 |
| Controller Board | 7-5 |
| Controller Communication with Host Computer and Operator .. | 7-6 |
| Printing | 7-8 |
| Fault Monitoring | 7-11 |
| Security Interface | 7-11 |
| Hardware Summary | 7-12 |
| Mechanism Driver Board | 7-17 |
| Ribbon Drive System | 7-17 |
| Shuttle Drive System | 7-19 |
| Paper Feed System | 7-19 |
| Reverse Paper Feed System | 7-20 |
| Magnetic Pick-up Unit (MPU) | 7-20 |
| Power Supply Board | 7-21 |
| AC Power | 7-21 |
| DC Power | 7-21 |
| Printing Mechanism | 7-22 |
| Shuttle Frame Assembly | 7-22 |
| Paper Transport System | 7-26 |
| Ribbon Transport System | 7-27 |
| Printer Interface and the IGP | 7-28 |

Functional Elements of the Printer

The printer consists of five functional elements:

- ♦ Operator panel
- ♦ Controller board
- ♦ Mechanism driver board
- ♦ Power supply
- ♦ Print mechanisms

Figure 7-1 shows how these elements are interrelated.

The rest of this chapter discusses these systems in more detail.




Figure 7-1. Functional Elements of the 6408-CTA Printer

Operator Panel

The operator panel assembly is the user's interface with the printer. LED indicators, contact switches, and a liquid crystal display (LCD) are mounted on a printed circuit board enclosed in a protective housing.

The operator panel processes and sends key closure information to the controller board via the backplane board and displays status information from the controller on the LCD.




Figure 7-2. Operator Panel Functional Overview

Controller Board

The central element of the printer is the controller board, which controls and coordinates all printer functions.

The controller board functions as two units: the data processing unit (DPU) and the real-time processing unit (RTPU). The DPU converts all character data into printable dot images. The DPU is the high-level logical controller of the printer; it is not involved in real-time or hardware-dependent printer operation. The RTPU operates the printer (host) interface, the operator panel, the print mechanism, and monitors the fault circuitry in the mechanism.

The DPU and RTPU communicate by means of shared memory. The DPU gets host and operator input from buffers in memory which are filled by the RTPU, and returns dot images and operator messages to buffers in memory which the RTPU empties. Figure 7-3 summarizes the architecture of the controller board.




Figure 7-3. Architectural Overview of the Controller Board

Controller Communication with Host Computer and Operator

The controller board processes five kinds of computer input:

- ♦ PC parallel
- ♦ Dataproducts parallel
- ♦ RS-232 serial
- ♦ IBM 3270 protocol (also called "coax," because the signals are delivered over a coaxial line)
- ♦ IBM 5250 protocol (also called "twinax," because the signals are delivered over a twinaxial line)

The RTPU operates all interfaces. The PC and Dataproducts interfaces are similar, and the RTPU uses direct memory access (DMA) hardware to load parallel data directly into shared memory.

The serial interface requires byte-by-byte intervention by the processor, since ACK/NACK and XON/XOFF protocols require that every byte be examined as it is received. The universal asynchronous receiver/transmitter (UART) is internal to the RTPU, which processes any protocol requirements then puts the data in shared memory, where the DPU can read it.

IBM protocols are handled by the RTPU through a Bi-phase Communication Processor (BCP); the data are then placed in shared memory.

To the DPU, therefore, all input data look the same, regardless of the interface used to receive the data. The interface functions of the RTPU are summarized in Figure 7-4.




Figure 7-4. Host Interface Functions of the RTPU

Operator Panel

The printer communicates with the operator by means of the Liquid Crystal Display (LCD) and Light Emitting Diode (LED) indicators on the operator panel. The operator communicates with printer by pressing keys on the operator panel. (See Figure 7-2.)

Thus there are three kinds of operator panel operation: keystroke input, display output, and indicator output. The RTPU handles the operator panel interface requirements of shifting and clocking operator panel data, but it is the DPU that processes the data.

Floppy Disk Controller Module

The floppy disk controller module is part of the controller board; it controls the flow of DPU program data from a standard 3.5 inch floppy diskette to the DPU program memory. The DPU controls this floppy drive.

Printing

The RTPU coordinates printing of the dot images sent from the DPU. Printing is a complex process requiring many control functions, but is logically divided into two groups:

- ♦ Hammer driver interface functions
- ♦ Mechanical interface functions

Hammer Driver Interface

In order to print a dot image, two things must happen. First, the dots must get to the hammers one dot row at a time and in the correct sequence. Second, the hammers must fire at the appropriate time in the stroke of the shuttle. The RTPU processor controls both of these functions, but each is actually performed by an application-specific integrated circuit (ASIC) containing hardware dedicated to the function. These ASICs are the Dot Plucker Memory Controller (DPMC) and the Fire Timer IC (FTIC). The hammer driver interface functions of the RTPU are summarized in Figure 7-5.




Figure 7-5. Hammer Driver Interface Functions of the RTPU

Getting Dots to the Hammers Getting dots to the hammers consists of going into the shared memory and pulling bits out in a given order and shifting them to the hammer driver at the correct time. This process is called "dot plucking." The order in which dots are plucked from memory depends on the dot density, the number of dots per hammer, the number of hammers on the hammer bank, the number of phases, and other factors. These factors are all considered by the RTPU processor as it programs the dot plucker and the FTIC for each dot row.

Hammer Fire Control Hammer fire control consists of synchronizing the firing of different sections of the hammer bank with the position of the shuttle. This synchronization varies with the dot density, the number of dots per hammer, the number of hammers on the hammer bank, the number of phases, and so on. The Fire Timer IC (FTIC) performs this synchronization, but it is such a complex procedure that most synchronization factors are programmed into the fire timing tables which are transferred (by DMA) from EPROM to FTIC while printing. The FTIC's fire control responsibility is thus reduced to tracking the MPU pulses that tell shuttle position, timing hammer firing between MPU pulses, and sending a pattern to the hammer driver telling it which phases to fire.

Synchronizing Dot Plucking and Hammer Firing Transfer of dots to the hammer driver must be synchronized with hammer firing. Dots are transferred to the hammer driver in serial streams of dots that tell which hammers will print when their phase is next fired. These serial streams are called bursts. The bursts are timed precisely; they must occur neither too early nor too late. Synchronization is accomplished by having the FTIC request bursts from the dot plucker. The FTIC reads the magnetic pick-up unit (MPU) to determine when to request a burst. The time at which the burst request is made is contained in the fire timing tables.

Mechanical Interface

Three mechanical operations are coordinated in printing: paper motion, ribbon motion, and shuttle motion. Virtually all digital handling of paper motion is contained in the RTPU. The ribbon and shuttle are controlled by logic on the mechanism driver board, under the direction of the RTPU. Figure 7-6 shows the mechanical interface section of the RTPU.




Figure 7-6. Mechanism Driver Interface Functions of the RTPU

Paper Motion The DPU determines when to move the paper and how far to move it. It communicates this to the RTPU through the shared memory. The RTPU processor performs some paper handling operations (such as holdback on slews), but most paper handling is done by a dedicated micro-controller called the paper feed controller (PFC).

The PFC is part of the RTPU and moves paper by looking up motion profiles and driving a sequence of motor positions to the mechanism driver board. If the motion is a dot row or interline advance, it is synchronized to hammer firing by a signal from the FTIC that tell the PFC when to move.

Ribbon and Shuttle Motion The ribbon and shuttle motors are controlled by a micro-controller on the mechanism driver board called the ribbon and shuttle processor (RSP). The RTPU interface to the RSP is a 2400 baud asynchronous serial line. A message protocol is used to communicate ribbon and shuttle information.

Fault Monitoring

The RTPU also monitors the hammer driver, mechanism driver, and the electro-mechanical sensors for fault conditions. Fault conditions are reported to the DPU.

Hammer Bank and Hammer Driver Faults

The FTIC works with the hammer driver ASIC (on the mechanism driver board) to monitor hammer driver shorts, average upper driven phase current, and temperature conditions. The RTPU reads the FTIC registers to determine out-of-range conditions, and these are passed on to the DPU.

Paper Faults

Two kinds of paper faults can occur: paper out and paper jammed. Both of these conditions are monitored through optical sensors. The paper feed controller (PFC) watches the paper out and paper motion sensors and reports errors to the RTPU processor. The RTPU then forwards the information to the DPU.

Ribbon and Shuttle Faults

The ribbon and shuttle processor (RSP) on the mechanism driver board monitors fault conditions in the drive circuits and notifies the RTPU if it finds errors. The RTPU processor can also use the FTIC to measure time between magnetic pick-up (MPU) pulses, enabling it to monitor shuttle speed and thus detect some shuttle faults.

Security Interface

The controller board contains a programmable array logic (PAL) chip called the security module. This PAL stores a 3-bit security code that is read by system software when the printer is powered on. The stored 3-bit code is compared to a security code on the emulation diskette. The program instructions that read this security code and set the lock-out mechanism must be executed out of the boot PROM or the 68EC030 will crash. This is because the lock-out mechanism enables the use of the DRAM and disables the reading of the security PAL. Conversely, when the security lock-out is reset, the code bits may be read but the DRAM may not be accessed. Therefore, if the instruction that resets the lock-out is fetched from DRAM, the next instruction will not be accessible from DRAM.

Controller Board Hardware Summary

A Motorola 68EC030 microprocessor performs the DPU functions and a Zilog Z80180 or Z8S180 microprocessor (a "Z180") is the RTPU processor. An 8032 micro-controller serves as the paper feed controller (PFC), which is part of the RTPU.

Actual implementation of this hardware blurs the distinctions between the DPU and RTPU, since the 68EC030 has access to the parallel port and the real-time functions of the dot plucker, which are RTPU resources, while the Z80180 has access to the nonvolatile memory (NVRAM), which is a resource of the DPU. These possibilities exist because of efficiencies in the hardware design; software maintains the functional differences between the DPU and RTPU.

Figure 7-7 illustrates how the controller board implements this hardware, and shows the seven data buses on the controller board:

- ♦ Z8S180 local bus: an 8-bit data path
- ♦ Z8S180 local buffered I/O bus: an 8-bit data path
- ♦ 8032 local bus: an 8-bit data path
- ♦ Common or shared bus: 16-bit data path shared by the DPU and Z8S180, arbitrated cycle by cycle
- ♦ Floppy controller bus: 8-bit data path from floppy disk to buffer memory
- ♦ DPU local bus
- ♦ Dot Plucker DRAM bus




Figure 7-7. Hardware Implementation of the Controller Board

Communicating with the Host Computer

The Z8S180 processor runs both the parallel and serial interfaces.

Host Parallel Input Parallel inputs are nine bits wide, but the Z8S180 direct memory access (DMA) used to make the transfer is only eight bits. Transfer is achieved by having hardware shift the DMA addresses by one bit—effectively multiplying the address by two and changing the DMA's auto-increment from byte to word. Software adjusts the addresses provided to the DMA controller when it is programmed for sixteen bit DMA. This manipulation saves the cost of a separate sixteen bit DMA controller and eliminates the extra clock cycle that would be required if the Z8S180 eight bit DMA were used without this modification.

Host Serial Input Serial communication with the host is done with one of the Z180 processor's internal UARTs. Additional modem control lines are provided in the Z180's control/status register.

IBM Protocol Serial Input Coax and twinax communication is accomplished using a National 8344 Bi-phase Communications Processor (BCP). This is a reduced instruction set (RISC) processor optimized for data communications. The 8344 has external circuitry that conditions data inputs for the processor's analog front end. When data are captured by the 8344, it strips the actual character data from the bit stream and places the data in SRAM to which the 68EC030 (DPU) has access. Access to this memory is arbitrated by a Remote Interface Arbitration System (RIAS) built into the 8344.

Communicating With the Operator

Operator Panel The controller is designed to communicate with the operator panel through the Control Panel ASIC (CPIC), but also supports older discrete IC operator panels. The synchronous serial port in the Z8S180 shifts data in and out of the operator panel. The control register in the RTPU contains three other operator panel bits: one samples the key switches, one strobes the LCD, and one strobes an LED holding register.

Floppy Disk Controller Module The controller board has an on-board floppy disk control module overseen by the DPU.

Printing

Hammer Driver Interface Dot plucking is handled by the Dot Plucker ASIC (DPMC), which runs at 18.432 or 24.576 MHz using the RTPU input clock. The Z8S180 programs the dot plucker ASIC and the FTIC on every dot row, after which the FTIC uses a DMA request line to control the movement of tables from EPROM to FTIC. The second DMA controller in the Z8S180 performs this transfer.

Fire Timing The RTPU programs the FTIC on every shuttle stroke, after which the FTIC uses a DMA request line to control the movement of tables from EPROM to FTIC. The Z180 microprocessor's second DMA does the transfer. The FTIC is synchronized to the RTPU by using the Z180's output clock signal (PHI).

Mechanism Driver Interface The paper feed controller (PFC) directs all paper motion. During printing, it usually moves paper in response to a trigger from the FTIC, which synchronizes paper motion with shuttle motion. The Z8S180 programs the PFC 8032 through an eight bit parallel port between processors at the beginning of each dot row, telling the PFC how far to move when the trigger is received. The PFC sets up for the move, waits, then moves when the trigger occurs. The other method of starting paper motion is with a command passed through the inter-processor parallel port. This results in paper movement that begins immediately. Other paper commands and status signals are also passed between processors through this port.

Ribbon and Shuttle Motion The Z8S180 interfaces through its internal UART to the ribbon / shuttle processor (RSP) on the mechanism driver board. The Z8S180 begins all transactions on the serial interface, so there is a bit in the Z8S180 hardware status register that the RSP sets to tell the Z8S180 when it needs service. The Z8S180 polls this bit regularly; if it is true, the Z8S180 initiates service over the serial interface by asking the RSP what it needs.

Fault Monitoring

The Z180, the PFC 8032, and the RSP monitor different functions for faults. The Z180 looks for hammer driver faults, shuttle stalls, interlock switch openings, fan failure, and paper out. The PFC 8032 monitors the paper out and paper motion detectors. The RSP on the mechanism driver board watches for faults in the motor drive circuits. The PFC and RSP report errors to the Z180, which collates fault status and passes the information to the DPU.

Hammer Faults The Z8S180 and FTIC check the hammer driver and hammer bank for faults on every shuttle stroke. Faults are detected by circuits on the mechanism driver board and relayed to the controller.

Fault circuitry can detect rising temperatures in the coils. One coil is checked on every shuttle stroke; therefore, 49 shuttle strokes are required to check all coils. When the RTPU is notified of a fault, it sends a message to the 68EC030.

The mechanism driver board also continuously monitors for shorts in hammer driver circuits and cables. If it detects currents that can harm the hammer bank, the +48 volt power supply is shut down within 70 milliseconds by "crowbar" circuitry.

Paper Faults The PFC 8032 monitors paper faults and reports them to the Z180 through the eight bit parallel port they share. The PFC works with a friction wheel paper motion detector and a reflective (optical) paper out sensor. The sensors interface directly to the controller board, where analog circuits condition the sensor inputs.

Ribbon and Shuttle Faults The RSP monitors ribbon and shuttle faults and reports them to the Z180 over the serial interface.

Mechanism Driver Board

The mechanism driver board, acting on commands from the controller board, controls real-time operation of the electromechanical printer systems.

Functionally, nine subsystems comprise the mechanism driver board:

- ♦ An 8032 micro-controller that controls ribbon drive and communication with the controller.
- ♦ The interface to the power supply board.
- ♦ Pulse-width modulator (PWM) current mode / voltage mode full-bridge power amplifiers connected directly to the shuttle, ribbon, paper feed, and platen open motors. Current mode is used for the paper feed motor, voltage mode is used for the ribbon and shuttle motors.
- ♦ The paper feed drive accepts control codes from the paper feed controller (PFC) on the controller for each motor phase to vector-control the paper feed motor.
- ♦ The shuttle drive controller receives speed commands from the controller through the 8032 micro-controller and commands the speed of the three-phase DC shuttle motor.
- ♦ The ribbon drive controller, based around the 8032 micro-controller, receives speed commands from the controller board and drives two DC stepper motors, regulating the speed and tension of the ribbon and monitoring the end of ribbon sensors.
- ♦ For reverse paper feed, the RTPU commands the ribbon and shuttle processor (RSP) to open and close the platen with the platen open motor.
- ♦ Fault detection circuitry samples and senses heat sink temperature, ribbon speed, shuttle speed, hammer driver circuitry, hammer bank coil temperatures, power supply voltages, and fault communication with the controller.
- ♦ Circuitry that registers magnetic pick-up unit (MPU) output, processes it for the logic interface, and sends it to the controller for timing hammer fire.

Ribbon Drive System

The ribbon drive system is controlled by the 8032 micro-controller. The controller sends commands to the 8032 to start and stop the ribbon, set the ribbon speed, and apply slack or tension to the ribbon. The real-time control functions are done by the 8032, acting in accordance with firmware control

algorithms and look-up tables. The 8032 communicates with an ASIC to provide direct digital PWM drive signals for the ribbon motor PWM amplifier. The 8032 drives the ribbon motors through PWM generators in the mechanism driver integrated circuit (MDIC). Nearly all mechanical control functions are carried out through the MDIC ASIC. Digital input/output is done through latches connected to the 8032 I/O ports and MDIC. The ribbon stall error message is generated when the drag motor does not turn as expected. Ribbon faults are passed to the controller board.

Ribbon Velocity

One motor is driven; the other motor is not driven and applies tension to the ribbon through its drag circuitry. Ribbon velocity is controlled by means of a closed-loop system that first measures the speed of the two ribbon drive motors. The velocity of the driven motor is known, while the velocity of the tensioning motor is measured by converting the zero crossing of the back-EMF signal to a digital pulse signal. This signal is processed by the 8032 to determine the radius of the ribbon on the take-up reel. The processor monitors this information and adjusts the velocity of the driven motor to maintain constant linear speed. The roles of the two motors reverse at the end of ribbon travel, when a metallic strip crosses the ribbon guide of the emptying reel and closes a circuit that causes the RSP to reverse motor functions.

The four PWM amplifiers in the ribbon drive system are voltage mode (as opposed to current mode) to aid in system damping. The 8032 input to the PWM amplifiers maintains a constant voltage/frequency ratio at the motor. The ribbon drive is protected from over current.

Ribbon Tension

The 8032 processor regulates tension in three discrete steps by using information gathered by the zero-crossing circuitry and ribbon information. Tension is adjusted by controlling the load on the drag motor back EMF. This load generates drag torque on the ribbon hub that maintains tension.

Start / Stop Ribbon

The ribbon motors are started and stopped by a digital signal from the controller. When a stop signal is received, the ribbon is locked to maintain tension. If the controller sends a slack signal, the PWM amplifiers are tri-stated.

Shuttle Drive System

The shuttle drive system is an analog closed-loop speed controller that accepts commands from the controller through the 8032 micro-controller and MDIC ASIC. The controller writes a word to the 8032, which in turn writes a word to the MDIC. The MDIC generates a clock signal based on this word.

The clock signal from the MDIC is the reference input to a phase detector. The other input to the phase detector is a logical combination of the pulses from three Hall-effect sensors in the brushless three-phase DC shuttle motor. The Hall-effect sensors are mounted to the motor stator 120 electrical degrees phase-shifted from each other. The phase detector is both a phase and frequency detector. It operates as a frequency detector when out of lock, and as a phase detector when the loop is phase-locked. During shuttle start, the frequency error from the phase frequency detector drives the servo system towards phase lock. At approximately 85% of final speed, the servo integrator resets to prevent overshoot. When the correct speed is reached, the system is in phase lock with the MDIC clock signal.

The shuttle is protected from overspeed, over current, missing Hall-effect sensors, and out-of-sync Hall-effect sensors.

Paper Feed System

Dot row advance and slew tables are stored on the controller board. The paper feed drive circuit takes commands directly from the controller to control the two-phase DC paper feed stepper motor. A paper feed command is a digital word containing a value proportional to the desired current level in the paper feed motor, enabling the motor to be quarter-stepped. Two PWM current mode amplifiers, protected against overloads and short circuits, drive the paper feed motor. In order to maintain the position of the paper, it must be kept under tension. To do this, the controller keeps the paper feed motor energized whenever printer power is on. During a fault condition (platen open, paper jam, etc.), this "holding current" is reduced to 5% of its normal value.

Reverse Paper Feed System

In order to reverse paper motion, the printer must open the platen, move the paper backwards vertically, close the platen, and remove the slack in the paper. A platen open or close command is generated on the controller board and communicated to the RSP 8032 processor. The RSP generates control and step clock signals for the platen driver circuitry. The platen driver circuitry is connected to a stepper motor that drives the platen through a toothed belt. The platen motor is only energized during the open and close cycles. The platen driver is protected from overcurrent.

Magnetic Pick-up Unit (MPU)

The magnetic pick-up unit (MPU) is mounted next to the shuttle motor flywheel. It provides timing information to the hammer fire controller by way of the controller. The rotation of the flywheel generates a pulse signal in the MPU. The output frequency is 100 times the shaft frequency of the shuttle motor. The MPU pulse train has one missing pulse in every revolution of the motor for indexing. The incoming signal from the MPU is processed with a zero-crossing detecting circuit to produce a clean signal, compatible with system logic. The clean signal is then sent directly to the controller.

Power Supply Board

The power supply is contained on a printed circuit board mounted in the card cage. The power supply senses and adjusts to any commercial electrical system that provides AC mains potential in 50 or 60 Hertz systems.

The power supply converts alternating current (AC) input power to direct current (DC) power and sends it to the mechanism driver and controller backplane boards for distribution to logic and electromechanical circuits.

AC Power

The power supply operates on AC voltages ranging from 86 to 264 V. It can tolerate variations in frequency of 47 to 62 Hz. The power supply is designed to withstand an AC input overvoltage of 300 VAC for one second with no degradation of DC output voltage or damage to printer circuits.

DC Power

The power supply PCBA contains two DC power supply systems for the printer. The first is a + 5 V bus for logic. The second consists of + 48 V and + 9.5 V buses for the electromechanical sections of the printer (that is, all drive motors and the hammer bank).

The maximum total continuous average DC load is 346 W. The + 5 V supply has a separate return line. Both returns are tied together in a single-point ground.

There is an opto-isolated input on the power supply that will shut down and latch off the + 48 V and + 9.5 V supplies unless it is pulled up to 5V with a 1K Ω resistor. This resistor is mounted on the mech driver board and may be pulled down or disconnected by mech driver hardware, controller board software, or internal cable interlocks. The + 5 V output will remain stable for reporting and latching the fault condition. The return for this signal is the + 5 V return. In addition, this shutdown circuit discharges and latches the + 48 V down to a level lower than 15 V in less than 200 milliseconds and requires recycling of the circuit breaker (On/Off switch) to reset the latch.

The + 5 V power supply has its own inverter, separate from the + 48 V and + 9.5 V outputs.

Loss of + 48 V is seen by the RSP and reported as a fault.

Printing Mechanism

The printing mechanism consists of the shuttle frame assembly, the ribbon transport system, and the paper transport system.

Shuttle Frame Assembly

Dots are printed by 47 hammer springs. Seven comb-like assemblies called frets, each fret containing seven hammer springs, are mounted on the hammer bank. Using 49 hammers balances the magnetic field characteristics of the hammer bank, while design parameters determine the use of 47 hammers for printing. (The first and 49th hammers are broken off so they cannot print.) The frets mount to the hammer bank on alignment pins, eliminating the need for individual hammer alignment. Figure 7-8 shows the shuttle frame assembly.




Figure 7-8. Shuttle Frame Assembly

Each hammer spring is a stiff leaf spring with a cylindrical, tungsten carbide tip on the free end. (See Figure 7-9.) A permanent magnet runs the length of the hammer bank and acts on the hammer springs through individual pole pieces. The pole pieces magnetically attract and hold the free end of the hammer spring under tension. This is called the retracted state.




Figure 7-9. Hammer Springs and Hammer Bank (Detail)

Two electromagnetic coils are mounted behind each hammer and wound around each pole piece. The coils are normally de-energized. When hammer driver logic determines that the hammer must print a dot, a current pulse energizes the coils. The polarity of the resulting magnetic field opposes the field of the permanent magnet, canceling its effect and releasing the hammer. The hammer springs forward, strikes the ribbon and paper, and leaves a dot impression of the hammer tip on the paper.

The coil is de-energized and its field collapses while the hammer is in flight. After striking the ribbon and paper, the hammer rebounds and the permanent magnet recaptures it.

Every text character is stored in memory as a pattern of dots on a logical grid called the dot matrix. Printer logic divides every printable line into horizontal

dot rows. The hammer springs put dots at the required positions for the entire line by striking a moving ink ribbon and the paper.

When the shuttle reaches the end of a sweep, it reverses direction, the paper is advanced one dot row, and the hammer springs print the next row of dots as the shuttle sweeps in the opposite direction. After a line of characters is printed, hammer action stops and the paper advances to the first dot row of the next print line. (See Figure 7-10.)

The dot patterns of characters vary according to the character set and font the user selects. The number of dot rows allowed for line separation depends on the vertical line spacing the user selects.

Figure 7-11 shows how each individual hammer spring forms characters as the shuttle scans horizontally.





Figure 7-10. Standard Character Formation



* Even column dot centers within the printed character area and character space hammer positions are not illustrated in this diagram.

NOTE: ● = Hammer Released and Dot Printed
○ = Hammer Not Released; No Dot Printed

Figure 7-11. Action of One Hammer Spring in Text Printing

Paper Transport System

The paper transport system accepts continuous, fan-folded, edge-perforated paper from three to 16 inches wide and from one to six sheets thick.

Horizontal positioning is provided by the horizontal adjustment knob and two tractors. The tractors are laterally adjustable along the splined shaft and tractor support shaft. Each tractor engages paper perforations with six pins and locks in place with a friction lock. During printing, the tractors are driven by the splined shaft, which is belt-driven by the paper feed drive motor. The paper feed drive motor is a two-phase step motor controlled by the paper feed sections of the mechanism driver board and the paper feed controller on the common controller board.

Paper may be manually advanced with the vertical adjustment knob.




Figure 7-12. Paper Transport System

Ribbon Transport System

The printer ribbon winds and unwinds continuously on a pair of spools latched to hubs which are driven by the ribbon motors. The ribbon motors operate only while the hammer bank assembly is running. Ribbon motion reverses when the metal strip at either end of the ribbon crosses the left or right ribbon guide, completing a circuit that causes both motors to reverse direction.

Constant ribbon tension is maintained by controlling each motor with a drive or drag circuit. While the hammer bank assembly is in motion, one motor acts as a drive motor, pulling the ribbon against the resistance exerted by the other motor—the drag motor. This system maintains a constant motor speed and ribbon tension.




Figure 7-13. Ribbon Transport System

Printer Interface and the IGP

The printer interface is the point where the data line from the host computer plugs into the printer. The printer interface, which processes all signals and data to and from the host computer, consists of a printed circuit board assembly and cable connector(s) for the data line.

Parallel and Serial Interface

The IBM 6408-CTA printer is equipped with buffered PC parallel, Dataproducts parallel, EIA-232-D serial, and EIA-422-A interfaces mounted on a single interface plate. These interfaces accept data in the U.S. ASCII protocol.

Only one of these interfaces can be used at a time, and is selected via operator panel configuration. Only one parallel host computer can be connected at a time.

Coax / Twinax Interface

The coax/twinax interface connectors enable the printer to emulate IBM 5225 Models 1, 2, 3, and 4 and 4234 Model 2 printers. The printer can be attached directly to an IBM network. These interfaces are also selected via operator panel configuration.

IBM data and protocols are processed by the Bi-phase Communication Processor (BCP) on the controller board, then sent to shared memory.

Intelligent Graphics Processor (IGP)

The Intelligent Graphics Processor (IGP) is a graphics protocol included on the controller board.


Using a simple programming language, the user can create forms, bar codes, logos, expanded characters, and other graphics. The IGP enables the printer to print sideways, upside down, and make forms combining graphics, alphanumeric data, and bar codes, all in a single pass. Documents explaining configuration, operation, and programming are included with the printer.

A

Wire Data







NOTE: Acronyms and Signal mnemonics are defined in Appendix G.

| | |
|---|------|
| IBM 6408-CTA Interconnection Diagram | A-2 |
| IBM 6408-CTA Power Distribution Diagram | A-3 |
| Circuit Board Assemblies | A-4 |
| Controller, LP30-CT | A-4 |
| Backplane, LP30 | A-6 |
| Mechanism Driver | A-8 |
| Power Supply | A-11 |
| Cable Assemblies | A-13 |
| Multi I/O Cable Assembly | A-12 |
| W1, Cable Assembly, CCB / Mech. Dr. | A-13 |
| W2, Cable Assembly, +5 V, PSA, Power Supply | A-14 |
| W3, Cable Assembly, Hi Voltage | A-15 |
| W4, Cable Assembly, Hammer Bank | A-16 |
| W5, Cable Assembly, Intermediate | A-17 |
| W6, Wire Harness, Main | A-18 |
| W7, Cable Assembly, AC / Ground | A-20 |
| Cable Assembly, Floppy Power, Single | A-21 |
| Cable Assembly, Floppy Interface | A-22 |
| Cable Assembly, Twinax Auto-Termination | A-23 |
| Hammer Bank Wiring Diagram | A-24 |




[illegible]


Controller, LP30-CT
57G1768




Controller, LP30-CT
57G1768




RFI Fence Mounting Holes




**J2
Test Points**




**J1
Coax/Twinax I/O**






**P1
Accessory**




LP30 Backplane, V1
57G1769




J8
Controller Board





J2
Main Power




LP30 Backplane, V1
57G1769




J4
Multi I/O





J5
Floppy




J3
Operator Panel








Mechanism Driver 57G1446









Mechanism Driver 57G1446




Test Points: Mech. Driver

| | |
|------|-------------------|
| TP1 | PAPER B AMPLITUDE |
| TP2 | PAPER A AMPLITUDE |
| TP3 | PAPER B CURRENT |
| TP4 | PAPER A CURRENT |
| TP5 | N MPU PULSE |
| TP6 | VCC (+5V) |
| TP7 | GND (+5V RET) |
| TP8 | SHUT CLK |
| TP9 | SHUT SPEED |
| TP10 | SHUT ERR |
| TP11 | HALL CLK |
| TP12 | GND (PAPER FEED) |
| TP13 | N COIL TEST |
| TP14 | N SHORT |
| TP15 | GND (HAMMER PWR) |
| TP16 | COIL TEMP |
| TP17 | +58V |
| TP18 | N FAIL SAFE |
| TP19 | GND (SHUTTLE) |
| TP20 | PFM1 |
| TP21 | PFM2 |
| TP22 | PFM3 |
| TP23 | PFM4 |
| TP24 | +48V |
| TP25 | +9.5V |
| TP26 | +15V |
| TP27 | +42V |
| TP28 | N CROWBAR |
| TP29 | N MD RESET |
| TP30 | N FAULT |







Multi-I/O Assembly 14H7231




PC Parallel




Serial





(To J4 on Backplane)






| Cable No. | Part No. | Description |
|-----------|----------|-------------------------------|
| W1 | 57G1454 | Cable Assembly, CCB/Mech. Dr. |




| Cable No. | Part No. | Description |
|-----------|----------|---------------------------------------|
| W2 | 08H7828 | Cable Assembly, +5 V, Power Supply |




| Cable No. | Part No. | Description |
|-----------|----------|----------------------------|
| W3 | 57G1457 | Cable Assembly, Hi Voltage |

| WIRE TABLE | |
|-------------|-------------|
| HR(P)/HL(P) | HR(J)/HL(J) |
| PIN 1 | PIN 1 |
| PIN 2 | PIN 2 |
| PIN 3 | PIN 3 |
| PIN 4 | PIN 4 |
| PIN 5 | PIN 5 |
| PIN 6 | PIN 6 |
| PIN 7 | PIN 7 |
| PIN 8 | PIN 8 |
| PIN 9 | PIN 9 |
| PIN 10 | PIN 10 |
| PIN 11 | PIN 11 |
| PIN 12 | PIN 12 |
| PIN 13 | PIN 13 |
| PIN 14 | PIN 14 |
| PIN 15 | PIN 15 |
| PIN 16 | PIN 16 |
| PIN 17 | PIN 17 |
| PIN 18 | PIN 18 |
| PIN 19 | PIN 19 |
| PIN 20 | PIN 20 |
| PIN 21 | PIN 21 |
| PIN 22 | PIN 22 |
| PIN 23 | PIN 23 |
| PIN 24 | PIN 24 |
| PIN 25 | PIN 25 |
| PIN 26 | PIN 26 |
| PIN 27 | PIN 27 |
| PIN 28 | PIN 28 |
| PIN 29 | PIN 29 |
| PIN 30 | PIN 30 |
| PIN 31 | PIN 31 |
| PIN 32 | PIN 32 |
| PIN 33 | PIN 33 |
| PIN 34 | PIN 34 |
| PIN 35 | PIN 35 |
| PIN 36 | PIN 36 |
| PIN 37 | PIN 37 |
| PIN 38 | PIN 38 |
| PIN 39 | PIN 39 |
| PIN 40 | PIN 40 |
| PIN 41 | PIN 41 |
| PIN 42 | PIN 42 |
| PIN 43 | PIN 43 |
| PIN 44 | PIN 44 |
| PIN 45 | PIN 45 |
| PIN 46 | PIN 46 |
| PIN 47 | PIN 47 |
| PIN 48 | PIN 48 |
| PIN 49 | PIN 49 |
| PIN 50 | PIN 50 |



| Cable No. | Part No. | Description |
|-----------|----------|-----------------------------|
| W4 | 57G1448 | Cable Assembly, Hammer Bank |



| Cable No. | Part No. | Description |
|-----------|----------|--|
| W6 | 57G1447 | Wire Harness, Main (continued on next page) |

WIRE TABLE

| CONNECTOR | | | | | | | | | | | | | WIRE LENGTH (+/- .25") | MAIN HARNESS WIRE COLOR | MATE TO WIRE COLOR |
|-----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|---------------------------|----------------------------|-----------------------|
| M/H | PFM | RML | RMR | SHM | CCF | P17 | EXF | SHH | PLM | RGR | RBL | MPU | | | |
| 1 | 1 | | | | | | | | | | | | 7.37" | BLACK | BROWN |
| A | 3 | | | | | | | | | | | | 7.37" | BLACK | ORANGE |
| 2 | 2 | | | | | | | | | | | | 7.37" | BLACK | BLUE |
| B | 4 | | | | | | | | | | | | 7.37" | BLACK | BLACK |
| 3 | 5 | | | | | | | | | | | | 7.37" | BLACK | YELLOW |
| C | 7 | | | | | | | | | | | | 7.37" | BLACK | RED |
| 4 | 6 | | | | | | | | | | | | 7.37" | BLACK | WHITE |
| D | 8 | | | | | | | | | | | | 7.37" | BLACK | GREEN |
| 5 | | 5 | | | | | | | | | | | 32.00" | BLACK | YELLOW |
| E | | 7 | | | | | | | | | | | 32.00" | BLACK | RED |
| 6 | | 3 | | | | | | | | | | | 32.00" | BLACK | ORANGE |
| F | | 1 | | | | | | | | | | | 32.00" | BLACK | BROWN |
| 7 | | | 7 | | | | | | | | | | 19.50" | BLACK | RED |
| H | | | 5 | | | | | | | | | | 19.50" | BLACK | YELLOW |
| B | | | 3 | | | | | | | | | | 19.50" | BLACK | ORANGE |
| J | | | 1 | | | | | | | | | | 19.50" | BLACK | BROWN |
| 9 | | | | 2 | | | | | | | | | 30.00" | BLACK | BLACK |
| K | | | | 3 | | | | | | | | | 30.00" | BLACK | RED |
| 10 | | | | 1 | | | | | | | | | 30.00" | BLACK | BLUE |
| L | | | | | 2 | | | | | | | | 24.50" | BLACK | RED |
| 11 | | | | | 3 | | | | | | | | 24.50" | BLACK | BLACK |
| M | | | | | | 2 | | | | | | | 17.50" | BLACK | RED |
| 12 | | | | | | 1 | | | | | | | 17.50" | BLACK | BLACK |
| N | | | | | | | 2 | | | | | | 29.35" | BLACK | RED |
| 13 | | | | | | | 3 | | | | | | 29.35" | BLACK | BLACK |
| P | | | | | | | | 6 | | | | | 32.75" | BLACK | BLACK |
| 14 | | | | | | | | | 7 | | | | 24.50" | BLACK | RED |
| R | | | | | | | | | 5 | | | | 24.50" | BLACK | YELLOW |
| 15 | | | | | | | | | 3 | | | | 24.50" | BLACK | ORANGE |
| S | | | | | | | | | 1 | | | | 24.50" | BLACK | BROWN |
| 16 | | | | | | | | | | 2 | | | 10.50" | BLACK | BLACK |
| T | | | | | | | | | | | 2 | | 33.00" | BLACK | BLACK |
| 17 | | | | | | | | | | 3 | | | 10.50" | BLACK | BLACK |
| U | | | | | | | | | | | 3 | | 33.00" | BLACK | BLACK |
| 18 | | | | | | | | | | 1 | | | 10.50" | BLACK | BLACK |
| V | | | | | | | | | | | 1 | | 33.00" | BLACK | BLACK |
| 19 | | | | | | | | 5 | | | | | 32.75" | BLACK | BROWN |
| W | | | | | | | | 2 | | | | | 32.75" | BLACK | YELLOW |
| 20 | | | | | | | | 4 | | | | | 32.75" | BLACK | ORANGE |
| X | | | | | | | | 3 | | | | | 32.75" | BLACK | WHITE |
| 21 | | | | | | | | 1 | | | | | 32.75" | BLACK | PURPLE |
| Y | | | | | | | | | | | | N/C | 33.00" | DRAIN | |
| 22 | | | | | | | | | | | | 2 | 33.00" | RED | WHITE |
| Z | | | | | | | | | | | | 1 | 33.00" | BLACK | BLACK |

PIN
ASSIGNMENT

Cable No.



W6

Part No.



57G1447

Description


Wire Harness,
Main
(continued
from previous
page)




| Cable No. | Part No. | Description |
|-----------|----------|---------------------------|
| W7 | 57G1456 | Cable Assembly, AC/Ground |



| Part No. | Description |
|----------|--------------------------------------|
| 57G1753 | Cable Assembly, Floppy Power, Single |




| Part No. | Description |
|----------|----------------------------------|
| 57G1764 | Cable Assembly, Floppy Interface |



| Part No. | Description |
|----------|---|
| 38F8254 | Cable Assembly, Twinax Auto-Termination |

Hammer Bank Wiring Diagram



B Printer Specifications

Contents

| | |
|--|-----|
| Duty Cycle | B-2 |
| Ribbon Specifications | B-2 |
| Paper Specifications | B-3 |
| Paper | B-3 |
| Labels | B-3 |
| Printer Dimensions | B-3 |
| Environmental Characteristics | B-4 |
| Temperature | B-4 |
| Relative Humidity | B-4 |
| Acoustic Noise Level | B-4 |
| Electrical Characteristics | B-4 |
| Input Power | B-4 |
| Power Rating | B-4 |
| Radio Frequency Interference (RFI) | B-5 |
| Interfaces | B-5 |
| Printing Rates | B-6 |

Duty Cycle

The IBM 6408 printer will print 75, 000 pages per month under the following conditions:

- ♦ Uppercase only
- ♦ 6 lines/inch
- ♦ 10 characters/inch
- ♦ 63% character density or 83 characters per line
- ♦ 63% line density or 42 lines/11-inch page
- ♦ Single part (18 lb) paper
- ♦ Printer is installed in accordance with the *Setup Guide*
- ♦ Printer is maintained in accordance with this maintenance information manual

Ribbon Specifications

NOTE: Use only the ribbons listed below:

IBM General Purpose Ribbon Part No. 1040990

IBM High Contrast Ribbon Part No. 1040993

Call IBM Direct to order ribbons:

1-800-IBM-2468 (USA)

1-800-465-1234 ext. 478 (Canada)

Paper Specifications

Paper

| | |
|------------------|--|
| Type: | Edge-perforated, fan-fold, 3 to 16 inches (7.62 to 40.64 cm) wide, 1 to 12 inches (2.54 to 30.48 cm) long |
| Thickness: | Single-part: 15 to 100 pound (6.80 to 45.36 kg) stock; Multi-part: 1- to 6-part forms (maximum 12 lb [5.44 kg] ply of upper plies) |
| Sheet Thickness: | 0.025 inch (0.0635 cm) maximum |
| Drive: | Adjustable tractors (6-pin engagement) |
| Slew Rate: | 16 in/sec (40.64 cm/sec) maximum |

Labels

| | |
|-------------|---|
| On Backing: | One-part continuous perforated fanfold back form. Labels must be placed at least 1/6 inch (0.42 cm) from the fan-fold perforation. Backing adhesive must not be squeezed out during printing. |
| Sheet Size: | 3 to 16 inches (7.62 to 40.64 cm) wide, including the two standard perforated tractor feed strips. A maximum sheet length of 12 inches (30.48 cm) between top and bottom perforations. |
| Thickness: | Not to exceed 0.025 inch (0.064 cm) (including backing sheet) |

Printer Dimensions

| | |
|---------|---------------------------------|
| Height: | 41 inches (104.1 cm) |
| Width: | 27 inches (68.6 cm) |
| Depth: | 29 inches (73.7 cm) |
| Weight: | 190 pounds (86.2 kg) (Unpacked) |

Environmental Characteristics

Temperature

Operating 41° to 104° F (5° to 40° C) up to 5000 feet (1524 meters)
41° to 90° F (5° to 32° C) up to 8000 feet (2438 meters)

Storage -40° to 158° F (-40° to 70° C)

Relative Humidity

Operating 10% to 90% (noncondensing)

Storage 5% to 95% (noncondensing)

Acoustic Noise Level

52 dBA (tested per ISO 7779)

Electrical Characteristics

Input Power

Voltage (RMS) 120 VAC or 230 VAC
(100 to 120 VAC or 200 to 240 VAC)

Phase Single

Frequency 47 to 62 Hz

Max RMS Current 6A @ 100 V; 3A @ 200 V

Power Rating

| 120 VAC 60 Hz | Operating (DP Mode) | | Standby |
|------------------|---------------------|--------------|---------|
| | All H's | Max. Typical | |
| Watts | 340 | 260 | 135 |
| BTU per hour | 1160 | 890 | 460 |
| VA | 535 | 400 | 200 |

| 220 VAC 50 Hz | Operating (DP Mode) | | Standby |
|------------------|---------------------|--------------|---------|
| | All H's | Max. Typical | |
| Watts | 320 | 275 | 130 |
| BTU per hour | 1090 | 940 | 445 |
| VA | 545 | 445 | 220 |

Radio Frequency Interference (RFI)

Radio Frequency Interference tested/certified to RFI standards FCC Part 15, Subpart B, Class A; VDE 0871 Class B; CSA C108.8-M1983 Class A.

Interfaces

| | |
|-----------------|---|
| Type: | Two resident parallel, two resident serial, one resident coax, one resident twinax |
| Logic Levels: | TTL/EIA-232-D |
| Data Format: | ASCII EBCDIC |
| Compatibility: | PC Parallel, DataProducts, EIA-232-D, EIA-422-A, Twinax, Coax |
| Transfer Rates: | Up to 200K bytes on parallel interfaces Up to 19,200 baud on serial interface |

Printing Rates

Printing speed of text is measured in lines/minute, and is a function of the selected font and dot density. Printing speed is independent of the number of characters configured in the character set repertoire. Print rates for lines containing attributes such as bold or emphasized printing, superscripts, subscripts, or elongated attributes will decrease to not less than half the rates of the font without such attributes. Typical printing rates are charted in Table B-1.

Plotting speed of graphics is measured in inches/minute, and is calculated as follows:

$$\frac{1}{\text{Shuttle Speed} \times \text{Vertical Density}} \times 60\,000 = \text{Plot Speed in } \frac{\text{inches}}{\text{minute}}$$

To prevent damage from overheating when graphics plotting is done over extended periods, the hammer bank contains a thermal sensing feature that automatically reduces the print rate.

Table B-1. Nominal Printing Rates

| Print Dimensions | | | Performance | | |
|--------------------------------------|--------------------------------|--|------------------------|--------------------------------|-------------------------------------|
| Dot Density (DPI) <i>NOTE 1</i> | Characters per Inch (CPI) | Dot Matrix <i>NOTE 2</i> | Uppercase Only LPM* | Descenders & Underline LPM* | Plot Mode <i>NOTE 3</i> IPM** |
| OCR A and B 120 (120) X 144 | 10 | 10 (10) X 14 + 2 | 165 | 145 | 33 |
| Near Letter Quality 90 (180) X 96 | 10 12 12.9 15 16.4 | 7 (13) X 9 + 3 6 (11) X 9 + 3 6 (11) X 9 + 3 5 (9) X 9 + 3 5 (9) X 9 + 3 | 320 | 245 | 33 |
| DP Quality 60 (120) X 72 | 10 12 13.3 15 17.1 | 5 (9) X 7 + 2 4 (7) X 7 + 2 4 (7) X 7 + 2 3 (5) X 7 + 2 3 (5) X 7 + 2 | 600 | 480 | 66 |
| Draft Quality 60 (120) X 48 | 10 12 13.3 15 17.1 | 5 (9) X 5 + 1 4 (7) X 5 + 1 4 (7) X 5 + 1 3 (5) X 5 + 1 3 (5) X 5 + 1 | 800 | 685 | 100 |
| NLQ Sans Serif 90 (180) X 96 | 10 12 12.9 15 16.4 | 7 (13) X 9 + 3 6 (11) X 9 + 3 6 (11) X 9 + 3 5 (9) X 9 + 3 5 (9) X 9 + 3 | 320 | 245 | 33 |

NOTE 1 A (B) X C, where: A is maximum horizontal dot density
B is horizontal placement resolution
C is vertical dot density

NOTE 2 D (E) X F + G, where: D is maximum number of dots that may be placed on
E horizontal dot positions
F is number of vertical dots for uppercase symbols
G is number of dots available for descenders

NOTE 3 The Plot Mode graphics described here are provided for IGP or Code V emulations. Plot speeds are obtained if the dot count per row does not exceed 85% of the maximum dots allowed for that mode, and the steps per dot row do not exceed the vertical density of that mode.

* LPM = Lines Per Minute

** IPM = Inches Per Minute

C

Ferrite Noise Suppression Cores

IMPORTANT

Before removing a cable that passes through or around a shielding bead (cylindrical ferrite core), count the number of times the cable is wound around the bead. You must duplicate these windings when you replace the cable. Use Figure C-1 as your guide.

Ferrite cores reduce radio frequency interference (RFI) to and from electronic equipment located near the printer.

The IBM 6408-CTA printer is equipped with two kinds of ferrite core:

- ♦ Shielding beads are round cores that resemble large iron washers. Cables pass through a shielding bead or are wound around it.
- ♦ Ferrites with clamp are rectangular in section, split down the center and the halves are housed in a hinged plastic case. Cables are folded into a groove cut into the center of the core, and the plastic case is closed, securing the core to the cable.

Figure C-1 shows the location of the ferrite cores.




Figure C-1. Ferrite Core Locations

D

Metric Conversion Tables

Length

| Multiply | By | To Obtain |
|--------------------|-------------|-----------------|
| foot | 0.3048* | meter (m) |
| foot | 30.48* | centimeter (cm) |
| foot | 304.8* | millimeter (mm) |
| inch | 0.0254* | meter (m) |
| inch | 2.54* | centimeter (cm) |
| inch | 25.4* | millimeter (mm) |
| meter | 3.280840 | foot |
| centimeter | 0.03280840 | foot |
| millimeter | 0.003280840 | foot |
| meter | 39.37008 | inch |
| centimeter | 0.3937008 | inch |
| millimeter | 0.03937008 | inch |
| * Figure is exact. | | |

Torque and Force

| Multiply | By | To Obtain |
|--------------------|---------|--------------------|
| pound-inch | 0.11298 | Newton-meter (N•m) |
| pound-foot | 1.3558 | Newton-meter (N•m) |
| Newton-meter (N•m) | 8.8511 | pound-inch |
| Newton-meter (N•m) | 0.7376 | pound-foot |
| pound | 4.4482 | Newton (N) |
| Newton (N) | 0.22481 | pound |

Mass and Density

| Multiply | By | To Obtain |
|----------|---------------|---------------|
| pound* | 0.4535924 | kilogram (kg) |
| ounce* | 28.34952 | gram (g) |
| kilogram | 2.204622 | pound* |
| gram | 0.03527397 | ounce* |
| | * avoirdupois | |

Temperature

| To Convert From | To | Use Formula |
|----------------------------------|----------------------------------|------------------------|
| temperature Celsius (t_C) | temperature Fahrenheit (t_F) | $t_F = 1.8t_C + 32$ |
| temperature Fahrenheit (t_F) | temperature Celsius (t_C) | $t_C = (t_F - 32)/1.8$ |

Power

| Multiply | By | To Obtain |
|--------------------------------|-------------|--------------------------------|
| Btu (International Table)/hour | 0.2930711 | watt (W) |
| watt (W) | 3.412141 | Btu (International Table)/hour |
| watt (W) | 0.001359621 | horsepower (metric) |
| horsepower (metric) | 735.499 | watt (W) |



Torque Table

The table below establishes the torque requirements for routine installation of threaded fasteners. These requirements apply to fasteners made of steel, at a minimum engagement of 3.5 threads, including chamfer and countersink. Fastener sizes are listed as Numbered Size – Threads Per Inch.

Torque Table

| Carbon Steel Fasteners (ANSI B18.6.3 – 1972) | | | | |
|--|--|--|--------------------------------------|--|
| Fastener Size | Into Alum. or Brass 25,000 psi ultimate tensile strength | Into Steel 60,000 psi ultimate tensile strength | Into Weld/Press Studs or Nuts | Into Medium Carbon Steel Fasteners 105,000 psi ultimate tensile strength |
| 2–56 | 25 ±2 in oz | 36 ±2 in oz | 30 ±2 in oz | — |
| 4–40 | 62 ±4 in oz | 75 ±5 in oz | 70 ±5 in oz | — |
| 6–32 | 122 ±7 in oz | 150 ±10 in oz | 135 ±10 in oz | — |
| 8–32 | 11 ±1 in lb | 18 ±1 in lb | 18 ±1 in lb | — |
| 10–24 | 20 ±1 in lb | 25 ±1.5 in lb | 21 ±1 in lb | — |
| 10–32 | 15 ±1 in lb | 29 ±2 in lb | 29 ±1 in lb | — |
| 1/4 – 20 | 40 ±3 in lb | 62 ±4 in lb | 62 ±4 in lb | 105 ±5 in lb |
| Fastener Size | | Torque for Routine Tightening of Threaded Fasteners | | |
| 4–40 UNC & 4–48 UNF | | 4 ±1 in lb | | |
| 6–32 UNC & 6–40 UNF | | 11 ±1 in lb | | |
| 8–32 UNC & 8–36 UNF | | 19 ±1 in lb | | |
| 10–24 UNC & 10–32 UNF | | 25 ±1 in lb | | |

F

Safety Inspection Guide

| | |
|---|-----|
| Safety Inspections | F-2 |
| Preparation | F-2 |
| Prepare the Printer for Inspection | F-3 |
| Inspect Mechanical Parts | F-3 |
| Top Cover and Doors | F-3 |
| Print Mechanism | F-4 |
| Inspect Electrical Parts | F-5 |
| Safety Ground Path | F-5 |
| Customer Power Source Service Check | F-7 |
| Power Cable | F-7 |
| Power On/Off Verification | F-8 |
| Print Interlock Service Check | F-8 |

Safety Inspections

The IBM 6408-CTA printer incorporates safety items installed to protect customers, operators, and service personnel from injury. Use this inspection guide as an aid in identifying possible unsafe conditions in the printer.

Perform the inspection steps outlined in this guide before the normal inspection for Maintenance Agreement Qualification, or any time you are instructed to make a safety inspection.

If you find any unsafe conditions, determine the severity of the hazard and whether or not you can continue the inspection without first correcting the problem.

NOTE: The correction of any unsafe condition is the customer's responsibility.

Preparation

You must have completed the "Electrical Safety Training Course for IBM Customer Engineers" (self-study course 77170 or existing level) to do the Safety Inspection.

Have the following items available:

1. *Electrical Safety for IBM Customer Engineers*, Order No. S229-8124.
2. A Fluke** meter (P/N 8496278) or similar device for resistance and voltage measurements.
3. An ECOS** Electrical Safety Tester (P/N 6339695) in the United States or a similar safety tester in other countries.

For each safety check on the following pages, do the steps in the order presented. Do not omit any steps.

Prepare the Printer for Inspection

DANGER

Always disconnect the AC power cord from the power source before performing any maintenance procedure. Failure to remove power could result in injury to persons or damage to equipment. If you must apply power during maintenance, you will be instructed to so in the maintenance procedure.

1. Have the operator take the printer off-line.
2. Power off the printer.
3. Unplug the printer power cord from the customer's power outlet.

Inspect Mechanical Parts

Top Cover and Doors

1. Inspect the top cover:
 - a. Open the top cover. Make sure the gas spring assembly holds the cover up in the open position.
 - b. Close the top cover. Make sure the operator panel is centered in the opening of the cover.
 - c. Make sure the window is not cracked or broken.
 - d. Make sure the seal around the top cover is not cracked or broken.
 - e. Make sure the electrostatic discharge (ESD) fingers are not loose or damaged. Make sure they touch the contact strips on the frame when the cover is closed.
 - f. Make sure there are no exposed or sharp edges.
 - g. Make sure the wireform paper path is undamaged.
2. Inspect the front and rear cabinet doors:
 - a. Make sure the seals and magnetic strips are not loose or damaged.

- b. Make sure the restraining cable is attached and unbroken.
 - c. Make sure there are no exposed or sharp edges.
- 3. Open the rear cabinet door and inspect the lower rear paper path:
 - a. Make sure the service panel permitting access to the I/O plate and circuit breaker (on/off switch) is installed.
 - b. Make sure the paper stacker tray assembly is in place and undamaged.

Print Mechanism


- 1. Open the printer top cover.
- 2. Make sure the shuttle cover is correctly installed and undamaged. (See page NO TAG.)
- 3. Make sure the paper path is correctly installed and undamaged. (See page NO TAG.)

Inspect Electrical Parts

Safety Ground Path

NOTE: Ground paths are summarized in Figure F-1.

1. Make sure the printer power cord is unplugged.
2. Remove the paper stacker tray assembly (page NO TAG).
3. Remove six screws and the service panel. (Refer to NO TAG, page NO TAG.)
4. Make sure the yellow/green cables from the line filter and circuit breaker power leads are undamaged and firmly attached to the ground lug on the floor of cabinet, as shown below.



5. Set a Fluke meter (P/N 8496278) or similar device to the lowest resistance scale. Measure the resistance between the power cable ground pin and the printer frame: safety ground circuits should measure 0.1 Ohm or less.
6. Install the service panel. (Refer to NO TAG, page NO TAG.)
7. Install the paper stacker tray assembly (page NO TAG).




Figure F-1. Ground Path Diagram

Customer Power Source Service Check

Use an ECOS Electrical Safety Tester (P/N 6339695) in the United States or a similar safety tester in other countries.

NOTE: The ECOS tester will trip ground fault detector protected outlets. This is a good test of the ground fault detector. Reset the outlet as needed.

Plug the ECOS meter into the customer's outlet. Follow the instructions supplied with the meter to test for the following:

1. Wiring errors
2. Low voltage
3. Neutral to ground short
4. Ground path impedance
5. Neutral impedance

NOTE: The customer is responsible for correcting problems with the power source. Inform the IBM Installation Planning Representative (IPR) of any problems with the customer's power source.

Each branch circuit must be grounded for safety and correct operation of the printer. This ground must be connected either to the electrical service ground or to a suitable building ground. The printer power cable has a green or green/yellow insulated grounding conductor. This is *not* a neutral.

Power Cable

1. Make sure the power cable is not damaged.
2. Make sure the power plug is the correct type.

Power On/Off Verification

1. Make sure all covers are installed.
2. Plug the power cable into the customer's power outlet.
3. Power on the printer and watch the LCD.
4. Verify that the power-on diagnostic tests and initialization routines are successful.
5. After successful initialization, the printer should cycle automatically to either the READY or NOT READY mode, depending on which power-on state was selected when the printer was configured.
6. Power off the printer. Verify that the LCD goes completely blank and all fans stop.

Print Interlock Service Check

1. Power on the printer.
2. Open the printer top cover.
3. Open the forms thickness lever.
The LCD should display a CLOSE PLATEN message and the audible alarm should sound if it is enabled.
4. Press **Stop**. The audible alarm should stop.
5. Close the forms thickness lever. The fault message should clear.
6. Loosen the shuttle cover screws and lift the shuttle cover enough to pull the magnet away from the cover open switch.
The LCD should display 090 CLOSE SHUTTLE COVER and the audible alarm should sound if it is enabled.
7. Press **Stop**. The audible alarm should stop.
8. Reseat the shuttle cover and tighten the cover screws. The fault message should clear.



Acronyms and Signal Mnemonics

NOTE: Mnemonics with initial letter "N" are negative true.

| ACRONYM/ MNEMONIC | DEFINITION |
|----------------------|---|
| AC | Alternating Current |
| ACK | Acknowledge |
| AMP | Amplitude; Ampere |
| AN | Anode |
| ASIC | Application-Specific Integrated Circuit |
| ATTN | Attention |
| | |
| B | Buffered |
| BCOM | Buffered Communication |
| BCP | Bi-phase Communications Processor |
| BHSC | Buffered Hammer Shift Clock |
| BN | Buffered, Low True |
| BNLD | Buffered, Low True, Lower Driver |
| BPS | Bits Per Second |
| BUD | Buffered Upper Driver |
| | |
| CA | Cathode |
| CC | Card Cage |
| CCB | Common Controller Board |
| CCF | Card Cage Fan |
| CE | Customer Engineer |
| CHNG | Change |
| CLK | Clock |

| | |
|--------------|--|
| CO | Cover Open |
| COLL | Collector |
| CONTLR | Controller |
| CPI | Characters Per Inch |
| CTS | Clear to Send |
| CUR | current |
| DC | Direct Current |
| DCD | Data Carrier Detect |
| DIAG | Diagnostic |
| DIFF | Differential |
| DMA | Direct Memory Access |
| DP | Data Processing, DataProducts |
| DPMC | Dot Plucker Memory Controller |
| DPU | Data Processing Unit |
| DRAM | Dynamic Random—Access Memory |
| DRVR | Driver |
| DSR | Data Set Ready |
| DTR | Data Terminal Ready |
| EMIT | Emitter |
| EPROM | Electrically Programmable Read-Only Memory |
| ERR | Error |
| EX | Exhaust, Extra |
| EXF | Exhaust Fan |
| FD | Feed |
| FLT | Fault |
| FP | Front Panel (Operator Panel) |
| FTIC | Fire Timer Integrated Circuit |
| GND | Ground |
| HB | Hammer Bank |
| HBF | Hammer Bank Fan |
| HBL | Hammer Bank, Left |
| HBR | Hammer Bank, Right |

| | |
|-----------------------|----------------------------------|
| HD | Hammer Driver |
| HDIC | Hammer Driver Integrated Circuit |
| HDPH | Hammer Driver Phase |
| IC | Integrated Circuit |
| ID | Identification |
| IGP | Intelligent Graphics Processor |
| INT | Interrupt |
| I/O | Input/Output |
| (J) | Jack connector |
| L | Left |
| LCD | Liquid Crystal Display |
| LED | Light Emitting Diode |
| LPI | Lines Per Inch |
| LPM | Lines Per Minute |
| MECH | Mechanism |
| MH | Mounting Hole, Main Harness |
| MOT | Motor |
| MPU | Magnetic Pick-Up (Unit) |
| N | Negative True |
| N/C | Not Connected |
| NC | Not Connected |
| No | Number |
| NOVRAM | Nonvolatile Random-Access Memory |
| NVRAM | Nonvolatile Random-Access Memory |
| P5 | + 5 V dc |
| (P) | Pin connector |
| P(1), P(2), etc. | Parallel data 1, data 2, etc. |
| PAL | Programmable Array Logic |
| PCBA | Printed Circuit Board Assembly |
| PCB | Printed Circuit Board |
| PE | Printer Error, Paper Empty |

| | |
|------------|-------------------------------|
| PER | Peripheral Device |
| PFC | Paper Feed Controller |
| PFM | Paper Feed Motor |
| PI | Paper Instruction |
| PLAT | Platen |
| PLM | Platen Motor |
| PMD | Paper Motion Detect |
| PO | Paper Out |
| PPR | Paper |
| PROM | Programmable Read-Only Memory |
| PS | Power Supply |
| PS5 | Power Supply + 5 Volt |
| PWM | Pulse Width Modulation |
| | |
| R | Right |
| RBN | Ribbon |
| RD | Read |
| RET | Return |
| RG | Ribbon Guide |
| RGL | Ribbon Guide, Left |
| RGR | Ribbon Guide, Right |
| RM | Ribbon Motor |
| RML | Ribbon Motor, Left |
| RMR | Ribbon Motor, Right |
| RQ | Request |
| RSP | Ribbon and Shuttle Processor |
| RST | Reset |
| RTPU | Real-Time Processing Unit |
| RTS | Request to Send |
| RXD | Receive Detect |
| | |
| SCS | SNA Character Stream |
| SEC | Security (Key) |
| SEL | Select |
| SEN | Sense, Sensor |
| SHH | Shuttle Hall (Effect) |
| SHM | Shuttle Motor |

SHUT Shuttle
 SLCT Select (On-line)
 SNA Systems Network Architecture
 SRAM Static Random-Access Memory
 SW Switch

 TXD Transmit Detect

 UART Universal Asynchronous Receiver/Transmitter
 UDPH Upper Drive Phase
 USART Universal Synchronous/Asynchronous
 Receiver/Transmitter

 V Volts
 VCC 5 Volts DC
 VDD Voltage at Drain
 VSS Voltage at Source

 WR Write

 XMT Transmit



Power Cords

| Part No. | Units | Description |
|----------|-------|--|
| 57G7261 | 1 | Power Cord, 110V 6 Feet Non-Lock, U.S., Canada |
| 46F2112 | 1 | Power Cord, 220V 6 Feet Non-Lock, U.S., Canada |
| 57G7260 | 1 | Power Cord, 110V 12 Feet Non-Lock, U.S., Canada, Brazil, Cayman Islands, Costa Rica, Dominican Republic, El Salvador, Guatemala, Mexico, Liberia, Panama, Saudi Arabia, Phillipines, Honduras, Peru, Columbia, Nicaragua, Bermuda, Bahamas, Barbados, Bolivia, Guyana, Ecuador, Haiti, Jamaica, Venezuela, Netherlands, Antilles, Trinidad, Suriname, Taiwan, Tobago, Saint Lucia, Indonesia |
| 1838573 | 1 | Power Cord, 220V 12 Feet Non-Lock, U.S., Canada, Honduras, Nicaragua, Peru, Phillipines, Saint Lucia, Taiwan, Thailand, Tobago, Panama |
| 80F7277 | 1 | Power Cord, 110V 6 Feet Twist-Lock, U.S., Canada |
| 80F7278 | 1 | Power Cord, 220V 6 Feet Twist-Lock, U.S., Canada |
| 7842142 | 1 | Power Cord, 110V 12 Feet Twist-Lock, U.S., Canada |
| 7842124 | 1 | Power Cord, 220V 12 Feet Twist-Lock, U.S., Canada |
| 46F5893 | 1 | Power Cord, 110V 6 Feet Watertight, U.S., Canada |
| 73F5157 | 1 | Power Cord, 220V 6 Feet Watertight, U.S., Canada |
| 46F5894 | 1 | Power Cord, 110V 12 Feet Watertight, U.S., Canada |
| 73F4932 | 1 | Power Cord, 220V 12 Feet Watertight, U.S., Canada |
| 13F9941 | 1 | Power Cord, 12 Feet, Argentina, Australia, Colombia, New Guinea, New Zealand, Paraguay, Samoa, Uruguay |
| 13F9979 | 1 | Power Cord, 9 Feet, Afghanistan, Algeria, Angola, Austria, Belgium, Benin Republic/Dahomey, Bulgaria, Burundi, Cameroon, Chad, Congo/Brazzaville, Central Africa Empire, Czechoslovakia, East Germany, Egypt, Finland, France, Greece, Guinea, Hungary, Iceland, Indonesia, Iran, Ivory Coast, Jordan, Korea, Lebanon, Luxembourg, Mali, Madagascar, Mauritania, Monaco, Morocco, Mozambique, Netherlands, Norway, Poland, Portugal, Rhodesia, Romania, Spain, Sudan, Sweden, Syria, Togo, Tunisia, Turkey, Upper Volta, USSR, West Germany, Yugoslavia, Zaire |
| 13F9997 | 1 | Power Cord, 9 Feet, Denmark |
| 14F0015 | 1 | Power Cord, 9 Feet, Bangladesh, Burma, Pakistan, South Africa, Sri Lanka |
| 14F0033 | 1 | Power Cord, 9 Feet, Bahrain, Brunei, Channel Islands, PRC, Cyprus, Hong Kong, India, Iraq, Ireland, Kenya, Kuwait, Malaysia, Malta, Nepal, Nigeria, Oman, Polynesia, Qatar, Sierra Leone, Singapore, Tanzania, Uganda, United Arab Emirates, U.K., Zambia |
| 14F0051 | 1 | Power Cord, 9 Feet, Switzerland, Liechtenstein |
| 14F0069 | 1 | Power Cord, 9 Feet, Chile, Ethiopia, Italy, Libya |
| 14F0087 | 1 | Power Cord, 9 Feet, Israel |
| 1332167 | 1 | Power Cord, 12 Feet, Japan |
| 57G7262 | 1 | Power Cord, No Plug |
| 38F8254 | 1 | Twinax Auto-Termination Cable |



Part Numbers

| Part Number | Page | Description |
|-------------|-----------------|----------------------------------|
| 0264641 | NO TAG | E-Ring |
| 0311072 | NO TAG | Ring, Grip |
| 04H4779 | NO TAG | Riser, Stacker Runner |
| 08H7828 | NO TAG A-14 | Cable Assembly, +5V Power Supply |
| 08H7926 | NO TAG | IBM Logo |
| 08H7936 | NO TAG | Platen |
| 08H7954 | NO TAG | Static Brush |
| 08H7950 | NO TAG | RH Bracket |
| 08H7951 | NO TAG | LH Bracket |
| 08H7955 | NO TAG | Hanger, Chain Assembly |
| 08H7956 | NO TAG | Chain Assembly, Stacker Inner |
| 14H7231 | NO TAG, A-12 | Multi I/O Assembly |
| 14H7253 | NO TAG | Diskette, IPDS Twinax |
| 14H7254 | NO TAG | Diskette, IGP-200 + IPDS Twinax |
| 14H7255 | NO TAG | Diskette, Code V + IPDS Twinax |
| 14H7256 | NO TAG | Diskette, Base Machine, Twinax |
| 14H7257 | NO TAG | Diskette, Code V, Twinax |
| 14H7258 | NO TAG | Diskette, IGP-200, Twinax |

| Part Number | Page | Description |
|-------------|----------------|---|
| 30H3962 | NO TAG | Window, Top Cover |
| 30H3963 | NO TAG | Diskette, Base Machine, Coax |
| 30H3964 | NO TAG | Diskette, Code V, Coax |
| 30H3965 | NO TAG | Diskette, IGP-200, Coax |
| 30H3966 | NO TAG | PROM Kit |
| 30H3981 | NO TAG | Runner, Stacker |
| 30H3985 | NO TAG | Extension Spring |
| 38F8254 | A-23 | Cable Assembly, Twinax Auto-Termination |
| 42F1814 | NO TAG | Clip, Parallel Port |
| 43F1678 | NO TAG | Fan Guard |
| 43F1678 | NO TAG | Fan Guard |
| 57G1418 | NO TAG | Operator Panel Assembly |
| 57G1421 | NO TAG | Motor Pulley, Paper Feed |
| 57G1437 | NO TAG A-11 | PCBA, Power Supply |
| 57G1438 | NO TAG | Circuit Breaker |
| 57G1440 | NO TAG | Fan Assembly, Cabinet exhaust |
| 57G1440 | NO TAG | Fan Assembly, Card Cage |
| 57G1441 | NO TAG | Panel Bracket |
| 57G1443 | NO TAG | Shuttle Frame Assembly |
| 57G1446 | NO TAG A-8 | PCBA, Mechanism Driver |
| 57G1447 | A-18 | Wire Harness, Main (W6) |
| 57G1448 | NO TAG A-16 | Cable Assembly, Hammer Bank (W4) |
| 57G1449 | NO TAG | Ribbon Guide Assembly, Left |

| Part Number | Page | Description |
|-------------|----------------|--|
| 57G1450 | NO TAG | Ribbon Guide Assembly, Right |
| 57G1451 | NO TAG | Platen Interlock Switch Assembly |
| 57G1452 | NO TAG A-17 | Cable Assembly, Intermediate (W5) |
| 57G1453 | NO TAG | Paper Detector Switch Assembly |
| 57G1454 | NO TAG A-13 | CCB/Mech. Driver Cable Assembly (W1) |
| 57G1456 | NO TAG A-20 | Cable Assembly, AC/Ground |
| 57G1457 | A-15 | Cable Assembly, High Voltage (W3) |
| 57G1460 | NO TAG | Shaft Assembly, Splined |
| 57G1461 | NO TAG | Splined Shaft Pulley (Vertical Adjustment Knob) |
| 57G1463 | NO TAG | Platen Open Motor |
| 57G1463 | NO TAG | Paper Feed Motor |
| 57G1464 | NO TAG | Hammer Bank Fan Assembly |
| 57G1465 | NO TAG | Cover Open Switch Assembly |
| 57G1466 | NO TAG | Tractor Set, L/R |
| 57G1467 | NO TAG | Platen Open Belt |
| 57G1468 | NO TAG | Paper Feed Timing Belt |
| 57G1469 | NO TAG | Ironer, Paper |
| 57G1472 | NO TAG | Bracket, Platen |
| 57G1473 | NO TAG | Link Spring |
| 57G1474 | NO TAG | Clamp, Bearing |
| 57G1475 | NO TAG | Hammer Spring Replacement Kit |
| 57G1476 | NO TAG | Magnetic Pickup Assembly (MPU) |

| Part Number | Page | Description |
|-------------|-------------------|--|
| 57G1477 | NO TAG | Hammer Bank Cover Assembly |
| 57G1479 | NO TAG | Ribbon Spool Hub Kit (includes 6-19x.50 set screw) |
| 57G1481 | NO TAG | Gas Spring Assembly |
| 57G1483 | NO TAG | Ball Stud |
| 57G1484 | NO TAG | Door Hinge |
| 57G1485 | NO TAG | Caster, with Brake |
| 57G1486 | NO TAG | Caster, without Brake |
| 57G1488 | NO TAG | Front Door Assembly |
| 57G1489 | NO TAG | Rear Door Assembly |
| 57G1507 | NO TAG | Collar |
| 57G1508 | NO TAG | Shuttle Cover Assembly (Air Shroud Assembly) |
| 57G1509 | NO TAG | Platen Open Motor Assembly |
| 57G1510 | NO TAG, NO TAG | Bearing, Nylon .376 |
| 57G1512 | NO TAG | Timing Belt Cover |
| 57G1513 | NO TAG | Cover, Platen Open |
| 57G1514 | NO TAG | Pulley, Platen Open |
| 57G1516 | NO TAG | Washer, Curved Spring |
| 57G1517 | NO TAG | Knob, Tractor Adjust |
| 57G1518 | NO TAG | Bracket, Switch Mount |
| 57G1519 | NO TAG | Tractor Support Shaft |
| 57G1521 | NO TAG | Clip, Grounding |
| 57G1522 | NO TAG | Spring, Extension 1.12L |
| 57G1523 | NO TAG | Link, Spring |

| Part Number | Page | Description |
|-------------|--------|--|
| 57G1524 | NO TAG | Spring, Extension 1.00L |
| 57G1525 | NO TAG | Top Cover |
| 57G1526 | NO TAG | Operator Panel Plate |
| 57G1564 | NO TAG | Chain Assembly, Stacker Outer |
| 57G1566 | NO TAG | Wireform Paper Path |
| 57G1568 | NO TAG | Paper Guide Assembly |
| 57G1571 | NO TAG | Bracket, Ironer |
| 57G1572 | NO TAG | Bracket, MPU |
| 57G1577 | NO TAG | Ribbon Drive Motor |
| 57G1582 | NO TAG | Label, Forms Length |
| 57G1594 | NO TAG | 6408-CTA Ship Kit |
| 57G1598 | NO TAG | Operator Panel Overlay (English) |
| 57G1599 | NO TAG | Operator Panel Overlay (Spanish) |
| 57G1600 | NO TAG | Operator Panel Overlay (French) |
| 57G1601 | NO TAG | Operator Panel Overlay (Italian) |
| 57G1602 | NO TAG | Operator Panel Overlay (German) |
| 57G1603 | NO TAG | Operator Panel Overlay (Dutch) |
| 57G1604 | NO TAG | Operator Panel Overlay (Brazilian / Portuguese) |
| 57G1663 | NO TAG | Security Module, IGP-200 Security Module, Code V |
| 57G1664 | NO TAG | Diskette, IGP-200 |
| 57G1684 | NO TAG | Security Module, IPDS Twinax Security Module, IPDS Coax |
| 57G1686 | NO TAG | 4MB Memory Kit (IPDS Feature only) |
| 57G1696 | NO TAG | Diskette, IPDS Coax |

| Part Number | Page | Description |
|-------------|----------------|--|
| 57G1706 | NO TAG | Security Module, IGP-200 + IPDS Twinax Security Module, IGP-200 + IPDS Coax Security Module, Code V + IPDS Twinax Security Module, Code V + IPDS Coax |
| TBD | NO TAG | Diskette, IGP-200 + IPDS Coax |
| TBD | NO TAG | Diskette, Code V + IPDS Coax |
| 57G1750 | NO TAG | Disk Drive, Floppy 3.5, 2.88MB |
| 57G1752 | NO TAG | Security Module, Base Machine |
| 57G1753 | NO TAG A-21 | Cable Assembly, Floppy Power |
| 57G1764 | NO TAG A-22 | Cable Assembly, Floppy Interface |
| 57G1765 | NO TAG | Disk Drive Bracket |
| 57G1768 | NO TAG A-4 | PCBA, Controller |
| 57G1769 | NO TAG A-6 | PCBA, LP30 Backplane |
| 57G3752 | NO TAG | Line Filter |
| 57G3753 | NO TAG | PCBA Rail |
| 57G3889 | NO TAG | Paper Detector Switch Assembly (Black back forms) |
| 57G3899 | NO TAG | Lever, Platen (Forms Thickness Lever) |
| 57G7176 | NO TAG | Stacker Assembly |

Index

Numbers

001 END OF FORMS / LOAD FORMS, 4-8
002 FORMS JAMMED / CLEAR JAM AND
RELOAD FORMS, 4-8
006 HOST SYSTEM REQUEST
ATTENTION, 4-6
008 HOLD PRINT TIMEOUT / PRESS
START, 4-6
015 COMMUNICATIONS CHECK /
CHECK CABLE, 4-7
017 COMMUNICATIONS CHECK /
CHECK CABLE, 4-7
021 SERIAL BUFFER OVERRUN /
VERIFY CONFIGURATION, 4-7
022 UNIT ADDRESS NOT RECEIVED /
CHECK PRINTER ADDRESS, 4-7
024 SERIAL LINE PARITY ERROR /
VERIFY CONFIGURATION, 4-7
025 SERIAL FRAMING ERROR / VERIFY
CONFIGURATION, 4-7
027 COMMUNICATIONS CHECK / CALL
SYSTEM OPERATOR, 4-7
028 COMMUNICATIONS CHECK / CALL
SYSTEM OPERATOR, 4-7
031 END OF FORMS TIMEOUT / LOAD
FORMS, 4-8
032 FORMS JAMMED TIMEOUT / CLEAR
JAM AND RELOAD FORMS, 4-8
051 HAMMER DRIVER SHORT, 4-9
052 MECHANISM DRIVER HOT, 4-9
053 48 VOLTS FAILED, 4-9
054 HAMMER COIL SHORT, 4-9
055 MECHANISM DRIVER LINK
FAILURE, 4-9

056 HAMMER COIL OPEN, 4-9
057 CLOSE PLATEN, 4-8
058 SHUTTLE JAM, 4-8
059 HAMMER BANK HOT, 4-9
089 RIBBON JAM, 4-8
090 CLOSE SHUTTLE COVER, 4-8
091 DISKETTE WRITE ERROR / CHECK
DISKETTE, 4-8
160 SHUTTLE FAN FAILURE, 4-9

A

A97 GRAPHIC CHECK ERROR / PRESS
STOP THEN START, 4-6
About the printer, 1-2
Acronyms, G-1
ACTIVATE LOST, 4-7
Adjustments, 5-1
 end of forms distance, 5-22
 hammer phasing, 5-27
 paper drive motor pulley alignment, 5-8
 paper feed timing belt tension, 5-4
 paper scale, 5-10
 platen angle, 5-12
 platen gap, 5-14
 platen open belt, 5-6
 platen open motor pulley alignment, 5-16
 ribbon guide, 5-18
 splined shaft skew adjustment, 5-20
ASCII Character Set chart, 4-45
Attention condition, 4-4

B

Backplane, replacement, 6-16

Belt

- paper feed timing, replacement, 6-5
- paper feed timing, tension adjustment, 5-4
- platen open, replacement, 6-6
- platen open, tension adjustment, 5-6

Block diagram

- controller board, 7-13
- operator panel, 7-4
- RTPU, host interfaces, 7-7

Boards: layouts, connections, and pin-outs, A-1

C

Cable assembly

- hammer bank, replacement, 6-8
- I/O, replacement, 6-12
- interconnections, A-1
- intermediate, replacement, 6-10
- part numbers, A-1

Cancel key, 1-6

Card cage, fan assembly, replacement, 6-26

CE Tests, 4-40

Character Set, U.S. ASCII, 4-45

Checks, service

- customer's power source, F-7
- power on/off verification, F-8
- print interlock, F-8
- print mechanism, F-4
- printer power cable, F-7
- safety ground path, F-5
- top cover and doors, F-3

Circuit board, replacement

- controller, 6-14

LP30 backplane, 6-16

mechanism driver, 6-18

power supply, 6-20

Circuit breaker, replacement, 6-21

Cleaning the printer, 3-3

Configuration, 2-1

Print key, 1-6

Controller board, diagnostic check, 4-35

Controller circuit board, replacement, 6-14

Controls and indicators, 1-6

- mechanical, all models, 1-8
- printing conventions, 1-5

Conversion, metric measurement, D-1

Cords, power, H-1

Cores, Noise Suppression, C-1

Cover assembly

- hammer bank, replacement, 6-22
- shuttle, replacement, 6-23

D

Diagnostic self-tests

- customer engineer, 4-40
- operator print, 4-37

Diagrams

- ground path, F-1
- interconnection and cables, A-1

Dimensions, printer, B-3

Disk drive, replacement, 6-24

Diskette and security module cross-reference chart, 6-47

Display messages, printing conventions, 1-5

Documents related to this manual, 1-4

Drive assembly, diskette, replacement, 6-24

Duty cycle, B-2

E

Eject/Restore key, 1-6
Electrical characteristics, B-4
End of Forms Adjust, procedure, 5-22
Enter key, 1-6
Environmental characteristics, B-4
Error log, 4-37
Error messages, 4-4
 See also Messages
ERROR: INCORRECT FONTS ON DISK,
 4-5

F

Fan assembly
 card cage, replacement, 6-26
 hammer bank, replacement, 6-27, 6-28
Fault messages. *See* Messages
Ferrite Noise Suppression Cores, C-1
Floppy drive assembly, replacement, 6-24
FM HEADER ERROR, 4-8
Form Feed key, 1-6

G

Gap, adjustment
 magnetic pick-up (MPU), 6-32
 platen, 5-14
Ground path diagram, F-1

H

Hammer
 phasing adjustment, 5-27
 spring assembly, replacement, 6-29
Hammer bank
 cover assembly, replacement, 6-22

fan assembly, replacement, 6-27, 6-28
wiring diagram, A-1

Hammer phasing adjustment, 5-27

Hard reset, 4-46

Hex code printout, 4-43

Hub, ribbon, replacement, 6-50

I

ICs, location and replacement, Mech. Driver
 board, 6-48

Illustrations, replacement procedures, 6-65

Inspection, safety, guide, F-1

Installation, 2-1

Interface specifications, B-5

INVALID

 ACTIVATE, 4-7

 COMMAND, 4-7

K

Keys, locations and operation, 1-6

Keys, operator panel, 1-6

L

LANGUAGE FILE NOT AVAILABLE, 4-5

LCD, 1-6

Levers and knobs, 1-8

Line Feed key, 1-6

LOADING FONTS FROM DISK, 4-5

LP30 backplane circuit board, replacement,
 6-16

M

Magnetic pick-up assembly, replacement,
6-32

Maintenance

adjustments, 5-1
cleaning the printer, 3-3
overview, 1-1
preparing the printer for, 6-4
preventive, 3-1

Manual

how to use, 1-3
notes and notices, 1-3
printing conventions, 1-5
related documents, 1-4

Mechanical controls and indicators, 1-8

Mechanism driver circuit board, replacement,
6-18

Menu key, 1-6

Messages

001 END OF FORMS / LOAD FORMS,
4-8
002 FORMS JAMMED / CLEAR JAM
AND RELOAD FORMS, 4-8
006 HOST SYSTEM REQUEST
ATTENTION, 4-6
008 HOLD PRINT TIMEOUT / PRESS
START, 4-6
015 COMMUNICATIONS CHECK /
CHECK CABLE, 4-7
017 COMMUNICATIONS CHECK /
CHECK CABLE, 4-7
021 SERIAL BUFFER OVERRUN /
VERIFY CONFIGURATION, 4-7
022 UNIT ADDRESS NOT RECEIVED /
CHECK PRINTER ADDRESS, 4-7
024 SERIAL LINE PARITY ERROR /
VERIFY CONFIGURATION, 4-7

025 SERIAL FRAMING ERROR /
VERIFY CONFIGURATION, 4-7
027 COMMUNICATIONS CHECK /
CALL SYSTEM OPERATOR, 4-7
028 COMMUNICATIONS CHECK /
CALL SYSTEM OPERATOR, 4-7
031 END OF FORMS TIMEOUT / LOAD
FORMS, 4-8
032 FORMS JAMMED TIMEOUT /
CLEAR JAM AND RELOAD FORMS,
4-8
051 HAMMER DRIVER SHORT, 4-9
052 MECHANISM DRIVER HOT, 4-9
053 48 VOLTS FAILED, 4-9
054 HAMMER COIL SHORT, 4-9
055 MECHANISM DRIVER LINK
FAILURE, 4-9
056 HAMMER COIL OPEN, 4-9
057 CLOSE PLATEN, 4-8
058 SHUTTLE JAM, 4-8
059 HAMMER BANK HOT, 4-9
089 RIBBON JAM, 4-8
090 CLOSE SHUTTLE COVER, 4-8
091 DISKETTE WRITE ERROR /
CHECK DISKETTE, 4-8
160 SHUTTLE FAN FAILURE, 4-9
A97 GRAPHIC CHECK ERROR / PRESS
STOP THEN START, 4-6
ACTIVATE LOST, 4-7
ERROR: INCORRECT FONTS ON
DISK, 4-5
FM HEADER ERROR, 4-8
INVALID ACTIVATE, 4-7
INVALID COMMAND, 4-7
LANGUAGE FILE NOT AVAILABLE,
4-5
LOADING FONTS FROM DISK, 4-5
P01 INIT. RTPU-PFC
COMMUNICATION, 4-5

P02 INIT. RTPU-RSP
 COMMUNICATION, 4-5
 P03 STATIC RAM TEST, 4-5
 P04 WAITING FOR DPU, 4-5
 P05 DIAGNOSTIC TEST PASSED, 4-5
 P06 ERROR: CANNOT READ DISK, 4-5
 P07 LOADING PROGRAM FROM
 DISK, 4-6
 P08 ERROR: INCORRECT FILE
 FORMAT, 4-6
 P09 8344 DIAGNOSTIC FAILED, 4-6
 P10 ERROR: EMULATION FAILED, 4-6
 P14 FAULT CONDITION / STATIC
 RAM*, 4-6
 P15 FAULT CONDITION / DPU
 TIMEOUT*, 4-6
 P16 FAULT CONDITION / 64180 OP
 CODE*, 4-6
 P17 SECURITY VIOLATION, 4-6
 PARAMETER ERROR, 4-7
 SCS COMMAND ERROR, 4-7
 STRUCTURED FIELD ERROR, 4-8

Messages, fault, 4-4

Metric measurement, conversion tables, D-1

Micro keys, 1-6

Mnemonics, G-1

Motor

 paper feed drive, replacement, 6-34

 platen open, replacement, 6-36

 ribbon drive, replacement, 6-33

MPU. *See* Magnetic pick-up assembly

N

Noise suppression, C-1

Notes and notices, 1-3

O

Operation, principles of, 7-1

Operator panel

 block diagram, 7-4

 replacement, 6-38

P

P01 INIT. RTPU-PFC COMMUNICATION,
 4-5

P02 INIT. RTPU-RSP COMMUNICATION,
 4-5

P03 STATIC RAM TEST, 4-5

P04 WAITING FOR DPU, 4-5

P05 DIAGNOSTIC TEST PASSED, 4-5

P06 ERROR: CANNOT READ DISK, 4-5

P07 LOADING PROGRAM FROM DISK,
 4-6

P08 ERROR: INCORRECT FILE FORMAT,
 4-6

P09 8344 DIAGNOSTIC FAILED, 4-6

P10 ERROR: EMULATION FAILED, 4-6

P14 FAULT CONDITION / STATIC RAM*,
 4-6

P15 FAULT CONDITION / DPU
 TIMEOUT*, 4-6

P16 FAULT CONDITION / 64180 OP
 CODE*, 4-6

P17 SECURITY VIOLATION, 4-6

Paper

 detector switch assembly, replacement,
 6-60

 drive motor pulley alignment, 5-8

 feed drive motor, replacement, 6-34

 feed timing belt replacement, 6-5

 feed timing belt tension adjustment, 5-4

- ironer, replacement, 6-41
- scale adjustment, 5-10
- specifications, B-3
- tractor (L/R), replacement, 6-62
- Paper detector switch, replacement, 6-60
- Paper guide assembly, removal, 6-40
- Paper jams, 4-8
- PARAMETER ERROR, 4-7
- Parts
 - illustrations, 6-65
 - replacement procedures, 6-4
- Phasing adjustment, 5-27
- Pin-outs, A-1
- Platen
 - angle adjustment, 5-12
 - gap adjustment, 5-14
 - interlock switch assembly, replacement, 6-61
 - platen open belt adjustment, 5-6
 - platen open motor, replacement, 6-36
- Platen replacement, 6-43
- Plot, rates, B-6
- Power, on/off verification, F-8
- Power cords, H-1
- Power distribution diagram, A-3
- Power supply, circuit board replacement, 6-20
- Principles of operation, 7-1
- Print Configuration key, 1-6
- Printer
 - About the 6408-CTA, 1-2
 - adjustments, 5-1
 - cleaning, 3-3
 - configuration, 2-1
 - dimensions, B-3
 - duty cycle, B-2

- installation, 2-1
- maintenance overview, 1-1
- preparing the printer for maintenance, 6-4
- principles of operation, 7-1
- reset, 4-46
- self-tests
 - customer engineer, 4-40
 - operator print, 4-37
- specifications, B-1
- troubleshooting, 4-1
- Printing, conventions in this manual, 1-5
- Printouts, hex code, 4-43
- Procedures
 - adjustment, 5-1
 - cleaning, 3-3
 - safety inspection, F-1
- PROMs and modules, location and replacement, controller board, 6-46
- PROMs, location and replacement, Mech. Driver board, 6-48

R

- Replacement
 - backplane, 6-16
 - card cage fan assembly, 6-26
 - circuit breaker, 6-21
 - controller circuit board, 6-14
 - cover open switch assembly, 6-59
 - diskette drive assembly, 6-24
 - extension spring, 6-58
 - gas spring assembly, 6-57
 - hammer bank cable assembly, 6-8
 - hammer bank cover assembly, 6-22
 - hammer bank fan assembly, 6-27, 6-28
 - hammer spring, 6-29
 - I/O cable assembly, 6-12
 - intermediate cable assembly, 6-10

LP30 backplane circuit board, 6-16
 magnetic pick-up assembly, 6-32
 mechanism driver circuit board, 6-18
 operator panel assembly, 6-38
 paper detector switch assembly, 6-60
 paper feed drive motor, 6-34
 paper feed timing belt, 6-5
 paper guide assembly, 6-40
 paper ironer, 6-41
 paper stacker assembly, 6-42
 platen, 6-43
 platen interlock switch assembly, 6-61
 platen open belt, 6-6
 platen open motor, 6-36
 power supply circuit board, 6-20
 PROMs, Mech. Driver board, 6-48
 PROMs and modules, controller board,
 6-46
 ribbon drive motor, 6-33
 ribbon guide assembly (L/R), 6-51
 ribbon hub, 6-50
 shuttle cover assembly, 6-23
 shuttle frame assembly, 6-55
 splined shaft, 6-52
 stacker, paper, assembly, 6-42
 support shaft, 6-54
 tractor (L/R), 6-62
 Reset, soft vs. hard, 4-46
 Return key, 1-6
 Ribbon
 drive motor, replacement, 6-33
 guide assembly (L/R), replacement, 6-51
 guide assembly, alignment, 5-18
 hub, replacement, 6-50
 specifications, B-2

S

Safety
 inspection guide, F-1
 notices, viii
 notices, defined, 1-3
 Scroll keys, 1-6
 SCS COMMAND ERROR, 4-7
 Security module, location and diskette
 reference chart, 6-47
 Self-tests
 customer engineer, 4-40
 operator print, 4-37
 Service checks
 customer's power source, F-7
 power on/off verification, F-8
 print interlock, F-8
 print mechanism, F-4
 printer power cable, F-7
 safety ground path, F-5
 top cover and doors, F-3
 Set Top Of Form key, 1-6
 Shaft
 splined, replacement, 6-52
 splined, skew adjustment, 5-20
 support, replacement, 6-54
 Shuttle
 cover assembly, replacement, 6-23
 frame assembly, replacement, 6-55
 Signal acronyms and mnemonics, G-1
 Soft reset, 4-46
 Specifications
 dimensions, printer, B-3
 duty cycle, B-2
 electrical, B-4
 environmental, B-4
 interfaces, B-5
 paper, B-3

- printing rates, B-6
- ribbon, B-2
- Speed, printing, B-6
- Splined shaft
 - replacement, 6-52
 - skew adjustment, 5-20

Spring

- extension, replacement, 6-58
- gas, assembly, replacement, 6-57
- Stacker, paper, assembly, replacement, 6-42
- Start key, 1-6
- Stop key, 1-6
- STRUCTURED FIELD ERROR, 4-8
- Supplies, tools, and test equipment, 1-10
- Support shaft, replacement, 6-54

Switch

- cover open switch assembly, replacement, 6-59
- paper detector switch assembly, replacement, 6-60
- platen interlock switch assembly, replacement, 6-61
- power, replacement, 6-21

T

- Tension adjustment
 - paper feed timing belt, 5-4
 - platen open belt, 5-6
- Test, equipment, tools, and supplies, 1-10

Tests

- controller board, 4-35
- customer engineer, 4-40
- print, operator, 4-37

- Tools, test equipment, and supplies, 1-10

Torque

- conversion to or from metric, D-1

- table, E-1

- Tractor, replacement, 6-62

- Troubleshooting, 4-1

- fault messages, 4-4

- symptoms not indicated by fault messages, 4-29

U

- Unit check condition, 4-4

V

- View key, 1-6

W

- Wiring diagrams, A-1